

1 Scrap profile

Overview

Menu	Order management → Order controlling → Scrap profile
Transaction code	scrf
Function authorization	scrf

Any person in a company who wants to reduce scrap must have knowledge of how and where scrap is accrued. The *Scrap profile* provides an overview of all scrap reasons and scrap quantities that were recorded in a specified period of time.

Selection criteria

The application provides the following selection criteria:

Date

Enter a period of time to narrow down the log records displayed. The application selects the BDE log records of record type T with a posting time that is included in the period of time specified.

Shift

In the period of time specified above, only those log records are selected that are assigned to the shift specified.

Time

In the period of time specified above, only those log records are selected that were booked in the time specified.

Workplace/group/cost center/company/short name/designation/responsibility area

These entries specify the workplaces/machines used for the evaluation. To select an entry, you access the master data of the workplace/machine configuration.

Report group

Use the option *Report group* to narrow down the selection to a specific group of workplaces/machines. You must define the report group in the [group configuration](#).

Reason

Selection based on a specific scrap reason.

Order/order type

You can limit the evaluation to one order.

Article

Selection according to the article

Sales order

If a sales order is assigned to the production order, this sales order can be used to select the data.

Project number

If a project number is assigned to the production order, this number can be used to select the data.

Check responsibility area

Using this option, the user can specify if the system checks the responsibility area of the workplace or the responsibility area of the object operation/order to display data. To use this selection option, you require the function authorization chkresp.



This selection option is only available, if you enable the extension [scrpf2](#).



If the selection period exceeds the period of time of the online data area, the system implicitly selects the data of the medium-term data area. You need not explicitly activate the access to the medium-term data area.

Condition: the data retention periods of orders (object ANR) and of log records (object ADEPRO) must be identical.

Detail application *Scrap profile*

The detailed report *Scrap profile* provides a table including all scrap reasons and scrap quantities that were recorded in a specified period of time.

Note on the column *Scrap rate*:

The scrap rate refers to the total quantity booked in the selected period of time (total of yield, scrap, rework quantity and open quantity in primary quantity unit) for the combination workplace/MES order number.

Example: in a specified period of time, the following quantities have been recorded at a workplace for an order/operation:

Day	Yield	Scrap
1	10	1
2	12	0
3	0	0
4	14	1
5	8	2

If you select the period of time Day 2 - Day 5, then the days 4 and 5 show scrap quantities that are displayed in the *Scrap profile*. The scrap rate refers to the total quantity booked in the selected period of time (here: $12+14+8+1+2 = 37$):

Day	Scrap	Scrap rate
4	1	2.7
5	2	5.4



To calculate the scrap rate, the system also uses postings that only include a yield, but no scrap. Entries in the result line with a scrap quantity of 0 are therefore possible.

You can hide these entries using the *Filter editor*.

Detail application *PivotGrid*

The detailed report *PivotGrid* provides an overview of all scrap reasons and scrap quantities that were recorded in a specified period of time. According to the settings of the pivot table, the application shows e.g. one column for each scrap reason. The scrap recorded automatically is displayed separately.

Scrap (P)

This pivot element includes the primary quantities.

Scrap reason

This pivot element includes the scrap reasons (number of the scrap reason).

Date

This pivot element includes the dates when the scrap was recorded.

The detail application contains not only the fields mentioned here, but numerous other fields. You can select these fields using the field list. Right-click the area above the column headers to open the context menu and select *Show field list*.



To calculate the scrap rate, the system also uses postings that only include a yield, but no scrap. Entries in the result line with a scrap quantity of 0 are therefore possible.

You can hide these entries using the *Filter editor*.