

1 ABC Analysis

Overview

Menu	Production Facility Management → Status analyses → ABC analysis
Transaction code	stabc
Function authorization	stabc

Purpose

This report lists all malfunctions that occurred while the selected machine was running. The ABC analysis is intended to be a pure report on "Failures" = "Malfunctions". For this reason, the status "Production" is not evaluated.

The statuses are sorted according to the "Pareto Principle" - i.e sorted according to their size, summed up and classified - and classified as A, B and C depending on how long the status lasted. The threshold values are configurable.

Selection criteria

The application provides the following selection criteria:

Workplace

Defines the workplace for which the ABC analysis is to be displayed.

Status type

Restricts the displayed error messages to one status type (depending on license or project).

Threshold value 1

Parameter used to set the ABC threshold values. For threshold value 1, the threshold is defined between the limits A and B. The predefined value is 50 %.

Threshold value 2

Parameter used to set the ABC threshold values. For threshold value 2, the threshold is defined between the limits B and C. The predefined value is 30 %.

Date from ...to (Shift / Time)

The error messages of the selected period of time are used.

Field descriptions

Status

Status number. The coloring is based on the status text configuration.

Status text

Status name

Status type

The selection criteria restrict the displayed status type (depending on license or project). For example, the selection criteria provide the following status types:

- Machine status
- Malfunction
- Operation mode
- Operation state
- Program
- ...

Status type designation

Designation of the active status type

Duration, %

Total status duration indicating how long the status was active at the machine and percentage of the total duration.

Quantity, %

Number indicating how often this status was active at the machine and percentage of the total number.

Shift

Shift number indicating the shift when the status was active.

Shift start / End of shift

Beginning and end of shift during which the status was active.

Detail application *ABC analysis*

The detail application *ABC analyses* provides a sum total of all accrued durations and displays the number of individual postings included. The data is classified in the three classes A, B and C. The classification is based on the percentages referring to the total duration. The values are totaled according to the "Pareto principle", i.e. the individual rows are sorted by their size in descending order into the classes A to C and added to the class until the total sum exceeds the threshold value (to be more precise: threshold value specified 100 %). Then the next class is filled.

Detail application *Individual listing*

If you select a row in the ABC analysis, the *Individual listing* shows the individual rows included in the selected row.