

1 Status Classes

Summary

Menu	Master data → Workplaces/ machine → Status classes
Transaction code	stc
Function authorization	mdstc

Status classes are created to group and evaluate workplace/ machine statuses into user-related classes independently from the HYDRA resource performance accounts. When the selection mask is called up, the system lists all of the status classes that have already been defined.

Usage

Create status classes if you would like to make use of evaluations of such respectively. The status classes are then assigned to the relevant status during the status assignment process.

Define a unique number for it.

The abbreviation is used to create a link to the status, which is why it must be unique.

The status class *Designation* is used for display purposes in the various evaluations.



In order to keep the status class abbreviations consistent with the RPA abbreviations, we recommend that you enter the status class abbreviation in upper case.

Integration

The status classes can also be evaluated in the various MOC evaluations in addition to the RPA and status evaluations.

The status classes can be assigned to the separate status types in [status assignment](#).

Field descriptions

Status class

Unique status class number

Status class abbreviation

Abbreviation of the status class. It must be unique. Recommendation: Use upper case letters.

Designation

Name of the status class