

1 Status Texts

Overview

FEDRA menu	Master data → Workplaces/ machines → Status texts
FEDRA menu	Master data → Workplaces/ machines → Status texts
Transaction code	Mstt
Function authorization	Mdmstt

In the status text dialog, all possible states (statuses) are designated with a descriptive text. These descriptions are then used in the [status assignment](#) performed later. The objective is to use standard status texts for all workplaces and machines.

Purpose

In the status text dialog, all possible states (statuses) are designated with a descriptive text. These descriptions are then used in the [status assignment](#) performed later. The objective is to use standard status texts for all workplaces and machines.

Integration

During status assignment, a status text is assigned to a status.



The colors configured in the status text can be displayed in different evaluations/reports.

Selection criteria

The application provides the following selection criteria:

Status text

Unique status text number

Designation

Status text name

Field descriptions

Status text

Unique status text number

Designation

Informative description of the status. This text is displayed at the terminal, among other places.

Color

You also have the option to assign a color to a status text. This color is taken into account at various places in MOC.

Recommendation:

When setting up a new status text, the status number should preferably match the number of the status that will later be created during status assignment.

Example: The status text 2 "Set up" should be assigned to the status 2 during status assignment.