

1 Unit Conversion

Overview

HYDRA menu	System administration → System settings → Unit conversion
FEDRA menu	System administration → System settings → Unit conversion
Transaction code	unic
Function authorization	mdunic

Purpose

You use this function to convert quantity units in the system.

Integration

You can use the unit conversion function to convert from one unit to another unit.



If a new conversion rule is created that is *not* based on a defined formula, then when a conversion from unit A → unit B is set up, the system automatically also creates a conversion from unit B → unit A.



Changing a conversion rule for unit A → unit B will have no effect on the existing conversion rule for unit B → unit A.

Requirements

The units that you would like to convert must exist in the system (create it, for example, using the function "unit").



Customizations are documented in the customer-specific documentation (CID).

Field descriptions

From unit

Initial unit from which the conversion should be performed

To unit

Target unit to which the conversion should be performed

Material

Material number if the conversion rule is material related.

Material type

Material type if the conversion rule is material type related.

Conversion factor

A button that allows a conversion to be made using conversion factors that are also defined in the dialog. In this case the formula is as follows:

$$y = \frac{Numerator}{Denominator} * 10^{Exponent} + Offset$$

Counters

Numerator in the conversion fraction

Denominator

Denominator in the conversion fraction

Exponent

Exponent in the conversion factor

Offset

Additive offset

Formula (check box)

A button that allows the conversion to be made using a stored formula.

Formula

A formula definition as an alternative to numerator/ denominator/ exponent/ offset:

This is a formula in the formula context "Quantity conversion" ("Formula management" application)

Rounding

N	Do not round
U	Round up
T	Round down (trunc)
R	Arithmetic rounding (round)

Rounding precision

Rounding to the specified decimal places

[Conversion](#)