

1 Work Plan - Edit Orders

Overview

HYDRA menu	Order management → Routing management → Work plan - edit orders
FEDRA menu	Detailed Scheduling → Order management → Work plan - edit orders
Transaction code	edwor
Function authorization	edwor

Available user fields		
Where	Object type/user field key	Source (type)
Table	AUNR/SYSTEM	Work plan - order (MF-D)
How to configure user fields?		Which user field types are available?

The "Work plan - edit orders" application provides the user with a comfortable option to create or change work plans and to generate orders from work plans. A work plan is a kind of "empty envelope" for orders and is used to generate real orders.

Selection criteria

The application provides the following selection criteria:

Work plan

You can select a specific work plan if you directly enter the work plan number.

Order type

Use the combo boxes to select work plans of specific order types. You can check several options.

Article

Use the article field to search for work plans for a specific article. You can also use wildcards.

Sales order, project number, planned order

Using these fields, you can search by inventory data of the order header. You can also use wildcards.

Customer name

If work plans have been created for separate customers, you can search by the "customer designation". You can also use wildcards.

Field descriptions

Order header fields are described [here](#)

**Notes**

- Only selected data is available in the table:
 - Work plan
 - Order type
 - Article
 - Article designation
 - Target quantity (B)
 - Target scrap (B)
 - Unit (B)
 - Customer name
 - Sales order
 - Planned order
 - Project number
- The below-mentioned values cannot be edited in the work plan order:
 - Basic start date
 - Basic end date
 - Scheduled start time
 - Scheduled end time

Editing functions

Please use the available buttons to create or edit work plan orders.

If a responsibility area is stored for the order, the editing of data is only possible if the options to display, insert, modify and delete are enabled in the configuration of the responsibility areas or profiles.

Toolbar



Generate order

Function authorization: or.generate

You can generate an order from the currently selected work plan by calling this function. For further information on this, please refer to the section [Generate order](#).



Edit long texts of orders

Function authorization: edwortx

Calls the application [Work plan - edit long texts of orders](#).



Edit order sequences

Function authorization: edwseq

Calls the application [Work plan - edit order sequences](#).



Edit operations

Function authorization: edwop

Calls the application [Work plan - Edit operations](#).

Generate order

Please proceed as follows to generate an order from the work plan:

- Select the work plan, from which you want to generate an order, from the table.
- Open the function using the button . The "generate order" dialog opens.
- In the "order" field, enter the order number for the order that is generated. The field can be left empty if numbers are assigned automatically for the order type (customization).
- In the dialog, the input fields are populated with the work plan data. If required, change or add field values.
- Confirm the dialog by clicking .

An order is now generated from the work plan. By default, the application "[Edit orders](#)" opens with the new order that you have just generated.

Note: The *Edit orders* application is opened in a separate window with each order that is generated. It is therefore recommended to close the application before generating a new order.

If you want to suppress that the application *Edit orders* opens, you can configure this via INI configuration/INI data configuration. When the order is successfully generated, a popup informs that the "order xxxx has been successfully generated". Confirm by clicking OK.

Menu: System administration → System settings → INI configuration / INI data configuration

Name: BDE

MOC user: 0

Comment: Settings for Shop Floor Data Collection

Section: EDWOR

Key: GENERATE_ORDER

Value: SUPPRESS_EDOR

Active: 

Comment: Suppress automatic call of application "edit orders"



Notes

- The order cannot be generated if a responsibility area is specified for which the user is not authorized.
- The article number is transferred to the operations of the order.
- The order quantity and the unit are transferred to the order header as (basic) target quantity or target unit and to all operations as basic target quantity or target unit.
- The entered quantity is transferred 1:1 as primary quantity, if the primary quantity unit (primary unit of input) of the operations is identical to the unit that is specified as quantity unit above. If conversion factors are defined for the operation of the order or work plan to be copied, they are used to calculate the primary quantity. In case, no conversion factors are defined and the base quantity unit and primary quantity unit are different, the system tries to convert the base quantity into the primary quantity unit using an internal conversion table (system customization). This procedure generally also applies for the secondary quantity and the tertiary quantity.