

1 Deployment of Layouts of the Shop Floor Monitor

Usage

If layouts are created for the Shop Floor Monitor (MDE-SFM), they may also be transferred to other systems.

Prerequisites

These requirements have to be met:

- The layouts have to be created in the Shop Floor Monitor. It is impossible to transfer layouts from a machinery used with HYDRA 7 or run based on java applets. (Previous version MPARK)
- The used templates and objects, such as workplaces have to be available in the target system.
- The target system has to match the technical status of the source system.
- The target system must not include layouts with the same name.

Procedure

Please proceed as follows to deploy layouts:

- Copy the required layouts (*.zip directories) from the source server to the target system (target server) in the same folder structure:

<Server>\<HYDRA directory>\<system number>\custom\mpark

The ZIP files stored here are filed with their unambiguous, technical name. This name can be shown in the list of layouts of the Shop Floor Monitor application.

- The table `hyd_parklayout` can be unloaded and transferred with the following restrictions:

```
xunload to hyd_parklayout.unl
select * from hyd_parklayout where typ = 'N'
```

Please note: The restriction "type = N" only exports layouts that were created in the Shop Floor Monitor.