

1 Application-Relevant Settings in HYDRA

Maintenance of the HYDRA distribution model - outbound processing

Use the [HYDRA distribution model](#) to maintain entries for HYDRA outbound processing:

Parameter name	Value
For the upload of time tickets	
Message type	WMMBXY
Description	MM-MOB - Upload of material movements
IDOC type	WMMBID02
Storage duration	10
Log. target system	Created logical system
Segment name 1	E2MBXYH

Maintenance of the HYDRA Scheduler

Use the [HYDRA Scheduler](#) to plan jobs for outbound processing:

Parameter name	Value
Transfer of goods movements to MLE outbound transactions	
Product key	SAP-MMMOB
License key	SAP-MMMOB
Command (Windows):	sh.exe ./myerprck.scr /MESTYP=WMMBXY
Command (Unix):	./myerprck.scr /MESTYP=WMMBXY
Comment:	SAP-MMMOB: Upload of goods movements → MLE outbound transactions

Parameter name	Value
Interval	5
Upload of confirmations from MLE outbound transactions to SAP MM	
Product key	SAP-MMMOB
License key	SAP-MMMOB
Command (Windows):	sh.exe .hysapupl.scr /UPLSEGNAM=E2MBXYH /SINGLE_IDOC /SUBLEVEL=2
Command (Unix):	./hysapupl.scr /UPLSEGNAM=E2MBXYH /SINGLE_IDOC /SUBLEVEL=2
Comment:	SAP-MMMOB - Upload of goods movements MLE outbound transactions → SAP MM
Interval	5



Please make sure that the upload program myerprck.exe/out has not been started for the message types ZWAU (goods issues in the HYDRA format) and ZWEI (goods receipts in the HYDRA format) using the script myerprck.scr, since it cannot be operated with SAP-MMMOB at the same time.

Maintenance of the HYDRA material type

In many cases, the HYDRA material type is relevant for the interface and needs to be activated to be able to transfer goods movements. For this reason, enable the flag “goods movements → transfer to interface” for the [HYDRA material type](#).



If the HYDRA material type is not available as application, the flag can also directly be set using the database:

```
update hz_typen set we_ext_kz = ,J' where hz_typ = '<Material type for which the flag is to be set>';
```