

Manual

Basic Services for Smart MES Applications SIS-SMA 3.0

Version 1.1.15248

Last changed on: 19.06.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Basic Services for Smart MES Applications.....	4
2	SMA Login.....	5

1 Basic Services for Smart MES Applications

Overview

Smart MES Applications (SMA) provide a selection of applications, which can be used to work with a HYDRA system via mobile devices or via WEB.

Purpose

The web-based implementation of SMA provides a wide range of uses. You can use SMA at the employee's workplace or remotely at the customer's site. You call SMA using a HTML5 capable web browser. For some devices, MPDV provides the possibility to use SMA as application (for example Android devices as of version 4.3; availability according to the MPDV compatibility list).

Implementation notes

Use SMA if the company requires mobile access to the information managed in HYDRA. You cannot replace an MOC with SMA. SMA supplements the MOC.

Integration

SMA is installed on an IIS server and communicates with the web service interface of HYDRA.

Features

Basic functions for the use of HYDRA MES applications on mobile devices or on the WEB.


Server software to connect the mobile clients to the HYDRA infrastructure. The login is based on the HYDRA authorization concept including user administration, function and cost center authorizations, responsibility areas, user profiles and password rules.

2 SMA Login

Overview

In order to access SMA, you need a login. We differentiate between a HYDRA administrator login and a user login.

Administrator login (HYDRA user login)



The screenshot shows the SMA login interface. At the top is a blue header with the SMA logo. Below it, the text 'Log on' is displayed. The main content area has three tabs: 'HYDRA user', 'Language', and 'Settings'. The 'HYDRA user' tab is selected and contains the following elements: a 'User' input field with the value '12345', a 'Password' input field, a 'Change password' link, and an 'OK' button.


The administrator login is divided into three tabs: HYDRA user, language and settings.

- HYDRA user (administrator): This tab initiates the login. You must have HYDRA administration rights and a valid password. You can change the current password for the assigned administrator using the link "Change password". You need to enter the previous password.
- Language: You can select between the languages German, English and Chinese. The selected language is valid when the HYDRA user is logged on. Initially the system uses the language set in the browser.
- Settings: Here the user can select the system to log on.

Clicking "Ok" button carries out the login of the settings.

User login (Person login)

Person Login:



The Person login is divided into three tabs: Person, language and settings.

- Person (HR user): This tab initiates the login. The user must enter the staff number in the field "Person" or the badge number in the field "Pin code" to identify the person and the relevant pincode of the person. The current password for the assigned user can be changed using the link "Change password". You need to enter the previous pincode.
- Language: You can select between the languages German, English and Chinese. The selected language is valid when the user is logged on. Initially the system uses the language set in the browser.
- Settings: Here the user can select the system to log on. The following settings are available:
 - Terminal mode: If the terminal mode is activated, the application "Time and Attendance" when requested deletes the previously stored personnel information. You should use this mode if the browser is used by several people for clocking purposes. The person in question should then exit using the application "Time and Attendance". This enables another user a quick clocking and your own data is deleted accordingly.
 - Display field "Person": If the terminal mode is activated, the setting or the field "Staff badge no" must also be activated. This setting enables to check the relevant person again (i.e. before clocking) if this terminal mode is not activated.

- Display field "Display badge": If the terminal mode is activated, the setting or the field "Person" must also be activated. This setting enables to check the relevant person again (i.e. before clocking) if this terminal mode is not activated.
- Terminal: States the PZE terminal configured for HYDRA. The configuration is required to collect times. A configuration for the terminal 254 is searched for in HYDRA by default.
- Cost center posting: If this setting is activated, then a clocking can be made for a certain cost center.
- Company for cost center posting: The entry is used as a filter to select a cost center. Please use exclusively with active cost center postings.
- "Company for absence reason list": This entry list for absence reasons is used in a configured terminal to add "reasons" specifically assigned to a company. (Absence reasons with assignment to a company + absence reasons assigned to this company).

Clicking "Ok" button carries out the login of the settings.