

1 Entering Serial and Batch Numbers

Usage

When entering individual batches, another batch can be entered at the terminal in addition to the operation and, depending on the production situation, may be defined as an input or an output batch.

Integration

Data are entered as part of the shop floor data collection (BDE) process. The type H BDE log records resulting from the data entry and illustrating the individual batch postings in chronological order can be displayed or edited in the "[order-related postings](#)" application.

Prerequisite

The following configurations are mandatory:

HYDRA basic settings

Using the "*Create unknown batches*" option in the HYDRA basic settings ("MPL" tab), a batch can be created automatically at the terminal by entering the batch number.

If automatic batch generation is not active, the batches must be created manually in HYDRA, since HYDRA will perform a validation check regarding the existence of a batch when batches are posted at the BDE terminal.

Manual batch generation can be activated through an interface or Client application after consultation with MPDV (not included in this license).

Terminal assignment

Batch entry may only be activated on machines assigned to terminals of the BDE and/or MDE operation mode.

Workplace/ Resource configuration

"Workplace configuration" tab → "MPL" category → "Batch management" category → select "Individual batch tracing".



Operations not requiring batch management can also be logged in at machines using batch management. In this case, entry of the batch number is not required. Please note that this is only possible for so-called workflow posting dialogs.

Operation data

For entry, the operation must be identified as requiring batch management.

The "Batch management requirement" flag can be preset by the ERP system (e.g. interface: HY72PPS Segment: HY72_AG_HD_001 (operation) field: OPT:CNR), or else set manually using the [editing function](#) in the MOC (presumes proper licensing/authorization).




Attempting to log on an operation requiring batch management at a workplace without active batch management will be refused by indication of a validation error.

Logging on an operation requiring batch management

<

The operation is selected in the "Select operation" tab. The status of the workplace/machine can be modified in the next tab, "Select status". This tab is only available at "single user workplaces".




The batch number and the staff badge number are entered in the "Batch entry/confirmation" tab. For this purpose, an alphanumeric batch number with a maximum of 20 digits must be entered. It can be entered either manually or by barcode.

Changing batches at the terminal

While the operation requiring batch processing is logged on, you can switch to a new batch by means of the "Change of batches" function key.

The production data (quantities produced and duration) are posted to the operation and the current batch simultaneously.



Chargenwechsel

Arbeitsgang 0032 0030 - Endmontage

Auftrag	MWETEST30032	Sollmenge	8000	ST
Artikel	0030 / 407*85 B	Gutmenge	0	ST
		Ausschuss	0	ST
		Fertigstellung	0%	

Arbeitsplatz 40312CHV 40312CHV

Aktueller Status 6 ANFAHREN

Charge

Personalkartennummer

CTAIP V2.0.2.39 Server:win2008-2:4 TNR:128 15.05.12 15:19:06

The new batch number can be entered manually via the keyboard or by barcode. As is the case when logging on an operation, the person implementing the batch change must possess BDE authorization in order to post the operation.

Please note

The batch currently logged on can be displayed in the OP info, provided it was integrated into the appropriate dialog by customizing. Please note that this field can only be displayed either system-wide or specifically for a terminal group. It is not possible to show/hide the field based on a dialog control defined at the workplace as well as in the input field.



Scrap quantities recorded via the "Partial confirmation" (A_TR) dialog are posted to the order, but not to the batch. As a consequence, such quantities are not included in the log record type "H", either.