

1 How to Switch Languages

Purpose

Use the function to switch languages online via the AIP2 terminal.

Integration

You can switch languages for the licensed and installed language packs ("localization").

Requirements

You have purchased the license for the used language pack(s) ("localization").

You have configured the online language switching (see section *How to configure* language switching).

If you also want to show translated database contents (MDBI texts, e.g. status texts), you have to activate and maintain these texts.

Terminal functions

The bottom taskbar of the AIP terminal shows the flag of the currently selected language. The flag has a green frame to indicate that the AIP start screen is opened. In this case, you can change the language. If you open another screen/dialog the frame around the flag turns red to indicate that language switching is currently not possible.

If you click the flag, a menu appears where you can choose the available languages:

The screenshot shows the AIP software interface. On the left, there is a list of workstations with their status and counts. In the center, there is a detailed view of a workstation (33021) showing its status (PRODUKTION), cycle times, and production data. On the right, there is a section for 'Arbeitsgänge' (Work Steps) and 'Angemeldete Personen' (Registered Persons). A language selection menu is open, showing three options: English (UK flag), Deutsch (German flag), and Chinesisch (Chinese flag). The menu is positioned over the 'Angemeldete Personen' section.

Arbeitsplatz / Maschine	
Arbeitsplatz / Maschine	Kurzbezeichnung
33021	HAND02
Gruppe	
FINISH	
Status	
PRODUKTION	
Takte	
0	
Sollzyklus [Sek./Takt]	
20	
Istzyklus	
0	
Gutmenge	
833	
Ausschuss	
4	

Angemeldete Personen	
Person	Person
10002630	85741
Name	Name
Weis, Sabine	Meier, Josef
Person	Person
40563	
Name	Name
Grieber, Maria	

The menu shows all configured languages. You can switch between a maximum of five languages.



If the terminal is offline, you cannot switch languages. An error message is displayed.

2 How to configure language switching

2.1 Activation

Use the file **hytnrcfg.ini** to configure language switching.

Example:

```
[multiple_language 0]
alt_lang1=2;1kEnglish
alt_lang2=1;1kGerman
alt_lang3=4;1kFrench
alt_lang4=15;1kChinese
```

Add an entry *alt_lang<x>* with consecutive number for each language to the section *[multiple_language 0]*. The language index of the required language follows after the equal sign. Then you find the name to be displayed or the corresponding language key, separated by semicolon.

The displayed flag is stored in the archive *pict.zip* and has the file name *LangFlag_<y>.png*; *y* stands for the corresponding language index.

The maximum number of languages that can be changed is restricted to 5 .

2.2 Instant updating of multilingual database contents



Available as of AIP version 8.2.2.34.

Service pack 16 provides this version.

If you use multilingual database contents and you switch languages, texts will only be displayed in other languages once the terminal has requested the data anew from the server. Until then the texts of the previously selected language are displayed. This delay might take some minutes depending on system configuration and the time of the last update.

You can configure the terminal to request all or specific lists from the server immediately after languages have been switched. Consequently, texts will be displayed instantly in the newly selected language.

You can configure this in the same section of the file **hytnrcfg.ini** where you also activate language switching.

Example:

```
[multiple_language 0]
alt_lang1=2;lkEnglish
```

...

LST-RELOAD-ON-LANGUAGE-CHANGE=<ALL>

Use the entry "LST-RELOAD-ON-LANGUAGE-CHANGE=<ALL>" to cause the AIP to request the data of all below-mentioned lists from the server after languages have been switched.



If the terminal still sends dialogs to the server (queue is not empty) when languages are switched, the data is not updated immediately but only once all dialogs have been sent to the server.

Updating of all data might take a while, subject to the amount of data and the infrastructure of your system. Users cannot operate the terminal during that time. To reduce the required time, you can restrict updating to your most important lists. Data of the other lists will be reloaded later during the regular update process.

Example:

```
[multiple_language 0]
alt_lang1=2;lkEnglish
```

...

LST-RELOAD-ON-LANGUAGE-CHANGE=MNR,MSTAT,AGRD,LOKVLIST

Use the following acronyms to reload only specific lists with texts from the server after language switching:

Acronyms	List
MNR	Machines
ANR	Orders
MSTAT	Machine status
HZTYP	Material types
AGRD	Reasons (reasons for scrap and other quantity types)
ZLO	Target locations
TPE	Transport units
AART	Order types
MAT	List of input materials logged on
RES	Resources
LOKVLIST	Sequencing lists of all assigned machines



Multilingual database contents must be enabled on the server. This document does not deal with the activation of multilingual database contents.

The installation manual of your MES Weaver system (MW) provides further information for system administrators. Contact MPDV if you need help with the activation of multilingual

database contents on the server.