

1 Available Escalations

1.1 Completed inspection reference (CPANUMP.COMPLETED)

An escalation is generated as soon as an inspection reference (e.g. inspection point) is completed. The configuration can be set so that a notification is only executed, for example, if the inspection result is "fail" (CPANUMP.STA == "NIO").

Event	Identifiers	Description
CPANUMP.ABSCHLIESSEN	CPANUMP.RECTYP	Data type
	CPANUMP.BER	Area
	CPANUMP.PANNR	Inspection requirement
	CPANUMP.EINTTYP	Type of inspection resource
	CPANUMP.EINTNR	Number of the inspection reference
	CPANUMP.STA	Status
	CPANUMP.FU:1	Quick user field 1
	CPANUMP.FU:2	Quick user field 2
	CPANUMP.FU:3	Quick user field 3
	CPANUMP.FU:4	Quick user field 4
	CPANUMP.FU:5	Quick user field 5
	CPANUMP.FU:6	Quick user field 6
	CPANUMP.FU:7	Quick user field 7
	CPANUMP.FU:8	Quick user field 8
	CPANUMP.FU:9	Quick user field 9
	CPANUMP.FU:10	Quick user field 10
	CPANUMP.FU:11	Quick user field 11
	CPANUMP.FU:12	Quick user field 12
	CPANUMP.FU:13	Quick user field 13
	CPANUMP.FU:14	Quick user field 14
	CPAN.ANR	Order
	CPAN.AGNR	Operation
	CPAN.FU:1	Quick user field 1
	CPAN.FU:2	Quick user field 2
	CPAN.FU:3	Quick user field 3
	CPAN.FU:4	Quick user field 4
	CPAN.FU:5	Quick user field 5

Event	Identifiers	Description
	CPAN.FU:6	Quick user field 6
	CPAN.FU:7	Quick user field 7
	CPAN.FU:8	Quick user field 8
	CPAN.FU:9	Quick user field 9
	CPAN.FU:10	Quick user field 10
	CPAN.FU:11	Quick user field 11
	CPAN.FU:12	Quick user field 12
	CPAN.FU:13	Quick user field 13
	CPAN.FU:14	Quick user field 14
	CPAN.ATK	Article number
	CPAN.ATKIDX	Drawing issue number
	CPAN.ATKBEZ	Article designation