

1 HYSAPQMC - Programmparameter

Usage

Use the interface program hysapqmc.exe/out, to request downloads from SAP QM via the QM-IDI-interface. The program downloads QM master date as well as inspection specifications.

Available program parameters

Parameter	Meaning/ Usage	Relevant interfaces	Productive release
Program parameter to control processing			
/MESTYP=<Value>	The MESTYP parameter is used to define the structure to be processed.	All	YES
/MESFCT=<Value>	The message function is used to differentiate within a message type	All	YES
/VARIANTE=<Value>	Variant for parameters of function module	All	YES
/LOGSYS=<Value>	Logical system for which the communication is performed (only used with stand-alone CAQ)	All	YES
/MESTYP_OUT=<Value>	Message type which is to be created	All	YES
/TL=<TRL_ALL/TRL_CONN/ TRL_TID/TRL_DATA	Defines the trace level for communication processes	All	YES
/PP_PDC_NO_COPY	When requesting inspection characteristics based on PP-PDC data, the original PP-PDC data is not copied as well	SAP-PPDC	YES
GET_INSPPOINTS_4_INSPLOTS	Request from sap only inspections points for the determined inspection lots from an inbound transaction (/TID={TID}) (available as of hysapqmc.exe/out V8.1.1.26)	SAP-QMIDI	YES