

1 ATP Inspection Group Assignment

Overview

Menu	Master data -> Production control -> ATP inspection group assignment
Transaction code	atpiga
Function authorization	atpiga

This document describes the application "ATP inspection group assignment" in the Manufacturing Operation Center (MOC).

Purpose

You use the function to assign material types or materials to the configured ATP inspection groups.

Integration

In order to visualize expected material consumption in graphical detailed planning, material types must be assigned to the ATP inspection groups stored in OPs.

Requirements

You have configured material types and ATP inspection groups in master data.

Selection criteria

The application provides the following selection criteria:

ATP inspection group

Selects the ATP inspection group

Material type

Selects the material type.

Material

Selects the material.

Field descriptions

ATP inspection group

Name of the ATP inspection group



Several material types or materials can be assigned to an ATP inspection group.

Material type

Material type to be assigned to an ATP inspection group.

Material

Material to be assigned to an ATP inspection group.



Each material type can be assigned to only one ATP inspection group.



Only material types configured in the application "Material types" are available during creation and changing of a data record.

Modified by

Last editor of the ATP inspection group assignment.

Modified on

Time of the last change of the ATP inspection group assignment.

"General" tab**Add**

Opens the dialog to add an ATP inspection group assignment.

**Copy**

Opens the dialog to copy an ATP inspection group assignment.

**Edit**

Opens the dialog to edit an ATP inspection group assignment.

**Delete**

Deletes an ATP inspection group assignment.