

1 Attributes

Summary

Menu	Master data → Material → Attributes
Transaction code	batatt
Function authorization	batatt

Usage

This function is used to create or modify batch attributes in the system.

Integration

The recording function on the terminal can be activated (when changing to a output batch) by assigning batch attributes to a [material type](#).

Requirement

The [material types](#) must already be defined.

Selection criteria

Material type

Only attributes with the selected [material type](#) are selected.

Field index

Only attributes with the selected field index are selected.

Attributes

Only the specified attributes are selected.

When using multiple selection criteria - if nothing else is specified - the amount of overlap of the selection criteria is displayed.

Field descriptions

Material type

The [material type](#) is a key field. The attribute refers to the selection material type (material type = summary of identical materials).

Field index

The field index is a key field. There are 40 text fields, 20 numerical fields and 20 decimal fields from which to select.

Display position

Specifies the order for display on the terminal.

Name

Designation of the attribute.

Unit

Unit of the attribute

Display attribute

If this identifier is set, the attribute is taken into consideration in the display in other masks.

Print attribute on batch ticket, printing position

Reserved; currently no processing.

Capture attribute while generating batch

If this identifier is set, the attribute can be captures during batch generation.

Automatic transfer (additional option)

Field value from the operation or order header can be transferred automatically. The specification is made for this from:

MES operation or **MES order header** via a field **acronym** that can be selected (e.g. ATK – item/article number, FU:10 - User field 10, etc.)

Data type

Here the data type of the field is specified, including field length and decimal places, if necessary. However, it is not useful to place a text in a decimal field or decimal input in a text field.