

1 Batch data overview

Overview

Menu	Material management → Inventory management → Batch data overview
Transaction code	batov
Function authorization	batov

Available user fields		
Where	Object type/user field key	Source (type)
Detail view	CNR/SYSTEM	Batch (MF-D)
How to configure user fields? Which user field types are available?		

Purpose

The application is only available in the structure described here if you enable the modification [batovextensionselection](#).



If you do not use the modification, please refer to this [Document](#).

Use the *batch data overview* to view or edit one or more batches depending on the entered selection criteria.

Integration

The *batch data overview* shows all existing batches matching the entered selection criteria.

The *batch data overview* shows the selected batches and their current status including further details.

Selection criteria

The application provides the following selection criteria:

"Batch" category

Batch number

The batch number represents the batch ID used by the user. The user can:

- enter/view the batch number in terminal dialogs
- use the batch number for tracing or information search via the office client



If the configuration option "automatic generation of the batch number" is enabled, leave the "batch number" field empty in the editing dialog when you add a new batch. The system will only assign the batch number automatically, if the "batch number" field is empty.

Material

Enter the material number as a selection criterion to display all batches assigned to this material number.

Workplace

Enter the workplace as a selection criterion to display all batches produced at this workplace/machine.

MES order number

MES order number (order/operation number) that produced the batch.

Internal batch number

The batch number is a **unique, system-wide** batch identification number.

Material buffers

The individual batches are located in a specific [Material buffers](#). Enter the material buffer to view all batches assigned to the selected material buffer.

Material type

The individual batches or materials belong to a [Material type](#). The same transport and handling guidelines apply to these material types across the system. Enter the material type to view all batches assigned to the selected material type.

Material category (kind of material)

The material category assigns batches to specific classes/ groups. Enter the material category to view all batches assigned to the selected material category.

Material name

The system takes over the material name from the currently logged in order when output batches are generated at shop floor terminals. As no material master is managed, the material name is stored redundantly in the batch description.

Manufacturing date from / until

Date/period of the production of a batch.

Consider long-term data

You can also select archived data.

Historic batch entries

If you use the function *historic batch entries* and you also use throughput batch numbers or serial numbers, the application will also show batches with the status "processed" for every throughput batch number or serial number. Use the function *historic batch entries* to get further process information on a throughput batch number or serial number.

Status category**Batch class**

The batch class describes the overall quality of the batch. Enter the batch class to view all batches matching the selected batch class.

Batch status

The batch status describes the technical system and production status of a batch. Enter the *batch status* as a selection criterion to view all batches assigned to this status.

Quality status

The quality status "blocked" prevents a batch from being logged on. Enter the quality status as a selection criterion to view all batches assigned to this quality status.

Manual Q status

Enter the manual Q status as a selection criterion to view all batches assigned to this status.

Material status

The material status indicates a logical status of the batch, e.g. packed, tested. Enter the *material status* as a selection criterion to view all batches assigned to this material status.

Transport status

The transport status represents the technical system status with respect to transfer postings to external storage. Select the transport status as a selection criterion to display all batches that are assigned to this transport status.

"Advance logon" option

Use this option to restrict the data to [batches logged on in advance](#).

"Attributes" category**Attribute (1 to 10)**

You can use the attributes directly stored with the batch to restrict the data displayed.

"Batch attributes" category**Batch attribute (name)**

You can use the [batch attributes](#) configured for the material type to restrict the data displayed. There are 40 text fields, 20 numeric fields and 20 decimal fields that may be configured.

"Alternative batch numbers" category**Alternative batch number (1 to 20)**

Select an alternative batch number as a selection criterion to display all batches that are assigned to this number.

"Reservation" category**Reserved for order**

Enter or select the order number in this field to display all batches that were produced for this order/ OP.

Reserved for OP

Enter or select the order/OP number in this field to display all batches that were produced for this order/ OP.

Dates category**Expiry date from / until**

Date/period that indicates the shelf life of a batch.

Availability date from / until

Date/period of the availability of a batch.

Warning time

Warning date of a batch

"Miscellaneous" category**Serial number**

Enter a *serial number* as a selection criterion to display all batches that are assigned to this serial number via the *serial number* field.

Batch number

Select the batch/lot number as a selection criterion to display all batches that are currently assigned to this number.

Person

Select *person* as a selection criterion to display all batches that have been produced by this person and, as a result, are currently assigned to this person (personnel number).

Collective batch (merged batch)

Enter a *collective batch number* (merged batch number) as a selection criterion to display all batches that are assigned to this collective batch number in the *collective batch* field (*merged batch* field).

PPS batch

Enter a *PPS batch* as a selection criterion to display all batches that are assigned to this PPS batch number in the *PPS batch* field.

Editing functions

Use the following functions that are available in addition to the standard features to edit one or several data records:



Add batch

Use this function to insert a new batch. Goods movements are not generated for the new batch.



Copy batch

Use this function to copy a batch. However, you have to enter a new batch number for the new batch. Goods movements are not generated for the new batch.



Edit batch

Use this function to edit a batch. But neither cancellations nor goods movements are generated for the changed batch.



Delete batch

Use this function to delete a batch. But neither cancellations nor goods movements are generated for the deleted batch.



Merge batches (new batch number)

Merging batches. A new batch number is generated for the new batch ([Merge batches](#)).

When merging collective batches, all individual batches are assigned to a new collective batch number.



Merge batches (use existing batch numbers)

Merging batches. A batch number already included in the merged batches is used for the new batch ([Merge batches](#)).

When merging collective batches, all individual batches are assigned to the selected collective batch number that is part of the merger.



Split batch

Create a new batch by splitting it off from an existing batch ([Batch split](#)). In this case, you can choose from the following options to deal with the remaining target quantity of the original batch:

- Repost the remaining quantity of the batch to the new batch
- Reduce the existing batch to the remaining quantity

If you split a collective batch, the selected individual batches/serial numbers are transferred to a batch split off. The remaining individual batches/serial numbers remain assigned to the original collective batch.



Repost

Use this function to repost a batch to another material buffer ([Repost batch](#)).



Generate

Use the function "enter goods receipt batch" to create batches manually ([Generate batch](#)). This is necessary if material is delivered via the incoming goods, for example.



Edit batch attribute

The tab "batch attributes" shows the [batch attributes](#) of the batch selected in the grid. The application only shows those batch attributes that have been assigned the option "show attribute on client" within the configuration of [batch attributes](#).

Provided that [batch attributes](#) are shown, click the button "edit batch attribute" to edit the batch attributes. In this case, the system does not check the field types/field lengths specified in the configuration of [batch attributes](#).

Go to



Graphic batch tracing

Calls up the application [Graphic batch tracing](#).



Document management

Calls up the [document management](#)

"Batch data overview" detail application

The *batch data overview* detail application shows all batches matching the entered selection criteria.

The documents entitled [batch object](#) and [batch structure](#) outline the information or field descriptions of the selected batches and, thus, of the detail application.