

1 Capacity Utilization

Summary

Menu	Production control → Production preparation → Graphic planning Production control → Production preparation → Info shop floor scheduling
Index tab	Planning details

Usage

You call up the capacity utilization in the graphic planning board if you would like to have an overview of how capacities are being utilized in your workplaces or workplace groups over a period of time.

Integration

Shown in the capacity utilization in the [graphic planning board](#) is a comparison of the *actual assignment* - blue - based on the planned operations and availability (*available resource*) - green - based on the shift calendar.

The information is presented in full hours. Generally, hours are rounded down.

Requirement

This requires that you selected a [planning profile](#) in the graphic planning board and that you requested data.

Settings

There are the following settings to choose from in the upper area of the capacity utilization:

View

This setting controls the view and as such how the values are grouped on the X axis. The following settings are available:

- Workplace (Pre-assigned when called up)
- Group
- Cost center

Values are grouped, i.e. how they are presented on the X axis, in alphanumeric order based on setting, workplace, group or cost center.

The information is presented in full hours. Generally, hours are rounded down.



Modifying the performance level for a workplace will not change the utilization, because the available time is calculated using the workplace's shift calendar.

Period

This setting controls the scope of time. The possible alternatives listed below relate to the start date of the planning profile:

- Today (pre-assigned when called up)
- Tomorrow
- This week
- Next week
- Next 7 days
- Next 14 days
- This month
- Next 31 days

(Quantity)

Number of workplaces/ groups/ cost centers in the visible area. Pre-assigned when called up: 5.

Processing functions

When calling up capacity utilization, the values for all of the planning profile's workplaces are displayed. Clicking on a workplace in the Gantt list of workplaces will display the values for the workplace; clicking on a group will display the values for all workplaces in the group.



For technical reasons, it is not possible to "unhighlight" a workplace or a group. If you would like to display the capacity utilization again for the total planning profile, the data must be requested again.

Please also note that if workplaces or groups are highlighted numerous times, only the workplace or group highlighted last will be taken into account.

The size of the detail application can be modified by moving the splitter between Gantt and detail application.

On the right next to the splitter is a second splitter. This provides the ability to display a tabular workplace list that shows the data workplace, short designation, group and cost center. By highlighting one or several workplaces in this list, you will have the ability to illustrate the capacity utilization broken down even further using additional criteria (e.g. by cost center or several groups).

