

1 Generating and canceling a merged operation

Overview

Menu	Production control → Production overview → Operations Production control → Production support → Pool of orders Production control → Production support → Order sequencing	
Function authorization	op.colopcreate op.coloprelease	Generate merged operation Cancel merged operation

Purpose

You use the function *Generate merged operation* to combine separate operations and to build one substitute OP. On the terminal, you then log on the substitute operation.

Integration

If you have created a merged operation on the MOC, you can schedule this merged operation using the MOC planning functions. This is not possible with merged operations created on the terminal.

For information on the processing and booking of merged operations, see [here](#).

Requirements

To generate merged operations on the MOC, you must have activated the relevant configuration in the *HYDRA basic settings*. Subject to this configuration, the functions for merged operations are available either on the terminal or on the MOC only.

Generate merged operation

To generate a merged operation, select all the operations that should be part of the merged operation. To select several operations (or to de-select them), hold the CTRL key down and click on the separate operations.



Click the button  to call the function *Generate merged operation*. The dialog *Generate merged operation* opens. The following input fields are available:

MOP order number

Enter the order number for the merged operation. If you leave this field empty, HYDRA automatically assigns the number.

Operation

By default, the operation number 0000 is preassigned here.

Target quantity (P)

For all selected operations, the system calculates for each operation:

Calculated quantity = target quantity (P) minus yield quantity (P).

The calculated quantities are totaled if the result is > 0.

The system uses the sum total to populate the field *Target quantity (P)*.

Note: the units are not converted; all operations must have the same primary quantity unit.

Target scrap (P)

For all selected operations, the system calculates for each operation:

Calculated quantity = target scrap (P) minus (actual) scrap (P).

The calculated quantities are totaled if the result is > 0.

The system uses the sum total to populate the field *Target scrap (P)*.

Note: the units are not converted; all operations must have the same primary quantity unit.

Setup time

By default, the maximum setup time of the selected operations is used.

Processing time

By default, the total of all processing times of the separate operations is used as processing time.

Reference OP

The data of the order/operation stored in field *Reference OP* is used for the merged operation ("copy template"). The system uses the operation having the lowest order/operation number of the selected operations to populate this field.

Confirm the dialog to generate the new merged operation.



You can combine a maximum of 50 separate operations to build a merged operation.

If you change the data of the merged operation, the inventory data of the OPs used to build this merged operation is NOT changed.

When you cancel the merged operation, the data of the included operations is still the same than at the time when the merged operation was created.

Cancel merged operation

As long as a merged operation has not been started (V status), you can cancel this merged operation and

restore the separate operations included by clicking the button . Once a merged operation has been started, you cannot cancel the merge anymore.



If you change the data of the merged operation, the inventory data of the OPs used to build this merged operation is NOT changed.

When you cancel the merged operation, the data of the included operations is still the same than at the time when the merged operation was created.

Display merged operations

With evaluations/overviews, you can control via selection if the evaluation/overview integrates merged operations or the operations included in merged operations.

Indiv. OPs

Only "normal" operations are shown, no merged operations or operations included in merged operations.

Merged operations

Only merged operations (MOP master) are shown.

Indiv. OPs summarized in merged OPs

Only the operations included in MOPs are shown.

In the application *Operations* (transaction code op), you can show the column *MOP*. This column shows the MES order number of the merged operation to which the single operation is assigned or the MES order number of the merged operation itself.