


1 Production Control Plan

Overview

Menu	Quality management → Production control plan → Control plan
Transaction code	cpl
Function authorization	cp



Available user fields

Where	Object type/user field key	Source (type)
Inspection plan: Table and detail view	Production: CPPL/FEP Goods receipt: CPPL/WEP Goods issue: CPPL/WAP Initial sample: CPPL/EMU Test equipment (gage) management: CPPL/PMV	QM
Inspection plan characteristics: Table	Production: CPPLMM/FEP Goods receipt: CPPLMM/WEP Goods issue: CPPLMM/WAP Initial sample: CPPLMM/EMU Test equipment (gage) management:	QM

	CPPLMM/PMV	
How to configure user fields?	Which user field types are available?	

Purpose

Use this function to create control plans and to print the form based on QS9000.

Requirements

You have to maintain specific master data in order to generate production control plans. The master data you have to maintain depend on the intended use. As a general rule, you have to maintain the following master data:

- Article
- Teams (=distribution list/distributor)
- Companies
- Parties in charge
- Inspection plans

Field descriptions

"Production control plan" tab

Area, production control plan, index

The *area*, *production control plan* and *index* uniquely identify all existing production control plans. You can select the *area*. You can enter alphanumeric characters for the production control plan and the index. All three fields are mandatory fields.

You must enter unique information in these fields, i.e. no other production control plan may exist that already includes this information. Assign a structured production control plan number in order to provide specific information. This information might be useful for sorting.

Article, article designation, drawing issue number, drawing number

Enter the article number. If you know the article number, you can directly enter it. If not, you can open the article catalog to identify and enter the requested article using the given filter and sort criteria. Select an article to take over the drawing issue number, the article designation (name) and the drawing number from the master data record. The system enters this data in the corresponding fields.

Active

Shows whether or not a production control plan is active.

Valid from, valid to

If required, you can enter a validity period, instead of the "global" activation using the toolbar. Yet activation for a certain period means that the user has no clear overview of currently valid inspection plans. You should therefore prefer the "global/unrestricted" activation option using the toolbar. If activated by toolbar functions, the system carefully monitors whether an active production control plan already exists for the specified article and the same drawing issue number. If this is the case, the activation of a production control plan automatically deactivates the previously active production control plan.

Team, Team designation

Enter a distribution list/distributor. If you know the distribution list/distributor, you can directly enter it. Otherwise, you can open the distributor catalog to identify and enter the requested distributor using the given filter and sort criteria. Select a distributor to take over the distributor and the distributor name from the master data record. The system enters this data in the corresponding fields.

Companies tab**Customer, customer designation, customer address 1-3**

Enter a customer. If you know the customer, you can directly enter it. If not, you can open the customer catalog to identify and enter the requested customer using the given filter and sort criteria. Select a customer to take over the customer, customer designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.

Manufacturer, manufacturer designation, manufacturer address 1-3

Enter a manufacturer. If you know the manufacturer, you can directly enter it. Otherwise, you can open the manufacturer catalog to identify and enter the requested manufacturer using the given filter and sort criteria. Select a manufacturer to take over the manufacturer, manufacturer designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.

Supplier, supplier designation, supplier address 1-3

Enter a supplier. If you know the supplier, you can directly enter it. If not, you can open the supplier catalog to identify and enter the requested supplier using the given filter and sort criteria. Select a supplier to take over the supplier, supplier designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.


Toolbar



Activate

Function authorization: none

The production control plan is assigned the status "active".



Deactivate

Function authorization: none

The production control plan is assigned the status "released". Once you have created a new production control plan, it has the status "in process". If you enable and then disable the production control plan, the control plan receives the status "released" to indicate that this control plan had been active before.

Team members detail application

This detail application shows the distribution list entries of the distributor assigned to the production control plan (in a list).

Team members							
Production control plan Documents Team members Releases							
Drag a column here to group by that column							
Team members							
Team	Team designation	P.i.charge type	Party in charge	Name p. in charg...	Name p. in charg...	Name p. in charg...	Pl
> CPL-001	Team Alpha	ext. Pers.	0001	Miller	Harry	HG	06
CPL-001	Team Alpha	ext. Pers.	0002	Zager	Peter	PZ	06
CPL-001	Team Alpha	ext. Pers.	0005	Caesar	John	WC	06

Documents detail application

Function authorization	cp
------------------------	----

If you activate the *Documents* tab, you can assign an arbitrary number of documents to each production control plan. If you activate this tab, the toolbar provides the corresponding buttons to edit documents. The *Documents* tab shows already assigned documents in a list.

You can use all formats registered by Windows when assigning the documents. You can assign simple documents (e.g. written in Word), drawings of any format and videos. You only have to make sure to install a program that is able to display the used format. The appropriate program linked in Windows opens the documents.

The file types "File", "URL", and "Text" are available. If you select the type "file", you can enter the file name including path manually. Select the file type "URL" to access the internet or intranet. Select the file type "text" to directly enter a text.

You can assign a designation/name to each document.

Toolbar

In addition to the standard functions, the application also provides the button to show documents.




Show documents

If a document link is stored, click this button to open and show the linked document. However, a program, which can show the linked file type, must be installed on the PC. You have to configure the paths in HYDRA to open the documents.

Releases detail application

Control plans may be released.



The screenshot shows a web application window titled "Insert" with a "Main page" tab. The "Releases" section is active, displaying a form for entering release details. The form fields are as follows:

Releases	
Party in charge type	Customer
Released by	0154
Release name 1	Miles
Release name 2	Betty
Release name 3	OVERHEAD
Released on	11/06/2013
List position	
Phone	02771/7384-19
Fax	02771/7383-30
E-Mail	g.kamper@office.de
Mobile	

Field descriptions

Party in charge type, released by, release name 1-3, phone, fax, e-mail, mobile

Enter a party in charge. If you know the responsible party, you can directly enter it. You can use the selection list to choose the relevant type. If not, you can open the catalog of responsible parties to identify and enter the requested party in charge using the given filter and sort criteria. Select a party in charge to take over the party in charge, the release names 1-3, the phone number, the fax number, the e-mail address and the mobile number from the master data record. The system enters this data in the corresponding fields.

Released on

Date of the release.

List position

Category of the different releases.

Inspection plan detail application

Function authorization	cppl
------------------------	------

If you select the detail application *Inspection plans*, the application shows all inspection plans pertaining to the production control plan.

You can choose from all inspection plans for all areas to assign inspection plans.

The entry in the *Position* field specifies where in the production control plan the inspection plan is indicated.

Field descriptions

Inspection plan tab

Inspection plan, inspection plan index

Enter the inspection plan. You have to use the search function (magnifying glasses) to enter the inspection plan, as in this case the system also takes over the area. Select an inspection plan to take over the inspection plan, inspection plan index, article number, article designation (name), drawing issue number and the drawing number from the inspection plan data record. The system enters this data in the corresponding fields.

Article, article designation, drawing issue number, drawing number

Enter the article number. If you know the article number, you can directly enter it. If not, you can open the article catalog to identify and enter the requested article using the given filter and sort criteria. Select an article to take over the drawing issue number, the article designation (name) and the drawing number from the master data record. The system enters this data in the corresponding fields.

Position

The entry in the *Position* field specifies where in the production control plan the inspection plan is indicated.

Operation, operation designation

Enter the operation and operation name.

Machine, machine designation

Enter the machine number and display the machine name.

Companies tab**Customer, customer designation, customer address 1-3**

Enter a customer. If you know the customer, you can directly enter it. If not, you can open the customer catalog to identify and enter the requested customer using the given filter and sort criteria. Select a customer to take over the customer, customer designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.

Manufacturer, manufacturer designation, manufacturer address 1-3

Enter a manufacturer. If you know the manufacturer, you can directly enter it. Otherwise, you can open the manufacturer catalog to identify and enter the requested manufacturer using the given filter and sort criteria. Select a manufacturer to take over the manufacturer, manufacturer designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.

Supplier, supplier designation, supplier address 1-3


Enter a supplier. If you know the supplier, you can directly enter it. If not, you can open the supplier catalog to identify and enter the requested supplier using the given filter and sort criteria. Select a supplier to take over the supplier, supplier designation (name) and the address fields 1-3 from the master data record. The system enters this data in the corresponding fields.

Toolbar



Open inspection plan

The application "inspection planning" opens and the selected inspection plan is displayed.



Restore active references

Function authorization: cppl.reference

Click this button to restore the references to active inspection plans. The production control plan now indicates if another version of the inspection plan/inspection plans has been enabled in the meantime.

However, this requires that exactly one version of the inspection plan is active at a time.

Inspection plan characteristics detail application

Characteristics												
Drag a column here to group by that column												
Inspection plan										Characteristic		
Area ID	Area	Inspection...	Insp. plan i...	Operation	Operation designation	Article	Drawing issue nu...	Article designation	Drawing number	OP	Charact...	Characteristic design...
>	Production	77 9938 882 01	30	Assembly	77 9938 882 C	Metal Pen, 4-colour, 10000m capacity	23213 90939	10 0001	Total length	variable		
F	Production	77 9938 882 01	30	Assembly	77 9938 882 C	Metal Pen, 4-colour, 10000m capacity	23213 90939	20 0004	Outer diameter	variable		
F	Production	77 9938 882 01	30	Assembly	77 9938 882 C	Metal Pen, 4-colour, 10000m capacity	23213 90939	30 0002	Evenness	variable		
F	Production	77 9938 882 01	30	Assembly	77 9938 882 C	Metal Pen, 4-colour, 10000m capacity	23213 90939	40 0003	Length pushbutton	variable		
F	Production	77 9938 882 01	30	Assembly	77 9938 882 C	Metal Pen, 4-colour, 10000m capacity	23213 90939	50 1000	Rurr	attributive		

This application shows the inspection plan characteristics of the selected inspection plan in table form.

Field descriptions

The document dealing with the application "inspection planning" describes the fields pertaining to the inspection plan characteristics.

Print detail application

Function authorization	cp.print
------------------------	----------

Use the print dialog of the production control plan to open a list of available reports. These are Word forms. The web services that are available in the respective context specify the potential content of these forms. In the master data of quality management, you can define the form entries, i.e. the contents of the

form list of the print dialog. Here, you can also specify the basics for new forms and the form properties. You require a license in order to change the forms with respect to content and design.

Print toolbar

There are no other special function buttons in addition to the standard functions/features.