

1 Expiry Preview

Summary

Menu	Material management → Inventory management → Expiry overview
Transaction code	eprev
Function authorization	eprev

Usage

The expiry preview deals with this question: "When does how much material expire?" It shows a prognosis of the expired material based on the current stock.

Requirement

All batches that currently have status "F" (Free) or "M" are considered (batch must first be stored for a minimum period before it is available = free). Depending on the selection, consumption is compressed into a specified time frame (daily or hourly).

Selection criteria

The following selection criteria are available in the application:

Material/ material type/ material buffer

Selection of the object to be selected

Material

All materials with the selected material number are selected.

Material type

All data records with the [material type](#) are selected.

Material buffer

All data records in the corresponding [material buffer](#) are selected.

Grid spacing day/ hour

The expiry preview outputs the selection of the grid spacing in days or hours.

Field descriptions

Index

Consecutive number

Date

Date on which the material expires

Quantity

Available batch quantity

Expired quantity

Quantity that expires on the corresponding date

Expired quantity (accumulated)

Total quantity that has expired by this date

Material buffer

Material buffer that includes the expiring material.