

1 Failure

Summary

Menu	Master data	Quality management	Failure
	Master data	Quality management	Failure location
	Master data	Quality management	Failure cause
	Master data → Quality management → Originator		
Transaction code	ftyp for failure type floc for failure location fcau for failure cause ori for originator		
Function authorization	ftyp		

There is a standardized catalog for failure types, cause and originator. The system differentiates entries using the failure types. There is an entry for each failure type in the menu. When requesting the application via the menu, the system opens the application and filters it to the individual failure type. The application can also be opened using a pre filter via the relevant transaction code.

Generally, the system uses the catalogs to clearly outline the failure.

Purpose

The "failure analysis number" field is the key field, i.e. when saving a new failure type, the system checks if a failure type with this key information exists.

The input of failure types is quite simple and only requires the assignment of a failure analysis number and name.

The system defines a failure type group beforehand and assigns the failure to the relevant group. This option should not be missed out as it provides improved reports/evaluations. The system assigns groups by opening the group tree using the magnifying button. The requested group may be selected and taken over in the group tree by way of the hierarchical tree entries. In the field "Groups" of the maintenance dialog of the failure cause the assigned group with hierarchical group structure appears.

The displayed list presents the group hierarchy with the columns "group 1 to group 5".

The system executes the maintenance of groups in the relevant failure group maintenance as is outlined in the manual „[MOC_Groups.pdf](#)“.

Under certain circumstances, we recommend the use of a self-explanatory structure of the failure number as a failure key.

By differentiating between active and inactive failure types, the system defines if the failure type is still available in failure selection lists in the later data acquisition process. Evaluations using inactive failure are still available. The system can also activate inactive failures.

Integration

Defect catalogs are used sometimes in measurement recording and complaint management. The evaluation of measured values can identify and later on evaluate the individual failure during quality deviations. Only in doing so, it is possible to identify the main failures, take appropriate action (measures) and prevent the defects from recurring.

In addition, this is the basis for failure mode analysis.

The system can also integrate failures in the analysis selection catalogs. An analysis selection catalog includes a subset of all failures and restricts the list of failures to be selected during the collection process to those of the analysis selection catalog assigned to the characteristic.

Requirements

Functional requirements from other applications must not be met in order to use this function.

Selection criteria

Selection criteria are self-explanatory and not described separately. The tab "Group" using the symbol  and the selection of a group (in the tree structure) can filter the failure groups. The group tree list provides a function to cancel and accept the entries made.

The "inactive" filter field allows the data set to be restricted to active or inactive failures.

Field descriptions

The available fields are self-explanatory and not explained separately.

The "inactive" check box identifies failures that are no longer used in the active data acquisition process.

In a tree structure, the group field shows the assigned group or allows groups to be assigned in form of the tree structure.

Toolbar

There are no other special function buttons in addition to the standard functions/features.