

1 Failure Causes

Summary

Menu	Master data → Quality management → Failure causes
Transaction code	fcau
Function authorization	fcau

The catalog of failure causes has been designed to describe the occurred defects/failures in more detail, e.g. if limit values have been infringed.

Utilization

The "failure analysis number" field is the key field, i.e. when saving a new failure cause, the system checks whether there is already a failure cause with this key information.

The input of failure causes is easy to handle. A failure analysis number and a corresponding designation only have to be assigned.

Failure cause groups may optionally be defined beforehand. Consequently, the corresponding group can be assigned to the respective failure cause. This option should not be missed out as it provides improved reports/evaluations. Groups can be assigned by opening the group tree using the magnifier function. The requested group may be selected and taken over in the group tree by way of the hierarchical tree entries. The assigned group including the hierarchical group structure then appears in the "groups" field of the editing dialog.

If failure causes are presented in list form the group hierarchy is represented by the columns "group 1" to "group 5".

Groups are edited in the "failure causes groups" application, which is described in the manual entitled "[MOC_Groups.pdf](#)".

Under certain circumstances it might be reasonable and recommendable to use a self-explanatory structure for the failure cause number as failure key.

By differentiating between active and inactive failure causes, it can be defined whether or not they are still to be available in failure selection lists in the later data acquisition process. However, it is also possible to evaluate inactive failure causes at any time. Moreover, inactive failure causes can be reactivated at any time.

Integration

The failure cause catalog is used, among other things, within measurement recording and in complaint management. If deviations with respect to tolerance limits are detected in measurement recording the failure cause catalog helps describe the actual failure cause in more detail and represents it in a way that allows for analyses/reports to be made. Only in this way is it possible to determine failure mode analyses, take appropriate action (measures) and prevent the deviation from reoccurring.

In addition this catalog is the basis for failure mode analyses relating to the failure cause.

The failure causes of this catalog can also be integrated in analysis selection catalogs. An analysis selection catalog includes a subset of all failures and restricts the list of failure (causes) that can be selected during the collection process to those of the analysis selection catalog assigned to the characteristic.

Prerequisite

Functional requirements from other applications do not have to be met to be able to use this function.

Selection criteria

Selection criteria are self-explanatory and are not described separately. Failure causes of a group can be filtered in the "groups" tab using the  icon and selecting a failure cause group (in tree structure). The group tree list provides a function to cancel and accept the entries made.

The "inactive" filter field allows for the data set to be restricted to active or inactive failure causes.

Field descriptions

The available fields are self-explanatory and are not explained separately.

The "inactive" check box identifies failure causes that are no longer to be used in the active data acquisition process.

In a tree structure the group field shows the assigned group or allows for groups to be assigned in form of a tree structure.

Toolbar

There are no other special function buttons in addition to the standard functions.