

1 Summary

1.1 General notes on the document

This document describes the “Groups”, e.g. article groups, application of the Manufacturing Operation Center (MOC). For general information on how to use MOC, please refer to the [“moc_cc.pdf”](#) document.

2 Groups


The group catalogs have been designed to create and edit groups for the different applications. The created groups may be assigned to master data of the corresponding application. Consequently, article groups may be created, for example, and assigned to the articles. In this case, it is also possible to create inspection plans on the basis of article groups.

Basically, the creation of groups is also reasonable for failure mode analyses.

2.1 Starting the function

Menu	Master data → Quality management → Article groups Master data → Process data processing → Article groups Master data → Quality management → Measure groups Master data → Quality management → Failure type groups Master data → Quality management → Failure location groups Master data → Quality management → Failure cause groups Master data → Quality management → Causer groups Master data → Quality management → Cost type groups
Transaction code	atcgr → Article groups measgr → Measure groups ftypgr → Failure type groups flocgr → Failure location groups fcaus → Failure cause groups origr → Causer groups costgr → Cost type groups
Function authorization	atcgr -> Article groups measgr.* → Measure groups ftypgr.* → Failure type groups flocgr.* → Failure location groups fcaugr.* → Failure cause groups origr.* → Causer groups costgr.* → Cost type groups

2.2 Default Application Layout



This figure of the article group catalog is exemplary for all groups.

2.3 Toolbar

The toolbar contains the function calls that are available for this application and possibly links to other applications. The functions placed on the “general” tab of the toolbar refer to all detail applications. In addition to the standard functions such as “help”, “request data”, “save application settings” and “print preview”, the other tabs include specific functions that are tailored to the corresponding detail application. The individual functions of the application are listed in the paragraphs that follow.

"Data" category



Request data

The information to be displayed within the application is requested according to the entered selection criteria. This process might take some time depending on the data set from which the system filters data and on the selection result to be transferred and displayed.

**Cancel**

This function cancels the query sent by clicking the "request data" button.

**Print****preview**

The print preview is opened for the selected detail application. The print preview also includes further options to change the resulting printout and functions for exporting the displayed information into other formats, such as PDF, Excel, image files.

**Save**

The application design configured by the user, e.g. columns and categories displayed as well as their respective size and display locations, etc. are only saved if the user requests it. In this case, the user has to affirm the confirmation prompt by clicking "Yes".

"Functions" category

There are no special functions for this detail application. Groups are created, changed and deleted using the context menu of the right mouse button within the tree structure view.

"Help" category

**Help on operation**

Clicking this button opens the help file describing how to operate MOC. The basic document is entitled "moc-cc.pdf". It describes how to use MOC in general and applies for all applications.

**Help on application**

This function opens the manual that describes the application from which the help function was requested. The application manual integrates the application function into the MES context and explains the information to be displayed. The documentation also includes all detailed applications.

**Help on detail application**


This function opens the application manual at the section where the respective detailed application is described.

2.4 Selection parameters

There are no selection parameters. A specific group can be found by using the "fast selection" function. To use the "fast selection" function just open the group tree structure on the 1st level, select the first entry and enter the first letter of the group in question. Consequently, the first group starting with this letter that is found is selected. The "fast selection" function also integrates subordinate groups that are not opened. If the requested term is included in a group that is not opened, it will be opened automatically.

2.5 "Groups" Detail Application

A group may be created, changed or deleted by opening the context menu of the right mouse button within the display area of the tree structure.



It is altogether possible to define groups up to the fifth hierarchy level. The "add root group" function has to be selected in the context menu of the group tree to create a new main group (1st level). The menu entry "add group" generates a sub-group (level 2 to 5). A designation, which is directly entered in the list view, has to be assigned for this new group. To be able to save the new group, click above or below this new entry within the group tree. Then a confirmation prompt appears asking whether or not the new group is to be saved. Provided that this question is affirmed ("yes"), the entry is saved. The same applies for renaming of groups. Regardless of which hierarchy level is concerned, the entry has to be selected to be able to edit the group designation. Changes can directly be entered in the corresponding line of the tree view. Click above or below the entry to be changed to be able to save the modification. No confirmation prompt appears when it comes to renaming.

An entry is also deleted by selecting a group entry and executing the "delete group" function. Only the group that is at the bottom of the group tree can be deleted.

The "expand all" context menu entry opens all groups up to the lowest hierarchy level. The "collapse all" context menu option closes all entries up to the first level.

The "delete selection" function cannot be used in the maintenance of groups dialog. This function is enabled, for example, in the maintenance of articles application if an article group is selected and this selection is to be removed/deleted.