

1 Order Status Assignment

Overview

HYDRA menu	Master data → Order → Order status assignment
FEDRA menu	Detailed Scheduling → Master data → Order status assignment
Transaction code	ost
Function authorization	mdost

Purpose

You can use the *Order status assignment* to configure the order statuses for the different order types. The order status provides the current status of the order.

Integration

Because order data are recorded in the system based on the operation, the system manages one status for each individual operation. The status indicates whether the operation has not yet begun, for example, or whether it has begun, was interrupted or has already been finished.

In addition, a status is also kept in the order header, which provides information on whether the order has not yet begun, whether it is currently being processed or whether it is already finished. At the time the last operation that can be posted is finished, the status is set to finished in the order header. Operations that cannot be posted will not be automatically finished when this occurs.

Both order and operation statuses can be configured. To do so, the status texts must be defined first. Then, the status texts are assigned to the individual statuses. What must be kept in mind is that for each order type, the order status or the operation status must be configured with one control indicator each (exception: statuses with a control indicator "S" may exist multiple times).

All possible order and operation statuses are configured in status assignment and are assigned to status texts using unique status numbers. The selection dialog allows you to select and display statuses that have already been assigned to an order type.

Requirement



The order status texts and order types must be created first.

Selection criteria

Status type

Selection of the assigned status type

Status text

Defined status text

Order type

Order type that was assigned to the status

Field descriptions

This dialog is used to define the statuses used in both the order (header) as well as in the separate operations. There is also another option that allows you to define an operation in relation to the secondary status. To differentiate which identifier is relevant for which status type, the corresponding status type is written in parenthesis after the field:

- A = Order status
- G = Operation status
- S = Secondary status

Order type [A G S]

The status is configured based on the order type. This means that for each order type the relevant order and operation statuses must be defined. Enter a valid order type in this field, for which the status should apply.

Status type (A/G/S)

A	Status refers to the (entire) order
G	Status refers to the operation
S	This is the preparation status (=secondary status) at the operation.

Status (A/G/S)

This is the externally valid status.

Status tab

Status text no. (A, G, S)

Reference to the order status text table

Symbol (G)

Symbol assigned to the status. It is displayed in different functions/ evaluations (e.g. order overview).

The following values are allowed (case sensitive):

Color of the LED	Value that needs to be entered in the editing dialog.	Value shown in the detail panel.
Light green	l.bmp	LED_LIGHT_GREEN
Dark green	e.bmp	LED_GREEN
Gray	v.bmp	LED_GREY
Yellow	u.bmp	LED_YELLOW
Yellow/ light green	f.bmp	LED_YELLOW_GREEN
Pink	n.bmp	LED_PINK
Black	a.bmp	LED_BLACK
Blue	p.bmp	LED_BLUE
Red	x.bmp	LED_RED

Color (G)

Color of the relevant status (text). At this time, this color is only used in the shop floor scheduling.

Entry tab

Control

Status type A (order status)

V	Prepared Release (for automatic release)
L	Running At least one OP was started
E	Finished All OPs are finished or deleted.
S	None All others

Status type G (OP status)

V	Prepared
---	----------

"Release indicator" for status; before OP is edited for the first time

L	Running Is set automatically once OP is logged on
U	Interrupted Is set automatically once OP is interrupted
F	Autom. interrupted Is set by the server if you want the OP to be interrupted automatically at the time of a shift change (when using HYDRA and the MDE function on the terminal)
E	Finished Is set automatically once OP is finished
S	None Other status; not automatically set. Means that no work has yet been done on the OP

Please note

An OP has not yet begun if its status is set with a control indicator: "V" or "S".

Explicitly setting an order to the status using the control indicator "E" will result in all OPs being set to the status with the control indicator "E".

The control indicator "A" means "archived"; it is not set via configuration, but is instead a fixed setting made at the time the data are transferred into the long-term table.

Can be logged on

Check to assure if the CURRENT status has set this indicator. If the operation is interrupted/finished, the field is ignored. .

Please note: If an OP or an order have been set with the flag "locked", then the OP may not be logged on under any circumstances (irrespective of this setting)

Sequencing list

If this status is set, the operation is shown in the sequencing list at the terminal.

Please note: if an OP or an order has been set with the flag "locked", then the OP may not be displayed under any circumstances (irrespective of this setting).

Successor can be logged on

If the indicator "Check of preceding OP" ("Plausibilities" index tab) is set to "S" = status at the order type, then this indicator is used to check whether the subsequent OP can be logged on.

The indicator relates to the preceding OP!

If, for example, an OP logon of the subsequent OP is not to be allowed until the preceding OP has at least begun, then this indicator must be set if the status is "running", "interrupted", "finished" (possibly "deleted").

If, for example, an OP logon of the subsequent OP is not to be allowed until the preceding OP has finished, then this indicator needs only to be set if the status is "finished" (possibly "deleted").

All preceding OPs resulting from relationships in ADE_AUFTRAGSNETZ, are checked in this regard.

Successor can be logged off

If the indicator "Can be finished" ("Entry" index tab) is set to "S" = status at the order type, then this indicator is used to check whether the subsequent OP can be logged off.

The indicator relates to the preceding OP!

Example 1: If an OP logoff of the subsequent OP is not to be allowed until the preceding OP has also *at least begun*, then this indicator must be set to "J" (y – yes) if the status is "running", "interrupted" or "finished".

Example 2: If an OP logoff of the subsequent OP is not to be allowed until the preceding OP has *finished*, then this indicator needs only to be set if the status is "finished" .

All preceding OPs resulting from relationships in ADE_AUFTRAGSNETZ, are checked in this regard.

Release of subsequent OP



The release is only processed if the operation status has changed after an operation posting (logon, interruption, logoff).

If this indicator is set, then setting the status will result in the status of the subsequent OP(s) being set to the release status, i.e. set to the status assigned with the control indicator "V".

This only happens if the subsequent OP(s) has (have) not yet been run, was (were) interrupted or has (have) been finished.

Thus, this option only makes sense if new operations are not created/ transferred using the status with the control indicator "V".

Planning tab

Planning

N	No planning (no transfer to the planning component)
T	Scheduling only
F	Scheduling and detailed planning (dispatching) - also includes the simulation

**Please note:**

The indicator "N" at the order overrides the indicator at the operations. Conversely, the indicators at the operations override the indicator "J" (y – yes) at the order

Posting tab**Posting order duration****Posting**

M Posting to the RPA of the workplace status
A posting to the RPA of the operation is made using the RPA of the status currently active at the workplace (default).

Posting RPA

Reserved; currently not used

Options tab**Initial status**

This relates to the initial status that should be set at the time an order (A) or an OP (G, S) is set.

Exactly one status must be set using this indicator for both the order as well as the operation.

Please note: If the initial status is not the status with the control indicator "V", then the status of the first operation as well as that of the order is set using the control indicator "V" after the first scheduling, provided that the indicator "Scheduling without implicit order release" is *not* set at the order type.

Status can be set manually

Reserved; currently not used.

Authorization

Reserved; currently not used

Change of secondary status

Change of secondary status allowed (J (y – yes)/N)

Priority check

Checking the priority in the priority management (order group)

If the priority control is activated in the configuration of the [Order types](#), then the system performs a check using the priority management ([Order group](#)) when an order is created or changed.

The check includes all orders with the status where this option is enabled.

Note: The priority is only checked if actually the priority was changed.

Alterable order data

If this status is set, the order or the OP may either be altered by the PPS system or manually or it may no longer be altered.

J = console and MLE interface (PPS=J) alterable

N = console and MLE interface not alterable

K = Only console alterable (not via the MLE interface)

M = Only MLE interface alterable (not via the console)

This option does not refer to the priority, notes, long texts, secondary statuses.

Deletable

May the order or the operation be deleted in this status (manually, via PPS system)?

Order

Yes, BUT only if the operations can be deleted, i.e. at no operation may a status be set that has a control indicator "L" AND for which the "deletable" indicator is set to "N".

Operation

If the OP is running, then the deletion flag is set.

Please note: Operations with a current status with a control indicator "L" or "F" may as a rule not be deleted, irrespective of this setting.

Action

Behavior indicating how the order or the operation should respond during the deletion process, i.e. at the time of deletion (now) or when a deletion flag is triggered:

Order

- | | |
|---|--|
| L | If something is physically deleted and all operations are physically deleted as well (order header controls the behavior) |
| E | Order is set to the status with the control indicator "E".
WARNING: Only the order header, i.e. for the OPs the indicator must also be set! |
| D | Order is set to status with control indicator "D" and is deleted/ archived using the archiving/ deletion program (data management) after the set period. How the operations are treated is described via the indicator RESET ACTION (LOESCHAKTION) at the status of each OP. |
| X | If the action was triggered by the MLE interface:
Order is set to the status with the control indicator "E".
WARNING: Only the order header, i.e. for the OPs the indicator must also be |

set!

If the action was NOT triggered by the MLE interface:

If something is physically deleted and all operations are physically deleted as well (order header controls the behavior)

Operation

- L Is physically deleted.
- D Is set to the status with the control indicator "D".
- E OP is set to the status with the control indicator "E" (fixed).
- X If the action was triggered by the MLE interface:
OP is set to the status with the control indicator "E" (fixed).
If the action was NOT triggered by the MLE interface:
OP is physically deleted.



The reset/deletion action should be the same for both the order header as well as for the OPs, because currently the settings each relate to the order or to OPs and the OPs do not "inherit" anything from their order header.

To assure that an order or an operation can no longer be deleted as of a certain status, the indicator must be set at all corresponding statuses.