

1 Security Gate Control

Summary

A security gate consists of two or several entries. Only one entry may be opened at a time. Access is denied in case an entry is already open when trying to open another entrance.

A security gate can be configured within the field “security gate with access point” in the “advanced settings” tab of the [access](#).

To enhance the security gate by another entrance, the new entrance number is to be entered in one of the two entrances.

The access by way of which the security gate has been configured cannot be changed. However, accesses that have not yet been assigned to a security gate may be added to an existing one or entrances may be removed from a security gate.



All entries of a security gate have to be connected to the same HYDRA-ZKS terminal.



The access status has to be monitored for all entrances in order to be able to monitor a security gate. The “maximum duration of open access” and “relay time door opener” have to be set for this purpose.