

1 Machine history

Overview

Menu	Production facility/Resource management → Resource analysis → Machine history
Transaction code	wphi
Function authorization	wphi

Purpose

The machine history is a report for the production management. The application allows for tracking and tracing of events that need to be posted at workplaces in MES. In this context, posting events such as status changes, order, tool, and personnel postings, maintenance activities as well as measures recorded at a workplace are listed in chronological order in a table. You can use various selection criteria to evaluate events.

Selection criteria

The application provides the following selection criteria:

Workplace from ... to ...

This selection criterion refers to the workplace stored in the machine or workplace master data. You can also use wildcards (placeholders *).

Group from ... to ...

This selection criterion refers to the group stored in the machine or workplace master data. The application shows all workplaces/machines assigned to the selected group. You can also use wildcards.

Short name

This selection criterion refers to the short name of machines in the master data. The application shows all machines or workplaces matching the entered character string. You can also use wildcards.

Designation

This field refers to the name of machines and workplaces defined in the machine master data. The application only shows the machines matching the specified character string. You can also use wildcards (placeholders *).

Cost center

This selection criterion refers to the cost center stored in the machine and/or workplace master data. The application shows all machines and/or workplaces assigned to the selected cost center. You can also use wildcards.

Company

This selection criterion refers to the company defined in the machine or workplace master data. The application shows all workplaces/machines assigned to the selected company. You can also use wildcards.

Report group

This selection criterion refers to the report groups. The application shows all workplaces/machines assigned to the selected evaluation/report group.

Responsibility area

This selection criterion refers to the responsibility area in the workplace/machine master. Note: The user can only view those machines included in the responsibility areas assigned to the user.

Type

Selects the category of the machine/workplace displayed in the evaluation/report. You can select E (individual workplaces) and G (group workplaces).

Type

Selects the workplace type. You can select the following workplace types:

- P Workplace
- N Machine
- J Machining center
- L Line
- A Aggregate
- C CAQ inspection station
- R Reel-based manufacturing
- S Cutting unit

Show comments

If you select the checkbox *Show comments*, the table also shows entered comments.

Comment

If the input field *Comment* includes a text, the table only shows the data records that include this text as a comment. You can use * as a wild card. Please note case sensitivity.



You cannot use this selection field to search BDE comments.

Machine statuses > X minutes only

This parameter only refers to events of the type "machine status". The application will show the machine status if the posted time is greater than the entered value.

Event type

You can restrict the displayed events. The application shows all events, in case you have not restricted the selection.

Designation	Acronym
Machine status	M_MST
Production lock	M_PSPERRE
Operation postings	A_ADE
Personnel postings	P_ADE
Target value changes	M_VORGABE
Maßnahme	R_MASSNAHME
Resource posting	R_MELDUNG
Release of resource	R_FREIGABE
Resource status	R_STATUS
Maintenance reset	R_WART_RESET
Exceeding of maintenance	R_WART_EXCEEDED
DNC Upload	R_UPLOAD
DNC Download	R_DOWNLOAD
Transfer posting of resources	R_UMBUCHUNG
Beginning of status end of status	RES_STB RES_STE
BDE comment	HY_BEM: Display of BDE comments that have been entered in reference to an operation.



You can only view BDE comments (event „Information“) if the upgrade [wphi2](#) is activated.

Please note: Posting of events depends on the customer's system and its use. Consequently, it might be the case that not all events listed here are relevant.

Date from ...to (shift/ time)

Use the date selection to restrict the period of time for the data you want to evaluate.

When selections are made using shift(s), the shift date is evaluated. If no shift is selected, all shifts are used.



Note that selection by shift is not supported for all event types. You can find detailed information on the shift selection [here](#).

If you select by time, the selection is based on the start date. Both times refer to the beginning or end of the date period specified above.



You can only evaluate *Group workplaces* if you select by *Time*. If you select by *Shift*, no data will be displayed because group workplaces do not refer to shifts.

Order / Article / MES order number

You can use these criteria to search for BDE postings:

- Log on OP, interrupt OP, log off OP, enter part quantities
- Log on staff, log off staff
- Change partitioning, change target cycle
- BDE comment



You can only select by order/article/operation if you enable the upgrade [wphi2](#).

Machine history detail application

The machine history lists all events, such as status changes, order or personnel postings of a machine that occurred on the day. These have to be evaluated or listed in a shift of this day. The evaluations/reports show the following postings:



Postings based on machines/workplaces:

Postings for machine statuses recorded automatically (with direct machine connection)

Postings assigned manually at the terminal

Setting the production lock or changing default values relating to machines/workplaces (target cycle, partitioning) at the terminal

Automatic assignment of default values with operation postings



Postings based on orders:

Postings performed automatically (when shifts change)

Manual postings (logon, logoff, interruption) at the terminal.

The corresponding order is displayed additionally. If it is a manual posting, the person who did the posting is shown as well. If waiting period processing is active, the displayed logon time of the order represents the time of entry and may deviate from the point in time indicated in the order log record. →→→

**Postings based on staff:**

Automatic (when shifts change)

Manual logon or logoff processes of staff at the terminal

In addition, the application shows the corresponding personnel number and the operation for which the person produces.

**Postings based on resources:**

Machine postings resulting from the HYDRA Tool and Resource Management module (HYDRA-WRM), e.g. the application also shows exceeded maintenance activities or measures/comments.

**Information**

Shows BDE comments entered via the AIP terminal and stored with the operation.



The event "information" is only available if you enable the upgrade [wphi2](#).

The event "information" also shows the total duration of the respective status / event. The duration is always zero when a person or OP is logged on. The duration states the interval between the logging on and logging off if you interrupt/log off an OP or person.

Field description

The following paragraphs describe the data available in the table. It might be the case that the application does not show this data by default. Use the column selection function to add the required data.

Field description *workplace* category**Workplace**

Workplace the event refers to.

Field description *event* category**Type**

Image display of the type

Event type

Assign the recorded event. Possible values: see event

Event

Classifies the event collected at the machine in the table row. In the columns "Selection by shift" and "Selection by time" you can see events available for a specific selection.

Event type	Event	Selection by shift	Selection by time
------------	-------	--------------------	-------------------

Event type	Event	Selection by shift	Selection by time
Machine status	Machine status according to configuration Coloring is set according to the settings in the status text configuration..	Yes	Yes
Production lock	Production lock set manually Production lock canceled manually	No	Yes
Operation postings	OP logged on OP interrupted OP logged off	Yes	Yes
Personnel postings	Person logged on Person logged off	Yes	Yes
Target value changes	Change partitioning/change target cycle	No	Yes
Exceeding maintenance of	Maintenance cycle exceeded	No	Yes
Maintenance reset	Maintenance reset	No	Yes
Information	BDE comment entered	Yes	Yes
Beginning of status end of status	Event and coloring according to configuration	No	Yes

Datum

Entry date of the event

Time

Entry time of the event

Duration

Time between the last event of this kind and the one currently displayed. The duration is only shown for the events "OP INTERRUPTED", "OP LOGGED OFF", "PERSON LOGGED OFF" as well as for machine statuses. In any other case, 0 is shown. These durations are synchronized with the BDE shift calendar, i.e. shift breaks are not included. Consequently, this value does not necessarily correspond to the period of time between logon and logoff.

Field description *master data category*

Workplace

Unique ID defined in the workplace configuration.

Designation

Machine name as defined in the workplace configuration.

Comment

Comment on the machine as defined in the workplace configuration.

Group

Capacity group which the machine was assigned to.

Cost center

Cost center as defined in the workplace configuration.

Company

Company as defined in the workplace configuration.

Responsibility area

Responsibility area required to view this workplace as defined in the workplace configuration.

Field description *order* category**Order type**

Order type of the order for which the event was collected.

order

Order number of the OP for which the event was recorded.

Sequence

Sequence number of the OP (provided that sequences are used).

OP

Operation number

Split

Split number of the operation (if split OPs are used)

SOP

Sub operation number (reserved).

Article

Article number produced by the operation; taken over from operation data.

Article designation/name

Article name of the article.

Field description *person* category**Person**

Personnel number of the person that has been logged on or off (only for Pers. postings)

Last name

The person's last name who was logged on or off (for personnel postings only).

First name

The person's first name who was logged on or off (for personnel postings only).

Name

Full name (last name, middle name and first name) of the person who was logged on or off (for personnel postings only).

Field description *status* category

If the event is a machine status, then this category shows the status number and status text name. This category shows the resource status for events based on resources.

Status

Status number of the assigned status

Status text

Status text of the assigned status

Receiving storage location

Destination when entering a resource status change (RES_STATUS).

Field description *maintenance* category**Maintenance type**

Type of the maintenance

T: based on cycles,

B: based on operating hours

Z: based on time

Maintenance

Maintenance short text

Target cycles

For maintenance type T only: number of cycles until the maintenance is due again.

Actual cycles

For maintenance type T only: number of cycles accrued since resetting the maintenance interval. Value results from the machine data collection (MDE).

Planned hours of operation

For maintenance type B only: number of operating hours until maintenance falls due again.

Actual hours of operation

For maintenance type B only: number of operating hours accrued since resetting the maintenance interval. Value results from the machine data collection (MDE).

Next date

For maintenance type Z only: time when the maintenance falls due the next time.

Processing mode

For maintenance events (RES_WART):

R = Reset

Z = Threshold exceeded

A = Enabled/disabled

For changed resource statuses (RES_STATUS):

S = Change over status

Threshold 1 (in %)

Threshold until reaching due date

Threshold 2 (in %)

Threshold until reaching due date

Threshold 3 (in %)

Threshold until reaching due date

Active

“Active” flag of the maintenance activity at the time of the event.

Active (so far)

Only relevant for processing mode A: previous “active” status of the maintenance activity at the time when the maintenance activity was activated/deactivated.

Modified by

Editor who edited/set/reset the maintenance.

Datum

Date of editing/resetting

Time

Time of editing/resetting

Field description *measure* category**Maßnahme**

Measure name

Designation

Name/description (long text) of the measure.

Reporting person

Person who created the measure.

Verantwortlicher

Person who has to carry out the measure.

Date of solution

Date when the measure has to be completed.

Priority

Priority of the measure.

Done

Flag indicating that the measure has been completed.

Done by

Person who marked the measure as being completed.

Field description *upload/download* category

(Not supported)

Field description *comment* category**Comment**

Comment on the event entered by the employee.

Field description *changed partitioning* category**Partitioning**

Partitioning

Cavity

Cavity number.

Type of modification

Reduced partitioning or increased partitioning.

Reason for change

Number of the reason for change.

Text of reason for change

Text of reason for change

Toolbar

Generate order (function authorization wphigenorder)

Use the "Generate order" function to create orders from work plans based on [Configuration](#).



Order information (function authorization: orin)

Request [Order information](#).