

1 Display Measured Values / Inspection Results

The measured/single values list derives from the list of characteristics.

On the left hand side this list appears with all previously collected measured values or attributive results.

The content can be restricted using a filter. A match code filter is available for the user. Content to be filtered in a text is replaced by the symbol "*". Using the symbol "?" an individual symbol can be replaced. The complete content of the document list can be filtered. The following information is part of the measured value list:

- Variable characteristics: Upper tolerance limit, actual value and lower tolerance limit. The information is separated by a pipe slash "|".
This information is displayed in the 1. line.
- Collection point in time (Date and hour)
This information is displayed in the 2. line of the document entry.

In the right display area detailed information is shown in the list for the selected entry. The parallel display of the left and right display area is dependent on the selected device. Only the measured/single values list is displayed on the smartphone. In order to show details the required entry should be selected. In the detailed display also inspection requirements, inspection step number and the corresponding area (i.e. P for production) are shown.