

1 Failure Type List containing Details

The dialog "Failure type overview" shows on the left hand side of the list all collected failure types which are assigned to the same complaint number. If a complaint contains several complaint details, all failure types of the complaint are always displayed even though specific failure types are assigned to one complaint detail. If a complaint shows for example 3 complaint details then 3 entries appear in the complaint overview list. For each of the entry the same failure type list is displayed.

The content can be restricted using a filter. A match code filter is available for the user. Content to be filtered in a text is replaced by the symbol "*". Using the symbol "?" an individual symbol can be replaced. The complete content of the list can be filtered. The following information is part of the failure type list:

- Failure type number
The information is displayed in the 1. line.
- Failure type description - comment

Article number - article description
Information is part of the 2. line and is also separated by a hyphen.

In the right display area detailed information is shown in the list for the selected failure type. The parallel display of the left and right display area is dependent on the selected display medium. The smartphone only displays the failure type list. In order to show details the required failure type should be selected.

In the detailed overview the selected failure type can be processed via a button.

The new creation of failure types is carried out in the home screen of the detailed display of a complaint.

Collection of measure for a failure location, cause of failure and originator of failure can only be done via the MOC.