

1 Setup change list

1.1 General

App name	Setup change list
App name mini	Setup list
Function authorization	sma.setli

The setup change list provides the user with an overview of the machines to be set up next. The operations listed which are planned in next. Setups, due to material, tool or color changes, are marked to improve your overview.

In addition, the setup change list has been designed as preview for (subsequent) shifts, which enables the responsible persons in the shift to know which machines have to be set up next.

Selection Criteria

The application provides the following selection criteria:

Resource

Resource used for maintenance.

Date from ... to ...

Date range when the maintenance should be carried out. The period is stored in default which is today's date plus 5 days.

Field description - List

MES order number

Combined order and operation number

OP name

Stored name of the operation

Icon for setup change

Display of required action using a symbol

Status

Current OP status

Field descriptions - detail

Order

Order header number of the operation

Status

Current OP status

OP name

Stored name of the operation

Workplace

Shows the workplace where the OP is currently planned for OPs that are not running (status U or V). For running OPs, the workplace is displayed where the OP is currently logged on. Click on workplace and the application workplace/machine opens. The system displays the information regarding the workplace.

Note: Function right sma.wpov is required to display the application "workplace/machine" and the relevant package (SMA-FMO) must be available.

Article

Article of the operation
Click on the article and the application "operation overview" opens. The system displays information regarding the operation.

Note: Function right sma.wpov is required to display the application "operation overview" and the relevant package (SMA-FMO) must be available.

Article name

Name of the article to be produced

M/O rel. setup

Machine/operator relation for setup; the value is taken from the operation.

Setup change

In order to set the value into the column "change" the operations next (planned dates) to that one are considered. If the value changes in the field "tool", then this value is entered. (Priority 1) If the value changes in the field "color", then the value "color" is entered. (Priority 2) If the value changed in the field "article", then the value "article" is entered in the column "change". (Prio 3)

Tool

The value is taken from the operation.

DNC

The value is taken from the operation.

Material

The value is taken from the operation.

Color

The value is taken from the operation.

Person OK

The value is taken from the operation.

Tool OK

The value is taken from the operation.

Material OK

The value is taken from the operation.

Target setup time

Total of the planned values "setup time" and "additional setup time" at the operation.

Target processing time

Planned processing time is stored in the operation.

RRT according to formula

Currently calculated RRT of an operation using the stored formula

Planned start

Planned setup date; corresponds to the planned start date of the operation.

Planned end

Planned end date for the operation