

1 Configuration Multiple Assignment of Resources

Overview

The planning component within HYDRA shop floor terminal is currently based on the assumption of no shift-free times with a fixed availability of 1000 at any one workplace. An operation's requirement is currently also set fix at 1000. So, when an operation is assigned, the availability of the workplace is used up entirely (availability 1000 - requirement 1000 = availability 0).

To allow for greater flexibility within the HYDRA shop floor terminal, the availability can now be changed on one side and the requirement can be changed on the other side.

Described below are the steps with which to activate multiple assignments in HYDRA shop floor terminal.

Workplace availability

At the workplace (workplace/ machine configuration, index tab HLS), availability is defined in one field.

The valid range of values for the availability field is between 1000-99999.

Configuration for defining the requirement

Configuring the order type

The requirement is defined via the operation. To assure the highest possible flexibility, a formula can be defined at the operation that is then used to calculate the requirement for an operation. The reference to a formula for this is defined to one of the operation's user fields so that the customer can transfer it via the interface. Which particular user field contains the reference to the formula is defined by specific order type (order type configuration). The formula itself is defined in HYDRA in formula management.

The formula defined in the operation's specified user field calculates its requirement. Possible values for the user field are 45-66.

Creating a formula

The formula is defined in HYDRA formula management that is meant to calculate the requirement for the operation.

Currently, the following user fields can be used in a formula to calculate the requirement: ANR.FU:23, ANR.FU:24, ANR.FU:25, ANR.FU:26, ANR.FU:27, ANR.FU:28.

Configuring user fields

Depending on the formula, the user fields used must be added to the operation.

In this example, the formula is stored in user field 45 (see configuring order types). Now user field 45 must be configured for the operation.

User fields 23 and 24 are used in the formula "REQUIREMENT", i.e. these must also be configured at the OP.

Defining the requirement at the operation

The values defined at the operation are used to determine the requirements.

If no formula is defined at the operation, a requirement of 1000 is assumed. This is the simplest of scenarios, because with it, multiple assignments can be defined based on the number of operations. For this purpose, a multiple of 1000 is defined as availability. The operation displayed above would have an requirement of 2000.