

1 Application-Relevant Settings in HYDRA

Maintenance of the HYDRA distribution model – inbound

Maintain entries for HYDRA inbound processing in the [HYDRA distribution model](#):

Parameter name	Value
To process production orders	
Message type	LOIPLO
Priority	None
Command	mle72imp.scr
Command parameter	/VARIANTE=< MLE variant to be used >
Description	PP-REM– Download of planned orders
Log. Target system	Created logical system
Retention period	10

Configuration of segment sorting

It might be required to re-sort segments if the SAP message type LOIPLO is enhanced using the user exit that is provided by default in SAP.

The SAP user exit allows to transfer additional data (= additional segments). However, this is only possible directly below the order header segment. If, for example, a component record is transferred at this position it cannot be posted, as the operations created by the standard segment are not yet available.

A configuration in the HYDRA INI configuration file allows to enhance the segment number (on which sequential processing is based) by a prefix before this number is inserted in the database and, as a result, to enable an alternative sorting.

The transfer of the planned order number is enabled as follows in the [HYDRA-INI configuration](#):

Parameter name	Value
----------------	-------

Parameter name	Value
INI name	HYALESRV
Section	<MESTYP>_SORT e.g. LOIPLO_SORT
Key	<Segment name> e.g. Z2BAPI000
Value	<prefix> e.g. Z
Active	Yes
Comment	PP-REM – setting of the segment sorting



The service “HYDRA<client number> MLE-Server SAP 1“ has to be restarted to activate the configuration.

Maintenance of the HYDRA distribution model – outbound

Edit an entry for HYDRA outbound processing in the [HYDRA distribution model](#):

Parameter name	Value
To upload time tickets	
Message type	REPMANCONFIRMATION1_CREATEMTS
Description	PP-REM – Upload
IDoc type	BFLUSHDATAMTS
Retention period	10
Log. target system	Created logicl system

Parameter name	Value
Segment name 1	BFLUSHDATAMTS

Maintenance of the HYDRA Scheduler

Edit entries for HYDRA outbound processing in the [HYDRA Scheduler](#):

Parameter name	Value
For uploads from the application to the MLE outbound transactions	
Product key	SAP-PPREM
License key	SAP-PPREM
Command (Windows):	sh.exe ./myerprck.scr /MESTYP= REPMANCONFIRMATION1_CREATEMTS /KAT=FA /RMTYP=REM
Command (Unix):	./myerprck.scr /MESTYP= REPMANCONFIRMATION1_CREATEMTS /KAT=FA /RMTYP=REM
Comment:	SAP-PPREM: upload → MLE outbound transactions
Interval	5
For uploads from MLE outbound transactions to SAP PP-REM	
Product key	SAP-PPREM
License key	SAP-PPREM
Command (Windows):	sh.exe ./hysapupl.scr /UPLSEGNAM=BFLUSHDATAMTS /SINGLE_IDOC /SUBLEVEL=2 /SUBPROT=ON
Command (Unix):	./hysapupl.scr /UPLSEGNAM=BFLUSHDATAMTS /SINGLE_IDOC /SUBLEVEL=2 /SUBPROT=ON
Comment:	SAP-PPREM: Upload MLE outbound transactions - _> SAP
Interval	5

Please proceed as follows if you use the upload to SAP PP-REM on a HYDRA system at the same time as the upload to SAP PP using PP-PDC:

Maintain the upload type "PP" (customizing) for production orders at the [HYDRA order type](#).



Add the parameter "/RMTYP=PP" for calling the upload of time tickets to SAP using PP-PDC in the [HYDRA Scheduler](#)

Keep the upload type "REM" for planned orders/serial production at the [HYDRA order type](#).

Maintain the script myerprck.scr by the parameter "/RMTYP=REM" as specified above for calling uploads to SAP serial production in the [HYDRA Scheduler](#)

Configuration of uploads

The BAPI used for uploads to SAP serial production supports several upload modes. They can be configured subject to the requirements in HYDRA:

Definition of the reference to the planned order

If the upload is to be performed in relation to the planned order this can be set by the die [HYDRA-INI configuration](#). By default, uploads are performed without indicating the planned order number.

In case the planned order is uploaded at the same time as the planned order quantity, posting errors will be the result, as the planned order might no longer exist at this point in time.

The transfer of the planned order number is enabled in the [HYDRA-INI configuration](#) as follows:

Parameter name	Value
INI name	PP-REM
Section	BFLUSHDATAGEN
Key	PLANORDER
Value	TRANSFER transfer of the planned order SUPPRESS the planned order is not transferred (by default)
Active	Yes
Comment	PP-REM: activation of the transfer of the planned order number

Define upload type

It is up to your decision whether you use a counting point upload (by default) or an end upload.

If you decide in favor of a counting point upload the operation number will be transferred with the upload.

With the counting point upload the SAP systems withdraws all material components consumed at the uploaded counting point process in a retrograde manner, posts the services accrued for the uploaded counting point operation, reduces secondary requirements of the planned orders and updates the information included in the logistic information system.

With counting point uploads scrap is uploaded as scrap for the specified counting point (BFLUSHFLAGS.RP_SCRAPTYPE = „1“).

The end upload function is used if you want to perform the upload and actual data collection at the end of the production process.

The upload type is defined as described-below in the [HYDRA-INI configuration](#):

Parameter name	Value
INI name	PP-REM
Section	BCKFLTYPE
Key	BCKFLTYPE
Value	01 upload as end upload without reference to the operation 02 upload as counting point upload with reference to the operation
Active	Yes
Comment	PP-REM: definition of the upload type