

1 Merge Batches at AIP

Usage

You use the function to merge several batches to one batch at AIP. Subject to the batch type, batches may be merged in the following ways:

- Merging simple batches and/or their quantities to one batch
- Merging individual batches pertaining to an already existing merged batch to one new merged batch

Dialog configuration

Dialog configuration (CNR.SUMMARIZE)

Define the AIP function keys in the file *ctaipbut.ini*:

```
[ANR-LN-Page3]
...
2=BATCH_MERGE,L,Lose zusammenfassen,Lose_zusammenfassen.png
```

The sections [BATCH_MERGE] and [DOC_BATCH_MERGE.LST] and [ATTR_BATCH_MERGE.LST] are required in the layout configuration of *ctaiplay.ini*:

```
[BATCH_MERGE]

GRID_FONT=Arial

GRID_FONTSIZE=9

GRID_COLOR=clBlack

GRID_BACKGROUND=clWhite


EXAMINE_SCANEXPR1=SLOS=J

EXAMINE_SCANCOLOR1=clBlue


DLL=C20,150,Z,batch

ATK=C20,150,L,article

SGR:REST=N12.0,100,R,quantity
```

EINH=C3,60,Z,unit

[DOC_BATCH_MERGE.LST]

GRID_FONT=Arial

GRID_FONTSIZE=9

GRID_COLOR=clBlack

GRID_BACKGROUND=clWhite

LINK=C20,400,L,link/document

[ATTR_BATCH_MERGE.LST]

GRID_FONT=Arial

GRID_FONTSIZE=9

GRID_COLOR=clBlack

GRID_BACKGROUND=clWhite

;GRID_ORDER=DAT=- | ZEI=- | SNR

ATTR=C20,100,L,attribute

VALUE=C20,80,L,value

EINH=C20,60,L,unit

TEXT=C20,200,L,text

System configuration

Further system configurations are not required to group batches.