

1 Interrupting/Finishing OP without the Last Batch

Usage

You use the function to prevent the last output batch generated between the output batch change and interrupting/finishing the OP from being connected in the system and, therefore, to be deleted.

Configuration

Material type

These configurations have to be made for the article's [material type](#) (article/item from operation):

- Interrupting/logging the OP off without the last batch: if the option is set, a last output batch will indeed be generated for the article of the operation (matching this material type) between the last output batch change and/or OP logon and OP interruption and/or OP logoff, but this one will be deleted immediately (batch status = "D"). The batch is not visible in the batch history.
- Delete batch assignment: If this flag is set, the connection to the running input batches of the OP will be deleted for the output batch "deleted at last". Consequently, the deleted batch is neither visible within batch tracing.

Dialog configuration A AB MPL/ A UN MPL

It is urgently recommended to remove the following fields as part of customizing the system, as they might lead to misunderstandings and errors.

- Batch number
- Target buffer
- Transport unit
- Comment on batch
- Quality (yield, scrap)
- Quantity
- Reason