

# Manual

## Advanced Terminal Functions AIP-EBM 8.1

Version 1.1.23049

Last changed on: 01.09.2020

## **Copyright**

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

# Contents

|   |                                  |   |
|---|----------------------------------|---|
| 1 | Advanced Terminal Functions..... | 4 |
|---|----------------------------------|---|

# 1 Advanced Terminal Functions

## Purpose

You use this functions package if you need to configure data entry via AIP for specific application scenarios.

## Integration

This function can be used integrated in the BDE, MDE (note the details below about automatic quantity input), MPL and WRM products to enter data at AIP.

## Features



The analysis of specific requirements and the illustration of the processes are a special customizing service that is offered for an additional charge. In order to be able to use the functions described, you must request this added service.

- The ability to assign a HYDRA machine to more than one terminal
- The capability of synchronizing manual posting between the terminals with the same machine so that current postings can be viewed at all logically connected devices:  
Example: An order was logged onto machine 24 (terminal 1). After the function was activated, the order is also immediately "visible" on machine 24 at terminal 2.
- The ability to create an option with which to perform postings that belong to one machine at different terminals, for example, if, because of the long travel paths, there are several of them placed on a line, but in BDE/ MDE they are logically assigned to one machine
- Considering the data quantities and performance capabilities of the devices, terminals can be configured so that more than 16 machines (= normally the upper limit) are assigned to one terminal.

## Checklist: Which functions should especially be considered

- When assigning multiple terminals to one machine, the number of terminals should be kept to a minimum: Communication between terminals increases significantly and in some cases may adversely impact the availability of the terminals.
- During an automatic entry of quantities, automatic quantities may only be entered through exactly one of the terminals.
- The list of logged on batches at AIP is not a part of the AIP-EBM synchronization function.
- The posting volume and how often data are posted at the terminals, especially during a shift change, must be considered: In a worst-case scenario, there may be problems with the synchronization, which might result in incorrect postings.

- The number of machines per terminal must be accounted for based on the posting volume, the data volume and the performance capabilities of the terminal hardware.  
Too many postings may, in some cases, result in conflicts during operation and if there are any network failures, this will result in longer waiting periods until the local queues have been emptied.
- The maximum number of machines per terminal is limited to 32 (technical limit).
- Customer specific adjustments are by default not compatible with AIP-EPM. In any case, they will need to be reviewed in terms of whether AIP-EBM can be used.