

Manual

AIP-AddOn Multimedia Kit AIP-AMK 8.2

Version 1.0.23435

Last changed on: 28.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	AIP Multimedia Kit Add-On	4
2	AIP Add-On Multimedia Kit	5
3	Paths	7
3.1	Sample configurations.....	10

1 AIP Multimedia Kit Add-On

Purpose

Add-on to the HYDRA terminal software if information for the user is to be displayed within the HYDRA application in the form of drawings, photos and videos.

Implementation considerations

You use the function package if:

- Information is to be provided to production in paperless form that extends beyond information in text form
- You want to demonstrate processes where the activities are taking place

Integration

The function package can be added on at any time. In order for it to function correctly, key information must be correctly entered in HYDRA. In addition, the access paths must be correctly set at the documents to be displayed (so-called path configuration)

Features


- Displays document with the following file formats:
Internal viewer: *.txt, *.ini, *.avi, *.tif, *.tiff, *.jpg, *.jpeg, *.dcx, *.eps, *.ico, *.pcx, *.pcc, *.png, *.ppm, *.pgm, *.pbm, *.tga, *.vst, *.afi, *.wmf, *.emf, *.bmp
External HTML viewer: *.htm, *.gif, *.wmv, *.mpg

2 AIP Add-On Multimedia Kit

This function packet makes it possible to display documents in a wide variety of formats in HYDRA.

On the one hand, there is the ability to display documents for operations (see below), however they can also be displayed using the AIP DNC and CAQ functions.

Example for how a document is selected in the AIP BDE function:



General information

Documents, graphics or other files can be displayed from the table in the *Documents* index tab.

By selecting an entry in the list and touching/ clicking on the *Open document* button, the file is downloaded to the AIP and, depending on the file extension, displayed either in an internal viewer or in an external application.

Internal viewer

Supported formats for internal viewers: txt, ini, avi, tif, tiff, jpg, jpeg, dcx, eps, ico, pcx, pcc, png, ppm, pgm, pbm, tga, vst, afi, wmf, emf, bmp.

Supported formats for an external HTML viewer: htm, gif, wmv, mpg,

External applications

If file formats (file extensions) other than the ones described above are used (e.g. PDF files), then external applications must be installed. The customer is responsible for the installation. **Error! Reference source not found.**

Http links as document references

It is also possible to transfer http links to a browser for display without having to download a file first. To do this, a path with the "http" protocol must be used (the path is configured at the console via File > System Administration > Paths).

These links are displayed in the internal HTML viewer supplied with the *AIP*. In this case, the file extension does not affect the selection of the viewer.

The files can also be displayed in the standard browser configured in Windows. To do this, the following flag must be set in the file "hytnrcfg.ini":

```
[Terminal->USR 0]
```

```
HTTPBrowser=standard
```

This setting is not recommended for a touch-screen *AIP* because operating a browser could be problematic.

3 Paths

Overview

HYDRA menu	System administration → System settings → Paths
FEDRA menu	System administration → System settings → Paths
Transaction code	path
Function authorization	path

Purpose

You use the application to create or change paths in the system. A path configuration is a character string that identifies a file, a directory or a resource (depending on the platform) in a computer system, e.g. device files in Unix.

The system uses the paths to access the files stored in the specified location or to store files according to the specified path.

Integration

The path configuration is a central functionality used by multiple functions in the system.

Field descriptions

Path

Identification of the storage location

Protocol

Access schema used for file transfer:

file Network access to the files via UNC file names.

You must ensure that a network share (= Windows share) exists for the folder where the files are stored.

ftp Access via File Transfer Protocol

Condition: An FTP server must be installed.

hydra Access using HYDRA file transfer to transfer files to and from the HYDRA server.

The protocol *hydra* is not supported in the MES Operation Center (MOC). It is recommended not to use this protocol even if the data is on the HYDRA server. Use the protocol *file* or *ftp*.

- http Support of http links to display web contents
- ftps The protocol *ftps* is only supported in the MES Operation Center (MOC).
- smtp The protocol *smtp* is only supported in escalation management (ESK) in combination with the SMS gateway (ESK-SMSGW).
- exe Display of documents with a defined application. The content of the document name is transferred to the application as parameter.

The "exe" support requires specific minimum versions of the MFPlugin on the client (1.2.STD.15028), of the Windows terminals (ctaip, 2.0.2.14) and of the BAPI lib/b_path.dll or lib/b_path.so (7.2.1.13).

- unc Support of unc links to display documents.
- The "unc" support requires specific minimum versions of the MFPlugin on the client (1.2.STD.15028), of the Windows terminals (ctaip, 2.0.2.14) and of the BAPI lib/b_path.dll or lib/b_path.so (7.2.1.13).

Note: To open the linked document, the relevant application is used according to the file extension. With this configuration, the Windows link is used. You cannot override this setting.

Different settings may be made according to the operating system and the network configuration used.

Host

The server's network name or IP address

- smtp SMTP mail server
- file If Tomcat and the system are installed on a shared server and the path is *not* used by the terminal applications (CTWIN, AIP), you can also enter the logical name "localfile" as local delegate access.
- unc Specification of file server name (e.g.: **docserver**)
- Note:** Two backslashes (\\) are automatically put in front of the file server name when the absolute path is later generated.

Port

Number of communication port

- file Not used
- ftp FTP port 0 = default port
- hydra x = 0: Current connection between the console or HYDRA terminal and the server.

x < 0: Connect using user number x.

x > 0: Connect on port x.

http x > 0 port is included in web link

ftps FTPS port number. 0 = default port (client only)

smtp SMTP port number. 0 = default port

exe Not used

unc Not used

URL path

This is the path where the files are stored, expressed as a URL without specification of the server (host). Slashes (/) are automatically converted to backslashes (\) by the clients, if necessary.

Placeholders / or <<MDT>> are not supported by the JAVA server (→ client).

file Specification of the Windows file share and any subdirectories

ftp Specification of the FTP path

hydra The URL path can also be specified relative to the installation location in the system. For example, /mydata refers to a subdirectory mydata of the system installation.

http Path of the web link

ftps Specification of the FTPS path (client only)

smtp Target adress (to:)

exe Specification of program. Parameters for the program must not be entered here. Specify the complete path including program name here (e.g. c:\windows\system32\write.exe).

unc Path name of file storage. Example: \documents\ncdoks\

Note: Correct backslashes (\) must be entered here.

User / password

The user name and password used for file access are entered here. You can use passwords up to a maximum length of 20 characters. You can use Latin letters, numbers and the common special characters. Please note that the MOC may not support certain special characters, for example the pipe or the quotation marks. You can test whether the characters of the password are valid by entering the password in another input field with plain text display, saving it and then taking it out again.

file User name and password used to access the Windows file share.

ftp User name and password used to log on to the FTP server.

hydra Not used

http It depends on the browser in use whether the user/password option is supported or not.
For security reasons, login details should not be used for http paths in general.

Please note:

The Internet explorer does neither process nor support the user/password option.

ftps User name and password used to log on to the FTPS server (client only)

smtp Not used

exe Not used

unc Not used

Comment

Text input field to describe the details entered above.

Overview of permitted configurations

Protocol	Comment	Client	AIP, CTWIN
file	Access via network share	✓	✓
file (host=local file)	Access to local file path	✓	✗
ftp	FTP server required	✓	✓
ftps	FTP server with SSL required	✓	✗
hydra	Proprietary protocol	✗	✓
http	Server upload not possible.	✓ 1)	✓
smtp	For escalation management (ESK) only	✗	✗

1) Presentation of http links defined as production resources and tools from the order information dialog

3.1 Sample configurations

Display of intranet links on the AIP terminal (when using HYDRA)

Use

case:

Depending on the article, the AIP should open and display different intranet pages. The complete path in this example would be:

<http://<host name>/folder1/folder2/folder3/ATK12345>

The first part of the path (host and further folder structure, displayed in blue) remains unchanged. Only the last part changes (folder structure with article, displayed in orange).

Requirements:

The ERP system/the customer transfers the last part (orange) including folder structure and article and the respective path name. These path specifications are included in the Production resources and tools (PRT) of the operation. Example:

Main page

Operation

MES order number S30002000200

Resource

Resource type DOC

Resource Intranet

Designation

Comment 1

Comment 2

Quantity

Required quantity 0

File

Path PATH

File name folder3/ATK12345

Configuration:

Configure the following items in the system:

- Path definition including the fixed section of the path of field *URL path* (blue section).

Main page

Path PATH

Protocol http

Host <host name or <IP address>

Port 80


URL path folder1/folder2

User

Password

Description

- If you do not want to open the link in the internal viewer on the AIP, but in an external viewer, you can store the following definition in the hytnrcfg.ini:



With this configuration, the link opens in the program set as standard in the host, e.g. the Internet Explorer.

Note:

After the configuration, you must restart the AIP terminal.