

Manual

AIP Add-On Online Language Switching AIP-AOS 8.2

Version 1.0.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Online Language Switching	4
2	How to Switch Languages.....	5
3	How to configure language switching	7
3.1	Activation	7
3.2	Instant updating of multilingual database contents	7

1 Online Language Switching

Purpose

The function package is useful if you use shop floor terminals (AIP) that are operated in different languages.

Integration

The AIP online language switching function enables to display data according to the licensed and installed language packs (localization). The component is available for the following HYDRA applications: BDE (Shop Floor Data Collection), MDE (Machine Data Collection), WRM (Tool and Resource Management), DNC (Direct Numeric Control), MPL (Material and Production Logistics), TRT (Tracking & Tracking), PDV (Process Data Collection) and CAQ (Quality Management).

Features

The Acquisition Information Panel (AIP) has been upgraded by a function for online language switching for AIP input dialogs and displays. Switching between the defined languages refers to the static texts included in dialogs and displays and to data contents, provided that they support different languages and are maintained in different languages.

2 How to Switch Languages

Purpose

Use the function to switch languages online via the AIP2 terminal.

Integration

You can switch languages for the licensed and installed language packs ("localization").

Requirements

You have purchased the license for the used language pack(s) ("localization").

You have configured the online language switching (see section *How to configure* language switching).

If you also want to show translated database contents (MDBI texts, e.g. status texts), you have to activate and maintain these texts.

Terminal functions

The bottom taskbar of the AIP terminal shows the flag of the currently selected language. The flag has a green frame to indicate that the AIP start screen is opened. In this case, you can change the language. If you open another screen/dialog the frame around the flag turns red to indicate that language switching is currently not possible.

If you click the flag, a menu appears where you can choose the available languages:

The screenshot displays the AIP Add-On Online Language Switching interface. On the left, a list of workstations is shown with their status and counts. The center section provides detailed information for a selected workstation, including its name, group, status, and various production metrics. The bottom section lists the registered persons for that workstation. A language selection menu is open, allowing users to switch between English, Deutsch, and Chinesisch.

Arbeitsplatz / Maschine	
Arbeitsplatz / Maschine	Kurzbezeichnung Gruppe Status
33021	HAND02 FINISH PRODUKTION
Takte	Beginn Dauer [Std:Min]
0	03.08.2015 06:00 1376:56
Sollzyklus [Sek./Takt]	Istzyklus Gutmenge Ausschuss
20	0 833 4

Arbeitsgänge	
MES Auftragsnummer	S30002090200
Entgraten	
Artikel	SAR-VPO011-M-9005
Mengen (Soll / Gut / Ausschuss)	1200 / 660 / 0

Angemeldete Personen		
Person	Person	Person
10002630	85741	40563
Name	Name	Name
Weis, Sabine	Meier, Josef	Grieber, Maria

The menu shows all configured languages. You can switch between a maximum of five languages.



If the terminal is offline, you cannot switch languages. An error message is displayed.

3 How to configure language switching

3.1 Activation

Use the file **hytnrcfg.ini** to configure language switching.

Example:

```
[multiple_language 0]
alt_lang1=2;1kEnglish
alt_lang2=1;1kGerman
alt_lang3=4;1kFrench
alt_lang4=15;1kChinese
```

Add an entry *alt_lang<x>* with consecutive number for each language to the section *[multiple_language 0]*. The language index of the required language follows after the equal sign. Then you find the name to be displayed or the corresponding language key, separated by semicolon.

The displayed flag is stored in the archive *pict.zip* and has the file name *LangFlag_<y>.png*; *y* stands for the corresponding language index.

The maximum number of languages that can be changed is restricted to 5 .

3.2 Instant updating of multilingual database contents



Available as of AIP version 8.2.2.34.

Service pack 16 provides this version.

If you use multilingual database contents and you switch languages, texts will only be displayed in other languages once the terminal has requested the data anew from the server. Until then the texts of the previously selected language are displayed. This delay might take some minutes depending on system configuration and the time of the last update.

You can configure the terminal to request all or specific lists from the server immediately after languages have been switched. Consequently, texts will be displayed instantly in the newly selected language.

You can configure this in the same section of the file **hytnrcfg.ini** where you also activate language switching.

Example:

```
[multiple_language 0]
alt_lang1=2;lkEnglish
```

...

LST-RELOAD-ON-LANGUAGE-CHANGE=<ALL>

Use the entry "LST-RELOAD-ON-LANGUAGE-CHANGE=<ALL>" to cause the AIP to request the data of all below-mentioned lists from the server after languages have been switched.



If the terminal still sends dialogs to the server (queue is not empty) when languages are switched, the data is not updated immediately but only once all dialogs have been sent to the server.

Updating of all data might take a while, subject to the amount of data and the infrastructure of your system. Users cannot operate the terminal during that time. To reduce the required time, you can restrict updating to your most important lists. Data of the other lists will be reloaded later during the regular update process.

Example:

```
[multiple_language 0]
alt_lang1=2;lkEnglish
```

...

LST-RELOAD-ON-LANGUAGE-CHANGE=MNR,MSTAT,AGRD,LOKVLIST

Use the following acronyms to reload only specific lists with texts from the server after language switching:

Acronyms	List
MNR	Machines
ANR	Orders
MSTAT	Machine status
HZTYP	Material types
AGRD	Reasons (reasons for scrap and other quantity types)
ZLO	Target locations
TPE	Transport units
AART	Order types
MAT	List of input materials logged on
RES	Resources
LOKVLIST	Sequencing lists of all assigned machines



Multilingual database contents must be enabled on the server. This document does not deal with the activation of multilingual database contents.

The installation manual of your MES Weaver system (MW) provides further information for system administrators. Contact MPDV if you need help with the activation of multilingual

database contents on the server.