

Manual

Overview of EMG Escalation Messages EMG-ESK 8.1

Version 1.0.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview Escalation Messages to EMG	4
2	Available Escalations	5
2.1	Events from the performance profile.....	5
2.2	Reading interval exceeded (RESWART.LIMIT_EXCEEDED).....	6
2.3	Absolute value limit exceeded (EMG.ABSOLUTE_VALUE_EXCEEDED)	6
2.4	Please note with regard to configuration.....	6
2.4.1	Activating escalation messages for activity recording	6

1 Overview Escalation Messages to EMG

Purpose

HYDRA escalation management provides a framework of functions for real-time forwarding of recorded or live events to individual users or user groups. During the process, escalation management takes active steps to ensure users are notified.

After notification, escalation management monitors times until acknowledgment by the recipients and until escalation is concluded. Escalations can be forwarded to other users or user groups during processing.

Implementation considerations

You use escalation management if you would like to have active, real-time notification of specific events in the BDE production environment so that you can react early enough to prevent downtimes and so that efficiency and productivity can be increased.

Integration

The events/ escalations already triggered in the EMG field are forwarded to central escalation management. This forms the framework used to forward the events triggered and to be able to follow up on them.

To notify people, escalation management accesses both [User Administration](#) as well as the [HR Master Data](#) stored in the system. Notifications can be sent out as e-mails by integrating the local mail server into the system.

Features

Application service (AS) to generate escalation messages, which, depending on the configuration, are forwarded to a defined group of users (e.g. the energy officer, the production manager, machine operator, maintenance technician) by e-mail, text message, etc.:

- Configuration of events that should trigger an escalation:
- Forwarding of the detected events to the HYDRA escalation management framework.
- Typical escalation examples:
 - Absolute value limit of a resource has been exceeded
 - Planned read-out point is exceeded
 - Tolerance limit has been exceeded

2 Available Escalations

2.1 Events from the performance profile

event_id	event_name	
PPMM.ACTION_LIMIT_EXCEEDED	Action limits* exceeded	EMG 8.1
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	EMG 8.1

* Understood as an "action limit" is the process action limit within the meaning of PDV

Event	Description	Identifiers	Description	Please note:
PPMM.ACTION_LIMIT_EXCEEDED	Process action limit exceeded	MNR.MNR	Machine number	An escalation is triggered by the terminal if a violation of the process action limit is detected.
		PPMM.MMNR	Characteristic number	
		MM.BEZX	Characteristic designation	
		MM.BEZX	Characteristic designation	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	MNR.MNR	Machine number	An escalation is triggered by the terminal if a violation of the tolerance limit is detected.
		PPMM.MMNR	Characteristic number	
		MM.BEZX	Characteristic designation	
		MM.BEZX	Characteristic designation	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	

2.2 Reading interval exceeded (RESWART.LIMIT_EXCEEDED)

The cyclically active maintenance monitoring program triggers an escalation as soon as a maintenance limit for a reading has been exceeded.

Event	Identifiers	Description
RESWART.LIMIT_EXCEEDED	RESWART.RESTYP	Resources types
	RESWART.RES	Resources no.
	RESWART.BEZ	Maintenance
	RESWART.WARTKL	Class
	RESWART.WART:N	Value next maintenance
	RESWART.WART:I	Actual value
	RESWART.WARTNR	Threshold reached 1, 2, 3
	RESWART.ART	Maintenance type

2.3 Absolute value limit exceeded (EMG.ABSOLUTE_VALUE_EXCEEDED)

The cyclically active monitoring program triggers an escalation as soon as an absolute value limit for a counter resource has been exceeded.

Event	Identifiers	Description
EMG.ABSOLUTE_VALUE_EXCEEDED	RES.ABSWGRENZE	Absolute value limit
	RES.EGR:GUT	Current counter value
	RES.RES	Resource
	RES.RSTDAT	Reset date
	RES.RESRSTZEI	Reset time
	RES.TYP	Resource type

2.4 Please note with regard to configuration

2.4.1 Activating escalation messages for activity recording

Escalation messages are activated at the terminal or the PCC.

With regard to the details, please refer to the [document on PDV escalations](#).

