

Manual

Overview EMG Escalation Messages EMG-ESK 8.3

Version 1.0.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview: EMG Escalation Messages	4
2	Available Escalations	5
2.1	Events from the performance profile.....	5
2.2	Reading interval exceeded (RESWART.LIMIT_EXCEEDED).....	6
2.3	Absolute value limit exceeded (EMG.ABSOLUTE_VALUE_EXCEEDED)	6
2.4	Please note with regard to configuration.....	6
2.4.1	Activating escalation messages for activity recording	6

1 Overview: EMG Escalation Messages

Purpose

The HYDRA Escalation Management provides a framework of functions to promptly forward collected or live events to specific users or user groups. The escalation management actively notifies users.

For the notification sent, the escalation management monitors the times until the notification is acknowledged and until the escalation is completed. Escalations can be forwarded to other users or user groups during processing.

Implementation notes

You use the escalation management to get an active, prompt notification about specific events that occur in the BDE production environment. This prompt notification helps you to react early enough to prevent downtimes and increase efficiency and productivity.

Integration

The events/escalations already triggered in the EMG environment are forwarded to the central escalation management. The escalation management provides the framework for forwarding and following up on triggered events.

To notify persons, the escalation management accesses both, the [User administration](#) and the [HR master data](#) stored in the system. You can also send notifications via e-mail because the local mail server is also integrated.

Features

Application service (AS) to generate escalation messages, which, depending on the configuration, are forwarded to a defined group of users (e.g. the energy officer, the production manager, machine operator, maintenance engineer) by e-mail, text message, etc.:

- Configuration of events that trigger an escalation
- Forwarding of the detected events to the HYDRA escalation management framework
- Typical escalation examples:
 - Absolute value limit of a resource has been exceeded
 - Planned read-out point is exceeded
 - Tolerance limit has been exceeded

2 Available Escalations

2.1 Events from the performance profile

event_id	event_name	
PPMM.ACTION_LIMIT_EXCEEDED	Action limits* exceeded	EMG 8.1
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	EMG 8.1

* Understood as an "action limit" is the process action limit within the meaning of PDV

Event	Description	Identifiers	Description	Please note:
PPMM.ACTION_LIMIT_EXCEEDED	Process action limit exceeded	MNR.MNR	Machine number	An escalation is triggered by the terminal if a violation of the process action limit is detected.
		PPMM.MMNR	Characteristic number	
		MM.BEZX	Characteristic designation	
		MM.BEZX	Characteristic designation	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	MNR.MNR	Machine number	An escalation is triggered by the terminal if a violation of the tolerance limit is detected.
		PPMM.MMNR	Characteristic number	
		MM.BEZX	Characteristic designation	
		MM.BEZX	Characteristic designation	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	

2.2 Reading interval exceeded (RESWART.LIMIT_EXCEEDED)

The cyclically active maintenance monitoring program triggers an escalation as soon as a maintenance limit for a reading has been exceeded.

Event	Identifiers	Description
RESWART.LIMIT_EXCEEDED	RESWART.RESTYP	Resources types
	RESWART.RES	Resources no.
	RESWART.BEZ	Maintenance
	RESWART.WARTKL	Class
	RESWART.WART:N	Value next maintenance
	RESWART.WART:I	Actual value
	RESWART.WARTNR	Threshold reached 1, 2, 3
	RESWART.ART	Maintenance type

2.3 Absolute value limit exceeded (EMG.ABSOLUTE_VALUE_EXCEEDED)

The cyclically active monitoring program triggers an escalation as soon as an absolute value limit for a counter resource has been exceeded.

Event	Identifiers	Description
EMG.ABSOLUTE_VALUE_EXCEEDED	RES.ABSWGRENZE	Absolute value limit
	RES.EGR:GUT	Current counter value
	RES.RES	Resource
	RES.RSTDAT	Reset date
	RES.RESRSTZEI	Reset time
	RES.TYP	Resource type

2.4 Please note with regard to configuration

2.4.1 Activating escalation messages for activity recording

Escalation messages are activated at the terminal or the PCC.

With regard to the details, please refer to the [document on PDV escalations](#).

