

Manual

MPL Escalation Messages (AS)

MPL-ESK 8.2

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Available Escalations	4
1.1	Batch was created by goods receipt (CNR.INCOMING)	4
1.2	Batch has been consumed (CNR.CONSUMED)	4
1.3	Batch has been deleted (CNR.DELETED)	5
1.4	Batch was transferred to another material buffer (CNR.TRANSFERRED)	5
1.5	Batch was manually locked (CNR.LOCKED)	6
1.6	Transport work plan not found (TRANR.TAP_NOT_FOUND)	6
1.7	Transport order already active (TRANR.TO_ACTIV)	7
1.8	Availability date reached (CNR.AVAILABLE)	7
1.9	Warning date exceeded (CNR.WARNING)	8
1.10	Expiry date exceeded (CNR.EXPIRED)	9
1.11	Batch status has changed (CNR.BATCHSTATUSCHANGED)	10
1.12	Input batch logged on (CNR.INPUTLOGGEDON)	11
1.13	Input batch logged off (CNR.INPUTLOGGEDOFF)	12
1.14	Output batch logged on (CNR.OUTPUTLOGGEDON)	13
1.15	Output batch logged off (CNR.OUTPUTLOGGEDOFF)	13
1.16	Input batch logged on in advance (CNR.PREREGISTERED)	14
1.17	Split batch (CNR.SPLITTED)	15
1.18	Collective batch (CNR.SUMMARIZED)	16

1 Available Escalations

The HYDRA Escalation Management provides a framework of functions to promptly forward collected or live events to specific users or user groups. The escalation management actively notifies users.

For the notification sent, the escalation management monitors the times until the notification is acknowledged and until the escalation is completed. Escalations can be forwarded to other users or user groups during processing.

The sections below describe all escalations of the MPL and TRT including their parameters.



If an identifier is replaced with the sign "@" in the message of an escalation, then this identifier is not available in the event that triggers the escalation. Identifiers that are not available are not identified subsequently.

1.1 Batch was created by goods receipt (CNR.INCOMING)

This event is triggered when a batch is generated.

Event	Identifiers	Description
CNR.INCOMING	CNR.CNR	Batch number
	CNR.ANR	Order + operation
	CNR.MNR	Workplace
	CNR.CKL	Batch class
	CNR.ZLO	Material buffer
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.STA	Batch status
	CNR.BEM	Comment
	CNR.MATTYP	Material type
	CNR.MATTYPART	Kind of material
	CNR.SGR:GUT	Target quantity yield
	CNR.SGE:GUT	Target quantity unit
	CNR.RGR:GUT	Remaining quantity yield
	CNR.DAT	Date
	CNR.ZEI	Time

1.2 Batch has been consumed (CNR.CONSUMED)

This event is triggered when an input batch is consumed. The batch is consumed when the remaining batch quantity = 0 when the input batch is logged off, for example.

Event	Identifiers	Description
CNR.CONSUMED	CNR.CNR	Batch number
	CNR.ANR	Order + operation
	CNR.MNR	Workplace
	CNR.CKL	Batch class
	CNR.ZLO	Material buffer
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.STA	Batch status
	CNR.BEM	Comment
	CNR.MATTYP	Material type
	CNR.MATTYPART	Kind of material
	CNR.OPT:VERBR	Consumption type
	CNR.DAT	Date
	CNR.ZEI	Time

1.3 Batch has been deleted (CNR.DELETED)

This event is triggered when the batch status Deleted is followed by a status change.

Event	Identifiers	Description
CNR.DELETED	CNR.CNR	Batch number
	CNR.GR	Reason
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.GRTXT	Reason text
	CNR.STA	Batch status
	CNR.BEM	Comment
	CNR.MATTYPART	Kind of material

1.4 Batch was transferred to another material buffer (CNR.TRANSFERRED)

This event is triggered when a batch changes the material buffer.

Event	Identifiers	Description
CNR.TRANSFERRED	CNR.CNR	Batch number
	CNR.ANR	Order + operation

Event	Identifiers	Description
	CNR.MNR	Workplace
	CNR.CKL	Batch class
	CNR.ZLO	Material buffer
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.STA	Batch status
	CNR.BEM	Comment
	CNR.MATTYP	Material type
	CNR.MATTYPART	Kind of material
	CNR.OPT:VERBR	Consumption type: M → manual R → backflush (retrograde)
	CNR.DAT	Date
	CNR.ZEI	Time

1.5 Batch was manually locked (CNR.LOCKED)

This event is triggered when a batch is manually locked. If the status *Manual Q status* is set to *Locked* by the function C_STA, then the event CNR.LOCKED is triggered. The function C_STA is triggered when the CAQ option 1210 is applied. For details on use and configuration, refer to the document [Configuration QM/CAQ Options](#).

Event	Identifiers	Description
CNR.LOCKED	CNR.CNR	Batch number
	CNR.GR	Reason
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.GRTXT	Reason text
	CNR.STA	Batch status
	CNR.QST	Manual quality status
	CNR.BEM	Comment
	CNR.MATTYPART	Kind of material

1.6 Transport work plan not found (TRANR.TAP_NOT_FOUND)

The following escalation is triggered if no active work plan can be found at the time when a transport order is created:

Event	Identifiers	Description
-------	-------------	-------------

Event	Identifiers	Description
TRANR.TAP_NOT_FOUND	TRANR.ATK	Article number
	TRANR.AUART	Order type
	TRANR.SANR	Triggering OP
	TRANR.DAT	Current date
	TRANR.ZEI	Current time

1.7 Transport order already active (TRANR.TO_ACTIV)

This escalation is triggered if a production operation is deallocated (cancelled/unplanned) that is already assigned to an active transport order.

Event	Identifiers	Description
TRANR.TO_ACTIV	TRANR.AUNR	Order number of transport order
	TRANR.ANR	OP number of transport order
	TRANR.ANR_STA	OP status of transport order
	TRANR.SANR	Deallocated OP
	TRANR.DAT	Current date
	TRANR.ZEI	Current time

1.8 Availability date reached (CNR.AVAILABLE)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch reaches the availability date, then this escalation is triggered. The availability date is cyclically monitored via an entry in the HYDRA scheduler. For further information on the cyclic monitoring, refer to the document [Monitoring of availability dates](#).



The availability date is monitored by a cyclic job in the scheduler. To use the availability date and to run the cyclic job in the scheduler, you require the license MPL-MMO.

Event	Identifiers	Description
CNR.AVAILABLE	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.VVDAT	Availability date
	CNR.VVZEI	Availability time
	CNR.WDAT	Warning date
	CNR.WZEI	Warning time
	CNR.VFDAT	Expiry date
	CNR.VFZEI	Expiry time
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.RGR:GUT	Remaining quantity
	CNR.SGE:GUT	Unit
	CNR.MATTYPART	Kind of material
	CNR.ZLO	Material buffer
	CNR.CKL	Batch class
	CNR.STA	Batch status

1.9 Warning date exceeded (CNR.WARNING)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch has exceeded the warning date, then this escalation is triggered. The warning date is cyclically monitored via an entry in the HYDRA scheduler. For further information on the cyclic monitoring, refer to the document [Monitoring of availability dates](#).



The warning date is monitored by a cyclic job in the scheduler. To use the warning date and to run the cyclic job in the scheduler, you require the license MPL-MMO.

Event	Identifiers	Description
CNR.WARNING	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.WDAT	Warning date
	CNR.WZEI	Warning time
	CNR.VFDAT	Expiry date
	CNR.VFZEI	Expiry time
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.RGR:GUT	Remaining quantity
	CNR.SGE:GUT	Unit
	CNR.MATTYPART	Kind of material
	CNR.ZLO	Material buffer
	CNR.CKL	Batch class
	CNR.STA	Batch status

1.10 Expiry date exceeded (CNR.EXPIRED)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection

method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch has exceeded the expiry date, then this escalation is triggered. The expiry date is cyclically monitored via an entry in the HYDRA scheduler. For further information on the cyclic monitoring, refer to the document [Monitoring of availability dates](#).



The expiry date is monitored by a cyclic job in the scheduler. To use the expiry date and to run the cyclic job in the scheduler, you require the license MPL-MMO.

Event	Identifiers	Description
CNR.EXPIRED	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.VFDAT	Expiry date
	CNR.VFZEI	Expiry time
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.RGR:GUT	Remaining quantity
	CNR.SGE:GUT	Unit
	CNR.MATTYPART	Kind of material
	CNR.ZLO	Material buffer
	CNR.CKL	Batch class
	CNR.STA	Batch status

1.11 Batch status has changed (CNR.BATCHSTATUSCHANGED)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection

method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

Event	Identifiers	Description
CNR.BATCHSTATUSCHANGED	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.RGR:GUT	Remaining quantity
	CNR.SGE:GUT	Unit
	CNR.MATTYPART	Kind of material
	CNR.STA	„Neuer“ Losstatus

1.12 Input batch logged on (CNR.INPUTLOGGEDON)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is logged on as input batch, then this escalation is triggered. The data of the escalation includes the information collected when the input batch is logged on.

Event	Identifiers	Description
CNR.INPUTLOGGEDON	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.ATK	Article

Event	Identifiers	Description
	CNR.ATKBEZ	Article designation
	CNR.ANR	MES order number
	CNR.MNR	Workplace
	CNR.PNR	Personnel number
	CNR.KNR	Staff badge number
	CNR.SLP	BOM item

1.13 Input batch logged off (CNR.INPUTLOGGEDOFF)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is logged off as input batch, then this escalation is triggered. The data of the escalation includes the information collected when the input batch is logged off.

Event	Identifiers	Description
CNR.INPUTLOGGEDOFF	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.BEM	Info on batch
	CNR.ANR	MES order number
	CNR.MNR	Workplace
	CNR.PNR	Personnel number
	CNR.KNR	Staff badge number
	CNR.SLP	BOM item
	CNR.RGR:GUT	Remaining quantity of the batch
	CNR.SGE:GUT	Unit
	CNR.EGR:VERB	Verbrauch des Eingangslos

Event	Identifiers	Description
	CNR.STA	Losstatus nach Abmeldung

1.14 Output batch logged on (CNR.OUTPUTLOGGEDON)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is logged on as output batch, then this escalation is triggered. The data of the escalation includes the information collected when the output batch is logged on.

Event	Identifiers	Description
CNR. OUTPUTLOGGEDON	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.ANR	MES order number
	CNR.MNR	Workplace
	CNR.PNR	Personnel number
	CNR.KNR	Staff badge number
	CNR.CALT1.. CNR.CALT20	Alternative batch number 1...20

1.15 Output batch logged off (CNR.OUTPUTLOGGEDOFF)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is logged off as output batch, then this escalation is triggered. The data of the escalation includes the information collected when the output batch is logged off.

Event	Identifiers	Description
CNR. OUTPUTLOGGEDON	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.ANR	MES order number
	CNR.MNR	Workplace
	CNR.PNR	Personnel number
	CNR.KNR	Staff badge number
	CNR.EGR	Recorded quantity
	CNR.EGE	Unit
	CNR.CKL	Class (yield, scrap, open quantity, rework)
	CNR.STA	Status
	CNR.EGG	Reason
	CNR.ZLO	Material buffer
	CNR.TPE	Transport unit
	CNR.BEM	Info on batch
	CNR.FU:1 – CNR.FU:66	User fields Date values are output in format "mm/dd/yyyy".
	CNR.CALT1 – CNR.CALT5	Alternative batch number 1...5

1.16 Input batch logged on in advance (CNR.PREREGISTERED)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is logged on in advance as input batch, then this escalation is triggered. The data of the escalation includes the information collected when the input batch is logged on in advance. For further information on the advance logon of an input batch, refer to the documentation [MBL Advance logon of input batches](#).

Event	Identifiers	Description
CNR.PREREGISTERED	CNR.DLL	Batch number
	CNR.CNR	Internal batch number
	CNR.ATK	Article
	CNR.ATKBEZ	Article designation
	CNR.ANR	MES order number
	CNR.MNR	Workplace
	CNR.PNR	Personnel number
	CNR.KNR	Staff badge number
	CNR.SLP	BOM item

1.17 Split batch (CNR.SPLITTED)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection

method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a batch is split, then this escalation is triggered.

The identifier "CNR.SPLITTED" includes information about the batches that are created when a batch is split. The following information is displayed for the split batches in the identifier "CNR.SPLITTED":

- Internal batch number (CNR)
- Quantity
- Class
- Reason

Event	Identifiers	Description
CNR. SPLITTED	CNR.CNR	Internal batch number that was split
	CNR.SPLITTED	Array of the split batches. The array includes the values "batch number", "quantity", "class" and "reason" per batch that is split off.

1.18 Collective batch (CNR.SUMMARIZED)



This escalation is available as of Service Pack 16.



To use this escalation, you must explicitly activate the escalation. Activation instruction: See [here](#).

When the escalation has been activated, you must restart HYDRA.



After activation of the escalation, the data volume required to retain data in the escalation management can increase considerably. This increase is subject to the specific data collection method.

Observe the development of the data volume in the escalation management after activation and change the [archiving settings of the escalation management](#), if required.

If a collective batch is generated, then this escalation is triggered.

The identifier "CNR.SUMMARIZED" includes the information about the batches that were used to create the collective batch. For the batches used to create the collective batch, the identifier "CNR.SUMMARIZED" shows the batch number (CNR).

Event	Identifiers	Description
CNR.SUMMARIZED	CNR.CNR	Internal batch number of batch, which is generated by merging the other batches. This identifier is always filled.
	CNR.SUMMARIZED	Array of the batches used to create the collective batch.
	CNR.CNR:NEW	If mode "N – generate new batch" is used to create the collective batch, then this field is filled.