

Manual

REK Escalation Messages REK-ESK 8.1

Version 1.0.1374

Last changed on: 19.06.2020

Copyright

©Copyright 2012 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	ESK Escalation Messages - Overview.....	4
2	Available Escalations	5
2.1	Measure generated (CMASSN.INSERTED).....	5

1 ESK Escalation Messages - Overview

Fields of application

HYDRA escalation management provides a framework of functions for real-time forwarding of recorded or live events to individual users or user groups. During the process, escalation management takes active steps to ensure users are notified.

After notification, escalation management monitors times until acknowledgment by the recipients and until escalation is concluded. Escalations can be forwarded to other users or user groups during processing.

Implementation notes

You use escalation management if you would like to have active, real-time notification of specific events in the inspection environment so that you can react early enough to prevent downtimes and so that efficiency and productivity can be increased.

Integration

The events/ escalations already triggered are posted to central escalation management. This forms the framework used to forward the events triggered and to be able to follow up on them.

To notify people, escalation management accesses both [User administration](#) as well as the [HR master data](#) stored in the system. Notifications can be sent out as e-mails by integrating the local mail server into the system.

Features

- Provision of different escalation messages in the environment of inspection data collection
- Event configuration: configuration of order-related events
- Forwarding of the detected events to the HYDRA escalation management framework

2 Available Escalations

2.1 Measure generated (CMASSN.INSERTED)

Once a measure has been generated, the escalation is triggered.

Event	Identifiers	Description
CMASSN.INSERTED	CMASSN.MASSER	Identifier for the measure
	CMASSN.RECTYP	Data type
	CMASSN.RECREF	Assignment
	CMASSN.BER	Area
	CMASSN.KEY:1	Key field 1
	CMASSN.KEY:2	Key field 2
	CMASSN.KEY:3	Key field 3
	CMASSN.KEY:4	Key field 4
	CMASSN.KEY:5	Key field 5
	CMASSN.MASNR	Measures number
	CMASSN.MASTEXT	Measures text
	CMASSN.VERANT:TYP	Responsible - type
	CMASSN.VERANT:NR	Responsible - number
	CMASSN.STA	Status
	CMASSN.ZIELDAT	Target date - date
	CMASSN.ZIELZEI	Target time - time
	CMASSN.BEM	Comment
	PNR	Person responsible (only if the person responsible is from the HR master data)