

Manual

Required Resources WRM-BRW 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview of Required Resources	4
1	Overview	5
1.1	General notes on the document	5
1.2	Classification	5
2	Required Resources	6
2.1	Starting the Function	6
2.2	Toolbar	6
2.2.1	"General" tab	6
2.3	Selection parameters	8
2.4	Detail Applications	8
2.4.1	Table view	8
2.5	Editing functions	9
2.5.1	Add new data record	9
2.5.2	Copy data record	9
2.5.3	Delete data record	9
2.6	Field description	9

1 Overview of Required Resources

Purpose

Required resources have been designed to facilitate handling of anonymous resources required in planning and resource allocation. One or several specific resources can be assigned to one anonymous resource. In the list of production resources and tools the anonymous resource is used as a placeholder for one of the specific resources assigned.

When logging on resources, one of the specific resources is logged on instead of the anonymous resource.

Implementation notes

The function package is used if you would like:

- to define anonymous resources required and assign specific resources that can actually be used to cover requirements.
- to consider required resources while assigning resources
- to log on/off specific resources assigned to a required resource

Integration

Required resources enable management and planning of anonymous resources required instead of specific, individual resources.

The displayed resource allocation results from detailed planning in HYDRA Shop Floor Scheduling or the ERP system.

Functions

Definition of anonymous resources required and assignment of real resources that can be used to cover the demand

Taking into account the availability of required resources when planning and assigning resources

Terminal function to log on/off a real resource instead of an anonymous resource

1 Overview

1.1 General notes on the document

This document describes the application "Required Resources" within the Manufacturing Operation Center (MOC). General information on how to use MOC can be found in the document entitled "[moc_cc.pdf](#)".

1.2 Classification

This function allows for resources to be assigned to a required resource. A required resource is a placeholder for a specific amount of actual resources. Required resources can be taken into account during planning. To do so, the required resources are entered as demand in their required amount for the operation in the PRT list. This requirement/demand is considered when assigning resources. The available amount matches the quantity of actual resources assigned to the required resource in this application. When logging orders on to the HYDRA terminal, a resource that is assigned to a required resource has to be logged on explicitly.

Example:

Five identical tools are available for the production of an article/item. When planning, it is irrelevant which one of these five identical tools is actually used to produce the article. The shop floor scheduling module considers the required resource that is assigned to the operation as anonymous resource that is available in a quantity of five tools.

When logging the operation on to the shop floor terminal, it is up to the user's decision which one of the five available tools, they actually want to use by logging on the required one.

2 Required Resources

2.1 Starting the Function

Menu	Master data → Resources → Required resources
Transaction code	reqres
Function authorization	mdreqres

2.2 Toolbar

The following functions can be started using the toolbar of the application. These functions affect the entire application including all detailed applications.

2.2.1 "General" tab

"Data" category



Request data

The information displayed in the application is requested according to the entered selection criteria. This process might take some time depending on the dataset from which the system filters data and on the selection result to be transferred and displayed.



Cancel

The query sent by clicking the "request data" button can be canceled using this function.



Print preview

The print preview is opened for the selected detail application. The print preview also includes further options to change the resulting printout and functions for exporting the displayed information into other formats, such as PDF, Excel, image files.



Save

The application design configured by the user, e.g. columns and categories displayed as well as their respective size and display locations, etc. are only saved if the user requests it. In this case, the user has to affirm the confirmation prompt by clicking "Yes".

“Functions” Category



Add

Function authorization: mdreqres.create

Opens the editing dialog to create a new entry.



Edit

Function authorization: mdreqres.edit

Opens the editing dialog to modify an existing entry.



Copy

Function authorization: mdreqres.copy

Opens the editing dialog to copy an existing entry.



Delete

Function authorization: mdreqres.delete

Opens the editing dialog to delete existing entries.

"Go to" category



Required resource

Function authorization: mdres

Opens the application "resource configuration" for the selected required resource.



Assigned resource

Function authorization: mdres

Opens the application "resource configuration" for the assigned resource.

“Help” Category



Help on operation

Clicking this button opens the help file describing how to operate MOC. The basic document is entitled "[moc_cc.pdf](#)". It describes how to use MOC in general and applies for all applications.

**Help on application**

This function opens the manual for the respective application from which the help file was requested. The application manual integrates the application function into the MES context and explains the information to be displayed. The documentation also includes all detailed applications.

**Help on detail application**

This function opens the application manual at the section where the relevant detailed application is described.

2.3 Selection parameters

The selection panel can be used to filter by superordinate or by assigned resources. The following selection criteria are available in the application:

Resource type

Type of resource.

Resource family

Family to which the resource is assigned.

Resource

Unique ID of the resource.

2.4 Detail Applications

2.4.1 Table view

The table view of the detail application offers the user an overview of existing entries. The displayed information can be sorted using table functions and depends on specified selection parameters.

When an editing function is started, it affects the entry/entries selected in the table.

The displayed fields can be customized using the “add columns” or “remove columns” functions of the context menu (column configurator).

Individual fields are described in the section entitled "field description".

2.5 Editing functions

2.5.1 Add new data record

Clicking the “insert” function opens an input dialog that provides the possibility to create and save a new entry along with all corresponding fields.

Once the values have been entered, the user can save the entered parameters and exit the input dialog by clicking the  button.

Using the  button, the user is able to cancel the input and to leave the input dialog (without saving).

Individual fields are described in the section entitled "field description".

2.5.2 Copy data record

The “copy” function provides the option to use an existing entry as a template for creating a new entry.

Once data have been copied, the user may save the new data record and exit the copy dialog by clicking the  button.

The  button enables the user to cancel the copy process and to leave the copy dialog (without saving).

2.5.3 Delete data record

By selecting a data record in the table view and clicking the “delete” function, the user can delete the selected entry.

The user is able to carry out or cancel the deletion process for the selected data record by answering the confirmation prompt that opens.

2.6 Field description

Resource type

Resource type which the resource is assigned to. This field is respectively displayed for the required resource as well as for the assigned resource.

Resource family

Resource family which the resource is assigned to. This field is respectively displayed for the required resource as well as for the assigned resource.

Resource

Unique ID of the resource. This field is respectively displayed for the required resource as well as for the assigned resource.

Name/Description

Unique resource name. This field is respectively displayed for the required resource as well as for the assigned resource.

Responsibility area

Responsibility area which the resource is assigned to.

Further master data fields can be shown in the table, please also see the application dealing with [Master data configuration of resources](#).