## **Memory Instructions**

## HEXADECIMAL DESCRIPTION CODE

CODE	
1XXX	ADD (add memory word to AC)
2XXX	LDA (load memory word to AC)
4XXX	BUN (Branch unconditionally)
5XXX	SUB (subtract memory word from AC)

## **Register Instructions**

HEXADECIMAL	DESCRIPTION
CODE	

7020	INC (increment AC)
7004	SZA (skip next instruction if AC zero)