
AUTONOMOUS MOBILE ROBOTICS

MOTION PLANNING AND CONTROL

GEESARA KULATHUNGA



SEPTEMBER 7, 2022

CONTROL OF MOBILE ROBOTS

CONTENTS

- Kinematics of wheeled mobile robots: internal, external, direct, and inverse
 - Differential drive kinematics
 - Bicycle drive kinematics
 - Rear-wheel bicycle drive kinematics
 - ► Car(Ackermann) drive kinematics
- Wheel kinematics constraints: rolling contact and lateral slippage
- Wheeled Mobile System Control: pose and orientation
 - Control to reference pose
 - ► Control to reference pose via an intermediate point
 - ► Control to reference pose via an intermediate direction
 - Control by a straight line and a circular arc
 - ► Reference path control
- Smooth path planning in a given 2-D space for vehicles with nonholonomic constraints using Hybrid A*

According to Fig. ??,

■ Steering angle α , steering wheel angular velocity ω_S , ICR point is defined by intersection of both wheel axes, and distance between wheels d

According to Fig. ??,

- Steering angle α , steering wheel angular velocity ω_S , ICR point is defined by intersection of both wheel axes, and distance between wheels d
- We can define R(t)

$$R(t) = d \tan(\frac{\pi}{2} - \alpha(t)) = \frac{d}{\tan(\alpha(t))}$$
 (1)

According to Fig. ??,

- Steering angle α , steering wheel angular velocity ω_S , ICR point is defined by intersection of both wheel axes, and distance between wheels d
- We can define R(t)

$$R(t) = d \tan(\frac{\pi}{2} - \alpha(t)) = \frac{d}{\tan(\alpha(t))}$$
 (1)

 \blacksquare Angular velocity ω around ICR

$$\omega(t) = \dot{\Phi} = \frac{\mathbf{v}_{s}(t)}{\sqrt{d^{2} + R^{2}}} = \frac{\mathbf{v}_{s}(t)}{d} sin(\alpha(t))$$
 (2)

According to Fig. ??,

- Steering angle α , steering wheel angular velocity ω_S , ICR point is defined by intersection of both wheel axes, and distance between wheels d
- We can define R(t)

$$R(t) = d \tan(\frac{\pi}{2} - \alpha(t)) = \frac{d}{\tan(\alpha(t))}$$
 (1)

 \blacksquare Angular velocity ω around ICR

$$\omega(t) = \dot{\Phi} = \frac{\mathbf{v}_{s}(t)}{\sqrt{d^{2} + R^{2}}} = \frac{\mathbf{v}_{s}(t)}{d} sin(\alpha(t))$$
 (2)

■ Steering wheel velocity

$$\mathbf{v}_{\mathsf{S}}(t) = \omega_{\mathsf{S}}(t)r \tag{3}$$

BICYCLE MOBILE (FRONT WHEEL DRIVE)

■ Internal robot kinematics

$$\dot{x}_{m}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t))$$

$$\dot{y}_{m}(t) = 0$$

$$\Phi(t) = \frac{\mathbf{v}_{S}(t)}{d}\sin(\alpha(t))$$
(4)

BICYCLE MOBILE (FRONT WHEEL DRIVE)

■ Internal robot kinematics

$$\dot{x}_{m}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t))$$

$$\dot{y}_{m}(t) = 0$$

$$\dot{\Phi}(t) = \frac{\mathbf{v}_{S}(t)}{d}\sin(\alpha(t))$$
(4)

External robot kinematics

$$\dot{x}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t))\cos(\Phi(t))
\dot{y}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t))\sin(\Phi(t))
\Phi(t) = \frac{\mathbf{v}_{S}(t)}{d}\sin(\alpha(t))$$
(5)

$$\begin{bmatrix} \dot{x}(t) \\ \dot{y}(t) \\ \dot{\Phi}(t) \end{bmatrix} = \begin{bmatrix} \cos(\Phi(t)) & 0 \\ \sin(\Phi(t)) & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} \mathbf{v}(t) \\ \omega(t) \end{bmatrix}$$
(6)

, where $\mathbf{v}(t) = \mathbf{v}_{\mathsf{S}}(t) cos(\alpha(t))$ and $\omega(t) = \frac{\mathbf{v}_{\mathsf{S}}}{d} sin(\alpha(t))$

MOTION CONTROL OF REAR-WHEEL BICYCLE MOBILE ROBOTS

■ Internal robot kinematics

$$\dot{x}_{m}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t)) = \mathbf{v}_{r}(t)$$

$$\dot{y}_{m}(t) = 0$$

$$\Phi(t) = \frac{\mathbf{v}_{r}(t)}{d}\tan(\alpha(t)$$
(7)

MOTION CONTROL OF REAR-WHEEL BICYCLE MOBILE ROBOTS

■ Internal robot kinematics

$$\dot{x}_{m}(t) = \mathbf{v}_{S}(t)\cos(\alpha(t)) = \mathbf{v}_{r}(t)$$

$$\dot{y}_{m}(t) = 0$$


$$\Phi(t) = \frac{\mathbf{v}_{r}(t)}{d}\tan(\alpha(t)$$
(7)

External robot kinematics

$$\begin{bmatrix} \dot{x}(t) \\ \dot{y}(t) \\ \dot{\Phi}(t) \end{bmatrix} = \begin{bmatrix} \cos(\Phi(t)) & O \\ \sin(\Phi(t)) & O \\ O & 1 \end{bmatrix} \begin{bmatrix} \mathbf{v}_r(t) \\ \omega(t) \end{bmatrix}$$
(8)

32

, where $\omega(t) = \frac{\mathbf{v}_r}{d} tan(\alpha(t))$



External robot kinematics

$$\dot{x}(t) = v \cdot cos(\Phi(t) + \alpha(t))$$

$$\dot{y}(t) = v \cdot sin(\Phi(t) + \alpha(t))$$

$$\dot{\Phi}(t) = v/R = v/(d/sin(\alpha)) = v \cdot sin(\alpha)/d$$

$$\dot{\alpha} = \text{input (rate of change of steering angle)}$$
(9)

MOTION CONTROL OF REAR-WHEEL BICYCLE MOBILE ROBOTS




■ Bicycle model imposes curvature constraint, where curvature is defined by

$$k = \frac{\dot{x}(t)\ddot{y}(t) - \dot{y}(t)\ddot{x}(t)}{\left(\dot{x}^{2}(t) + \dot{y}^{2}(t)\right)^{3/2}}$$


■ Curvature constraint is non-holonomic $v^2 \leq \frac{a_{lat}}{k}$, where $a_{lat} \leq a_{lat_{max}}$

Ī





https://github.com/winstxnhdw/AutoCarROS2, https://doi.org/10.3390/s19214816



https://www.youtube.com/watch?v=i6uBwudwA5o

■ Uses steering principle, i.e., inner wheel, which is closer to its ICR, should steer for a bigger angle than the outer wheel, Consequently the inner wheel travels with slower speed than the outer wheel





Figure: Angular velocity speed descending order

Ackermann geometry is to avoid the need for tires to slip sideways when following the path around a curve which requires that the ICR point lies on a straight line defined by the rear wheels' axis

- Ackermann geometry is to avoid the need for tires to slip sideways when following the path around a curve which requires that the ICR point lies on a straight line defined by the rear wheels' axis
- Ackermann geometry can be seen as two bicycles welded together side by side

- Ackermann geometry is to avoid the need for tires to slip sideways when following the path around a curve which requires that the ICR point lies on a straight line defined by the rear wheels' axis
- Ackermann geometry can be seen as two bicycles welded together side by side
- For differential drive it needs individual drives at each wheel which makes the system more complex

- Ackermann geometry is to avoid the need for tires to slip sideways when following the path around a curve which requires that the ICR point lies on a straight line defined by the rear wheels' axis
- Ackermann geometry can be seen as two bicycles welded together side by side
- For differential drive it needs individual drives at each wheel which makes the system more complex
- Ackerman steering adjusts the relative angles of the steerable wheels so they both run true around a curve. Differentials allow the two driven wheels to run at different speeds around a curve, quite a different requirement



■ Steering wheels orientations

$$tan(\frac{\pi}{2} - \alpha_L) = \frac{R + l/2}{d} \rightarrow \alpha_L = \frac{\pi}{2} - arctan(\frac{R + l/2}{d})$$

$$tan(\frac{\pi}{2} - \alpha_R) = \frac{R - l/2}{d} \rightarrow \alpha_R = \frac{\pi}{2} - arctan(\frac{R - l/2}{d})$$
(10)

■ Steering wheels orientations

$$tan(\frac{\pi}{2} - \alpha_{L}) = \frac{R + l/2}{d} \rightarrow \alpha_{L} = \frac{\pi}{2} - arctan(\frac{R + l/2}{d})$$

$$tan(\frac{\pi}{2} - \alpha_{R}) = \frac{R - l/2}{d} \rightarrow \alpha_{R} = \frac{\pi}{2} - arctan(\frac{R - l/2}{d})$$
(10)

Back wheels (inner and outer) velocities

$$\mathbf{v}_L = \omega(R + \frac{l}{2})$$
 (11) $\mathbf{v}_R = \omega(R - \frac{l}{2})$

■ Steering wheels orientations

$$tan(\frac{\pi}{2} - \alpha_{L}) = \frac{R + l/2}{d} \rightarrow \alpha_{L} = \frac{\pi}{2} - arctan(\frac{R + l/2}{d})$$

$$tan(\frac{\pi}{2} - \alpha_{R}) = \frac{R - l/2}{d} \rightarrow \alpha_{R} = \frac{\pi}{2} - arctan(\frac{R - l/2}{d})$$
(10)

Back wheels (inner and outer) velocities

$$\mathbf{v}_L = \omega(R + \frac{l}{2})$$
 (11) $\mathbf{v}_R = \omega(R - \frac{l}{2})$


Inverse kinematics is quite complicated (TODO)


■ Unicycle Kinematic Model The simplest way to represent mobile robot vehicle kinematics is with a unicycle model, which has a wheel speed set by a rotation about a central axle, and can pivot about its z-axis. Both the differential-drive and bicycle kinematic models reduce down to unicycle kinematics when inputs are provided as vehicle speed and vehicle heading rate and other constraints are not considered.

- Unicycle Kinematic Model The simplest way to represent mobile robot vehicle kinematics is with a unicycle model, which has a wheel speed set by a rotation about a central axle, and can pivot about its z-axis. Both the differential-drive and bicycle kinematic models reduce down to unicycle kinematics when inputs are provided as vehicle speed and vehicle heading rate and other constraints are not considered.
- Differential-Drive Kinematic Model uses a rear driving axle to control both vehicle speed and head rate. The wheels on the driving axle can spin in both directions. Since most mobile robots have some interface to the low-level wheel commands, this model will again use vehicle speed and heading rate as input to simplify the vehicle control.


■ Bicycle Kinematic Model treats the robot as a car-like model with two axles: a rear driving axle, and a front axle that turns about the z-axis. The bicycle model works under the assumption that wheels on each axle can be modeled as a single, centered wheel, and that the front wheel heading can be directly set, like a bicycle.

- **Bicycle Kinematic Model** treats the robot as a car-like model with two axles: a rear driving axle, and a front axle that turns about the z-axis. The bicycle model works under the assumption that wheels on each axle can be modeled as a single, centered wheel, and that the front wheel heading can be directly set, like a bicycle.
- Ackermann kinematic model is a modified car-like model that assumes Ackermann steering. In most car-like vehicles, the front wheels do not turn about the same axis, but instead turn on slightly different axes to ensure that they ride on concentric circles about the center of the vehicle's turn. This difference in turning angle is called Ackermann steering, and is typically enforced by a mechanism in actual vehicles. From a vehicle and wheel kinematics standpoint, it can be enforced by treating the steering angle as a rate





https://www.youtube.com/watch?v=hu__jYsN6mw




https://www.youtube.com/watch?v=hu__jYsN6mw

Coordinate frames

- I inertial
- R robot
- S − steering
- W wheel


There are different types of wheel types, each of which has own constraints. For this course we only focus on standard wheel type. The following important assumptions are made

- Plane of wheel always remains vertical, where only one single point of contact between the and ground plane
- No sliding at this single point of contact



WHEEL KINEMATICS CONSTRAINTS: FIXED STANDARD WHEEL

- lacktriangle α , β , and l locate the relative to the robot internal (local) frame
- lacksquare θ is the angle between inertial x-axis and X_R (global frame)
- What differential constraints on velocity does the wheel impose on the chassis?



https://asl.ethz.ch/education/lectures/autonomous_mobile_rob

WHEEL KINEMATICS CONSTRAINTS: FIXED STANDARD WHEEL


Two constraints can be derived based on those assumptions. The position A is expressed in polar coordinates by distance l and angle α

rolling contact

$$[\sin(\alpha + \beta) - \cos(\alpha + \beta) - \cos(\alpha + \beta)][\dot{x} \dot{y} \dot{\theta}]^{\top} - r\dot{\Phi} = 0$$
(12)

■ no lateral slippage

$$[\cos(\alpha + \beta) \quad \sin(\alpha + \beta)$$
$$(l)\sin(\beta)][\dot{x} \ \dot{y} \ \dot{\theta}]^{\top} = 0$$
(13)



 Can control start pose to goal pose by classical control, where intermediate state trajectory is not prescribed or reference trajectory tracking

- Can control start pose to goal pose by classical control, where intermediate state trajectory is not prescribed or reference trajectory tracking
- Nonholonomic constraints need to be considered, in such occasion, the controller is is twofold: feedforward control and feedback control, namely two-dgree-of-freedom control.

- Can control start pose to goal pose by classical control, where intermediate state trajectory is not prescribed or reference trajectory tracking
- Nonholonomic constraints need to be considered, in such occasion, the controller is is twofold: feedforward control and feedback control, namely two-dgree-of-freedom control.
- Openloop control: feedforward control is calculated from the reference trajectory and those control action are fed to system

- Can control start pose to goal pose by classical control, where intermediate state trajectory is not prescribed or reference trajectory tracking
- Nonholonomic constraints need to be considered, in such occasion, the controller is is twofold: feedforward control and feedback control, namely two-dgree-of-freedom control.
- Openloop control: feedforward control is calculated from the reference trajectory and those control action are fed to system
- However, feedforward control is not practical as it is not robust to disturbance, feedback needs to be applied

- Can control start pose to goal pose by classical control, where intermediate state trajectory is not prescribed or reference trajectory tracking
- Nonholonomic constraints need to be considered, in such occasion, the controller is is twofold: feedforward control and feedback control, namely two-dgree-of-freedom control.
- Openloop control: feedforward control is calculated from the reference trajectory and those control action are fed to system
- However, feedforward control is not practical as it is not robust to disturbance, feedback needs to be applied
- Wheeled mobile robots are dynamic. Thus, motion controlling system has to incorporate dynamics of the system, in general, which systems are designed as cascade control schemes: outer controller for velocity control and inner controller to handle torque, force, etc.

23

TARGET (REFERENCE) POSE CONTROL

■ Pose = position + orientation

TARGET (REFERENCE) POSE CONTROL

- Pose = position + orientation
- Feasible path, which can be **optimal**, should satisfy the kinematic, dynamic, and other constraints including disturbances, appropriately

TARGET (REFERENCE) POSE CONTROL

- Pose = position + orientation
- Feasible path, which can be **optimal**, should satisfy the kinematic, dynamic, and other constraints including disturbances, appropriately
- Reference pose control, in general, is performed as two sub controlling tasks: orientation control and forward-motion control. However, these are interconnected each other

 Orientation control cannot be performed independently from the forward-motion control

- Orientation control cannot be performed independently from the forward-motion control
- Let robot orientation $\Phi(t)$, at time t, and reference orientation is $\Phi_{ref}(t)$

$$e_{\Phi}(t) = \Phi_{ref}(t) - \Phi(t) \tag{14}$$

- Orientation control cannot be performed independently from the forward-motion control
- Let robot orientation $\Phi(t)$, at time t, and reference orientation is $\Phi_{ref}(t)$

$$e_{\Phi}(t) = \Phi_{ref}(t) - \Phi(t) \tag{14}$$

■ How fast can we drive the control error to zero? It depends on additional factors: energy consumption, actuator load, and robustness

- Orientation control cannot be performed independently from the forward-motion control
- Let robot orientation $\Phi(t)$, at time t, and reference orientation is $\Phi_{ref}(t)$

$$e_{\Phi}(t) = \Phi_{ref}(t) - \Phi(t) \tag{14}$$

- How fast can we drive the control error to zero? It depends on additional factors: energy consumption, actuator load, and robustness
- Since $\dot{\Phi}(t) = \omega(t)$ is the input for control for diff drive, a proportional controller is able to drive control error of an integral process to o

$$\omega(t) = K(\Phi_{ref} - \Phi(t)) \tag{15}$$

, where K is an arbitrary positive constant

• $\dot{\Phi}(t) = \frac{\mathbf{v}_r}{d}tan(\alpha(t))$ is the input for control for Ackermann drive. The control variable is α , which can be chosen proportional to the orientation error:

$$\alpha(t) = K \left(\Phi_{ref}(t) - \Phi(t) \right)$$

$$\dot{\Phi}(t) = \frac{\mathbf{v}_r}{d} tan(K \left(\Phi_{ref}(t) - \Phi(t) \right))$$
(16)

26

 $\dot{\Phi}(t) = \frac{\mathbf{v}_r}{d}tan(\alpha(t))$ is the input for control for Ackermann drive. The control variable is α , which can be chosen proportional to the orientation error:

$$\alpha(t) = K \left(\Phi_{ref}(t) - \Phi(t) \right)$$

$$\dot{\Phi}(t) = \frac{\mathbf{v}_r}{d} tan(K \left(\Phi_{ref}(t) - \Phi(t) \right))$$
(16)

■ For small angle and constant velocity of rear wheels $\mathbf{v}_r(t) = V$, a linear approximation can be obtained,

$$\dot{\Phi}(t) = \frac{V}{d} (K \left(\Phi_{ref}(t) - \Phi(t) \right)) \tag{17}$$

TARGET (REFERENCE) FORWARD-MOTION CONTROL

■ Forward-motion control is inevitably interconnected with orientation control, i.e., forward-motion alone can not drive to goal pose without correct orientation


$$\mathbf{v}(\mathbf{t}) = K\sqrt{((x_{ref}(t) - x(t))^2 + (y_{ref}(t) - y(t))^2)}$$
 (18)

TARGET (REFERENCE) FORWARD-MOTION CONTROL

■ Forward-motion control is inevitably interconnected with orientation control, i.e., forward-motion alone can not drive to goal pose without correct orientation

$$\mathbf{v}(\mathbf{t}) = K\sqrt{((x_{ref}(t) - x(t))^2 + (y_{ref}(t) - y(t))^2)}$$
 (18)

■ However, $\mathbf{v}(t)$ should have maximum limits, which is due to actuator limitations driving surface conditions. On the other hand, when robot get closer to goal, it might try to over take the reference pose, which is eventually lead to accelerate, which is not desired



 It is required to reach to the target position where the final orientation is not prescribed, hence direction of reference position

$$\Phi_{r}(t) = \arctan \frac{y_{ref} - y(t)}{x_{ref} - x(t)}, \omega(t) = K_{1}(\Phi_{r}(t) - \Phi(t))$$

$$\mathbf{v}(\mathbf{t}) = K_{1}(\mathbf{v}_{ref}(t) - \mathbf{v}_{ref}(t))^{2} + (y_{ref}(t) - y(t))^{2}$$
(19)

It is required to reach to the target position where the final orientation is not prescribed, hence direction of reference position


$$\Phi_{r}(t) = arctan \frac{y_{ref} - y(t)}{x_{ref} - x(t)}, \omega(t) = K_{1}(\Phi_{r}(t) - \Phi(t))$$

$$\mathbf{v}(\mathbf{t}) = K \sqrt{((x_{ref}(t) - x(t))^{2} + (y_{ref}(t) - y(t))^{2})}$$
(19)

■ What will happen when orientation error abruptly changes $(\pm$ 180 degrees)? if the absolute value of orientation error exceeds 90 degree, orientation error increased or decreased by 180 degree

$$e_{\Phi}(t) = \Phi_{ref}(t) - \Phi(t), \omega(t) = K_1 \operatorname{arctan}(\tan(e_{\Phi}(t)))$$

$$\mathbf{v}(\mathbf{t}) = K \sqrt{((x_{ref}(t) - x(t))^2 + (y_{ref}(t) - y(t))^2)}.\operatorname{sgn}(\cos(e_{\Phi}(t)))$$
(20)



■ Idea is to shape in a way that the correct orientation is obtained

- Idea is to shape in a way that the correct orientation is obtained
- Intermediate point is determined by

$$x_t = x_{ref} - r \cos(\Phi_{ref})$$

$$y_t = y_{ref} - r \sin(\Phi_{ref})$$
(21)

, where distance from reference point to intermediate point denoted r

- Idea is to shape in a way that the correct orientation is obtained
- Intermediate point is determined by

$$x_t = x_{ref} - r \cos(\Phi_{ref})$$

$$y_t = y_{ref} - r \sin(\Phi_{ref})$$
(21)

- , where distance from reference point to intermediate point denoted r
- If distance between current and intermediate position $\sqrt{(x-x_t)^2+(y-y_t)^2} < d_{tol}$, where term d_{tol} depicts threshold, robot starts controlling to reference point

REFERENCES



Butterworth-Heinemann, 2017.

ROLAND SIEGWART, ILLAH REZA NOURBAKHSH, AND DAVIDE SCARAMUZZA.

INTRODUCTION TO AUTONOMOUS MOBILE ROBOTS. MIT press, 2011.

SEBASTIAN THRUN.

PROBABILISTIC ROBOTICS.

Communications of the ACM, 45(3):52–57, 2002.