PT-200 Pallet Tracker: User Manual

Demo document for Northwind Demo Ltd, a fictional company. The PT-200 is not a real product.

1. About the PT-200

The PT-200 is a handheld scanner that records where each pallet is in the warehouse. Scan the pallet label, then scan the shelf label. The location is sent to the stock system over Wi-Fi.

2. Safety

Use the PT-200 only between -20 and 45 degrees Celsius. Do not look into the scanner window while it is scanning. Do not open the case; there are no parts you can repair inside.

3. Charging the battery

Charge the PT-200 in its docking station for 3 hours before first use. A full charge lasts about 10 hours of scanning.

The battery light is green when the battery is full, amber while it is charging, and red when less than 15% charge is left.

Replace the battery after 500 charging cycles or when a full charge lasts less than 6 hours.

4. Error codes

- E12: the scanner window is dirty. Clean it with a dry, soft cloth.
- E31: no Wi-Fi connection. Move closer to an access point, or restart the device.
- E47: battery fault. Stop using the device and contact product support.

To restart the device, hold the power button for 10 seconds.

5. Warranty and support

The PT-200 has a 2-year warranty from the date of delivery. The warranty does not cover damage from drops or liquids.

Contact product support at support@northwind-demo.example or on extension 5100. Have the serial number ready; it is on the label under the battery.