


Flexi Full Motion Desk Mount



F160

Flexi Full Motion Desk Mount

Fits Most Monitors Size: 17"~27"

Max Load: 4. 4~14.3lbs (2~6.5kg)Single

VESA:75×75,100×100mm

Severe personal injury and property damage can result from improper installation or assembly.

Read the following warning carefully before beginning.

- Products must be installed by professional or installer.
- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing, if you require replacement parts, please contact your local distributor for assistance.
- This product fits most 17"-27" LCD / monitor; maximum weight of LCD / monitor: 6.5kg / 14.3lbs.
- Installer-friendly and straight forward.
- For safe installation, the desk you are mounting to must support minimum 3 times the weight of the total load (the mount, the monitor and all accessories weight).
- Do not use this product for other than the original designed.
- This product contain moving parts, please use with caution.
- When installing monitor, please do not damage electrical wiring or power source.
- Installation and routing of monitor cables on the monitor bracket must comply with electro-technical regulations.
- Importantly, mains- and data-cables must be secured against twisting and squeezing or shearing.
- The manufacturer will bear no responsibility to the desk of mounting, or incidental or consequential damages arising thereof.
- The manufacturer disclaims any liability for the modifications, improper installation, or installation over the specified weight range. The manufacturer will not be liable for any damages arising out of the use of, or inability to use, the product.
- This product is designed for indoor used only, use of this product outdoor could lead to product failer and severe personal injury.
- ▲ This product contains a high pressure gas spring, fire and percussion prohibited. Also it is strictly prohibited to dismantle without professionals. Please return to the manufacturer or hand over to professional agencies if the product is abandoned. In order to ensure the performance of gas spring, full direction adjustment of the product arm is recommended several times per month.

We reserve the right to modify or alter instructions. No modification or alteration without formal notice.

Symbols

	Tightening Direction		+ : Torque increased - : Torque reduced
	拧紧方向		+ 定点恒力加大 - 定点恒力减小
	loosening Direction		+ : Torque increased - : Torque reduced
	拧松方向		+ 定点恒力加大 - 定点恒力减小
	Phillips Screwdriver		By Hand
	螺丝起子		手工
	Open-End Wrench		Hex Wrench
	开口扳手		六角扳手
	Adjustment		Pencil
	调整		铅笔
OPT	Optional		Hand Drill
	可选		手电钻
	Remove		Star Wrench
	移开		安全扳手

F160

Installation Manual


Install mount at table edge
or
Install mount on desk.

Part list

			×2
A	B	C	
(M4x25)-8pcs	(M5x25)-8pcs	(M6x15)-6pcs	
D	E	F	
(Φ10xΦ5.2x1.5)-8pcs		(10mm) (4mm)	
		I	×2
(Φ8xΦ5x11)-8pcs			
G	H	I	
	(5mm)		


A1、Install mount at table edge:

Step 1




Warning:
Ensure screws are secured firmly.


Step 2



Step 3




Full motion after full installation (Table edge)





A2、Install mount on desk:


Step 1




Step 2




Full motion after full installation(Desk top)




B、 AV cables and wires routing



C、 Monitor installation




D、 Mounting monitor onto mount





E、 Setting static position

+ : Torque increased, - : Torque reduced.




F、Setting tilt angle position



G、Full 360° monitor rotation

Please beware of unbalance displays gravity during displays installation to mount.



TENSION ADJUSTMENT AFTER WALL MOUNT INSTALLATION



Warning

Do not adjust tension without putting on TV.

1.Ensure TV has been put onto mount.

2.Read your TV packaging or manual to find out TV net weight.

3.Ensure TV net weight between 5.5–15.4lbs(2.5–7kg)

Adjustment sign



Anti-clockwise reduce
tension(carry less weight)

clockwise to increase
tension(carry more weight)

Warning!



NB[®]
NORTH BAYOU

www.nbavmount.com


Add:58, South of Xinxing Road,
Economic Development Zone.
Kunshan City, Jiangsu Province, China.
215333.

TEL: 86-512-57971777
FAX: 86-512-57970776



Dual Monitor Desk Mount


Part No. GSMP0002



GSMP002



75x75/100x100



support@walelectric.com

WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



TIPOVER WARNING


**SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER.
TO HELP PREVENT TIPOVER:**

- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL.

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIP OVER.


SMALL PARTS- NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

Measure the thickness of your mounting surface or desk



Fit clamp: 0.4"~3.3"
Grommet: 0.4"~3.3"

Supplied Parts List



Arm
A (x1)



VESA Plate
B (x2)



C-Clamp Brace
C (x1)



C-Clamp
D (x1)



M6x10 Bolt
E (x2)



M6x12 Bolt
F (x3)



Metal Pad
G (x1)



Nut
H (x1)



Bolt
I (x1)



Support Plate
J (x1)



Allen Key 4mm
K (x1)



Allen Key 5mm
L (x1)



M4x12 Bolt
M-A (x8)



M5x12 Bolt
M-B (x8)




D5 Washer
M-C (x8)

Step 1


Option A

Clamp Installation

1. Connect Arm **A** and C-Clamp Brace **C** from the bottom using M6x12 Bolt **F** and tighten with Allen Key 4mm **K**.




2. Select the preferred height firstly and connect C-Clamp **D** to C-Clamp Brace **C** using M6x10 Bolt **E** and tighten with Allen Key 4mm **K**.




Option B Grommet Base Installation

1. Attach Metal Pad **G** & Bolt **I** to the bottom of Arm **A** using M6x12 Bolt **F**, tighten up with Allen Key 4mm **K**.




2a Existing Grommet Hole Installation

If the existing grommet hole comes with a plastic protector, remove it to ensure a flat surface before installing the desk mount. Insert the assembled Bolt **I** through the desk hole, guide the Support Plate **J** and Nut **H** through the Bolt **I**, rotate the Nut **H** clockwise to fasten for stability.



2b Self-drilled Grommet Hole Installation

Mark the position of the hole on your mounting surface. Drill a 3/8" (10mm) diameter hole at the marked position through the mounting surface. Insert the assembled Bolt **I** through the desk hole, guide the Support Plate **J** and Nut **H** through the Bolt **I**, rotate the Nut **H** clockwise to fasten for stability.




Step 2



Step 2.1

Select TV Screws

Only one screw size fits your TV




Hand thread screws into the threaded inserts on the back of your TV to determine which screw diameter (M4 or M5) to use.




Step 2.2

Attach the VESA Plate to your TV/Monitor, and thread M4x12 Bolt **M-A** or M5x12 Bolt **M-B** into the mounting holes with D5 Washer **M-C**, tighten with Allen Key 5mm **L**.



Step 3

Put the assembled TV/Monitor onto the Arm **A** and ensure the stability, tighten the VESA plate using Top Screw.




Step 4

Press the Arm **A** on horizontal level as image shown, adjust gas spring tension to your personal preference using Allen Key 5mm **L**, adjust the tilt tension using Allen Key 5mm **L**.

Adjust the Gas Spring Tension


- Insert the 5mm Allen Key into the adjusting hole and turn clockwise (-) to reduce gas spring tension, suitable for lighter screens.
- Insert the 5mm Allen Key into the adjusting hole and turn counter-clockwise (+) to increase gas spring tension, suitable for heavier screens.
- Please take note it may take numerous turns for gas spring tension adjustment.



- For Heavier Monitors
 For Lighter Monitors


Step 5

Screw out the bolts and take off the cable cases with Allen Key 5mm ①.




Step 6

Guide the cables through and put the cable cases back.



Step 7

Manually swivel, tilt, and rotate the monitor for the best viewing angle.





Thank you for choosing us!

We support the technology that brings your home to life.
We offer high quality products, professional customer service,
and extensive technical support.

If you have any questions, please contact us.

 1-844-SATTLER (18447288537)

 support@wallelectric.com

 www.wallelectric.com