## PleaseNote:

The foot must be completely stuffed into the hole, using a certain force to pull outward will not fall is installed, only so that it will not be crooked, please watch our installation video and then install!



