

CDA3331C Introduction to Microprocessor Laboratory Manual

Spring 2021

Prepared by Dr. Bassem A. Alhalabi

Department of Computer & Electrical Engineering & Computer Science

College of Engineering

Florida Atlantic University

FLORIDA ATLANTIC UNIVERSITY CEECS DEPARTMENT LOGIC DESIGN AND MICROPROCESSOR LAB

LD/MP Lab Rules and Regulations

- 1. Use your student's ID card to admit ONLY yourself and KEEP the door always CLOSED.
- 2. No smoking / drinking / eating is allowed in the lab. Keep the entire lab CLEAN.
- 3. Do not leave your own documents and/or papers in the lab.
- 4. Lab documents may not be checked out.
- 5. Do not INSTALL / COPY / DELETE / MODIFY any software in the lab.
- 6. Keep in your possession only the chips you are using in your current (or next) experiment.
- 7. When your lab is graded, return the chips to the recycle bin and wires to the wires pan.
- 8. Be conservative on wires by using short runs (1", 2", 5", ...). Reuse used wires.
- 9. Teaching Assistants will be available in the lab at scheduled times, which are posted.
- 10. Completed experiments must be checked/graded by the TA's during scheduled lab time.

Lab Usage Limitation

You must be enrolled in Logic Design or Microprocessor Courses to use this lab. Further, your experiment should be all thought of before taking time in the lab.

Security

You are continuously video taped for your security and against lab vandalism.

Problem Reporting

Any hardware/software failure and discovery of any lost or damaged item in the lab must be reported to the lab attendants or the CEECS technical support staff.

Penalties

Any violation and/or abuse of the Lab regulations and/or facilities may result in disciplinary actions and loss of lab access privileges.

Lab Access

You should aleady have access to the LD/MP lab via your student ID card. In using this access privilege, you indicate you read, understood, and accept all lab regulations.

FLORIDA ATLANTIC UNIVERSITY CEECS DEPARTMENT MICROPROCESSOR LAB

Experiments Grading Sheet

- 1. Students should maintain this sheet along with this whole lab manual for their own records.
- 2. TAs must sign and time/date next to every grade, and should indicate if the student cleaned up the workplace after grading each lab.

Lab#	TA Signature	Date	Time	Clean	Grade
0		/ / 2020	:	Y N	/ 5
	Special Remarks:				
1		/ / 2020	:	Y N	/ 15
	Special Remarks:				
2		/ / 2020	:	Y N	/ 20
	Special Remarks:	,		,	
3		/ / 2020	:	Y N	/ 20
	Special Remarks:				
4		/ / 2020	:	Y N	/ 20
	Special Remarks:			•	
5		/ / 2020	:	Y N	/ 20
	Special Remarks:			•	
6		/ / 2020	:	Y N	/ 20
	Special Remarks:			•	
Tota		/ / 2020	:	Y N	/1 20
	Special Remarks:				

Student Name:	Z#:	Sign:	ature:
---------------	-----	-------	--------

Important Info from the Class Syllabus

17. Required texts/reading

To reduce costs for our students, we strongly encourage you to explore the adoption of open educational resources (OER), textbooks and other materials that are freely accessible. We also encourage you to clearly state in the syllabus if course materials are available on reserve in the Library.

1-

Book, Required:

Programmable Microcontrollers with Applications: MSP430 Launch Pad with CCS and Grace

By Cem Unsalan, 1st Edition

http://smile.amazon.com/dp/oo71830030/ref=rdr_ext_tmb

Please read Chapters 1, 2, and 3 ahead.

Required Demo Board:

https://www.ti.com/store/ti/en/p/product/?p=MSP-

EXP430G2ET&keyMatch=MSP%E2%80%91EXP430G2ET&tisearch=Search-EN-everything

Technical User's Guide:

 $\frac{https://www.ti.com/lit/ug/slau772/slau772.pdf?ts=1609376312708\&ref_url=https\%253A\%252F\%252Fwww.ti.com/scauses-funiversalsearch.tsp\%253FsearchTerm\%253Dmsp430q2553\%2Blaunchpad$

The old demo board:

http://www.ti.com/tool/msp-exp430g2

Lab Kit, Required:

Lab kit including the above demo board, a breadboard, wires and various sensors and electronic parts will be distributed in class or mailed to your home address if class is online.

18. Supplementary/recommended readings

2-

Read about this demo board, Launchpad, ahead of time. This Launchpad may use an MSP430 microcontroller which is a different version from the one we are studying in the book, but still very much the same MSP430 family, meaning same basic architecture with different functions, memory size, and/or pin count.

Here is the TI original data sheets on the micro of the kit NSP430G2553.

http://www.ti.com/lit/ds/symlink/msp430g2553.pdf

Please keep copies of pages (3 and 5) with you all the times.

3-

Please read ahead about the compiler:

http://www.ti.com/tool/ccstudio?DCMP=PPC_Google_TI&k_clickid=7948fe70-5539-a2a8-dbbf-oooo2b86f1of And download it from:

http://processors.wiki.ti.com/index.php/Download CCS#Code Composer Studio Version 8 Downloads onto your laptop, which you should bring with you all the time when we start the labs.

If you do not have a laptop, you will need to use the one in the lab room EE203.

4-


Also below is the link for a cd you can download which has programming examples.

http://www.ti.com/general/docs/lit/getliterature.tsp?baseLiteratureNumber=SSQCo28&fileType=zip


Please bring with you to the lab your own small tools kit, basically a small pliers, wire cutter, and small screw drivers set. You can find small kits at Lowes, Home Depot, Radio Shack, etc.


Code Composer Studio, CCS

The image below is for a typical layout for CCS. A special class during the 3rd-4th week of the semester will be devoted as a lab orientation for CCS, using lab 0 as a first assembly program to explore.



The demo Board Pinout (MSP-EXP430G2ET)







• CDA3331C • Intro to Microcomputers •

Name/Semester: Grade: /5

[5] 0) This lab is designed to help students get acquainted with the MSP430 Launchpad microcontroller training kit. Type the following sample assembly language program which starts at address 0x0200 (&0200h), or simply \$200. The program adds the contents of three consecutive memory locations starting at address \$200. The sum is stored at location \$206. In the following subsections, various commands are listed for you to explore.

In the Code Composer, create a new Assembly Project and insert the following code into section label "Main loop here". You can also copy the entire skeleton program from the text file provided on your Canvas course.

LAB1	mov.w #01, &0200h mov.w #02, &0202h mov.w #03, &0204h	<pre>;set a number on location \$0200 ;set a number on location \$0202 ;set a number on location \$0204</pre>
LINEA	clr R7 clr R8 clr R9 clr R10	;clear the entire R7 register ;clear the entire R8 register ;clear the entire R9 register ;clear the entire R10 register
LINEB	mov.w &0200h, R7 mov.w &0202h, R8 mov.w &0204h, R9	copy a word from &0200h to R7; copy a word from &0202h to R8; copy a word from &0204h to R9
LINEC	mov.b R7, R10 add.b R8, R10 add.b R9, R10 mov.b R10, &0206h	<pre>;start accumulator in R10 with value form R7 ;add to it the content R8 ;add to it the content R9 ;now store the sum back in memory</pre>
Mainloop	jmp Mainloop	;Infinite Loop

Name/Semester: Grade: [1] 0.a) Exercise 1: Default program execution o Insert break point at the Mainloop line o Build and execute program o Record value of core registers when program stops at the breakpoint R7______, R8______, R9______, R10______, SR______, NZVC_____ [2] 0.b) Exercise 2: Memory manipulation o Soft Reset the micro o Insert break point at LINEB label o Insert break point at LINEC label o Keep the break point at Mainloop line o Run the program so it stops at LINEB o Record Values of the following registers: R7_____, R8_____, R9_____, R10_____, SR_____, NZVC____ o Using the memory browser, modify the content of following memory locations by manually typing the new values over the initial values (in decimal notation): $\mathbf{0}$ 0x0200 = **02**, 0x0202 = **03**, 0x0204 = **10** o Run the code, and now it will stop at LINEC o Record the updated values of the registers: R7_____, R8_____, R9_____, R10_____, SR_____, NZVC____ o Run the code, and now it will stop at Mainloop o Record the values again: R7_____, R8_____, R9_____, R10_____, SR_____, NZVC____ [2] 0.c) Exercise 3: Register manipulation o Soft Reset the micro o Remove the break points at LINEB and keep the ones at LINEC and Mainloop o Execute program to stop at LINEC o Record the new values: R7_____, R8_____, R9_____, R10_____, SR_____, NZVC____ o Manually modify the contents of Registers as follows: R7 = 05, R8 = 01, R9 = 0 (decimal notation) o Run the code till it stops at the last breakpoint, Mainloop o Record the new values:

R7_____, R8_____, R9_____, R10_____, SR_____, NZVC____

Name:	Grade:	/15

15] 1) Write an assembly program that adds the content of Registers R4, R5, and R6 to register R7 then subtract the content of R10 from R7. Once calculation is done all values of aforementioned registers must be saved in memory starting at memory address 0x0200. Use these register values: R4 = 4, R5 = 3, R6 = 10, R10 = 15. The overall program structure should be as follows:

Setup		;clear all registers	
	• • • • • •	;Setup Register Values	
Addition		;Add the content of registers	
	• • • • •	;R4,R5,R6 into R7	
Subtraction	• • • • •	;subtract content of R10 from R7	
Store	• • • • •	;Store the content of all Register used	
		; into memory including results in the	
	• • • • •	;Order R4, R5, R6, R10, R7.	
Mainloop	jmp Mainloop	;Infinite Loop	

- [3] 1.a) complete the above assembly program.
- [12] 1.b) Answer the Following Questions:

Name:	Grade:	/20
- 1 	323401	. = 0

- [20] 2) The program of this exercise deals with arrays of numbers and subroutines. Next page is the program outlines. At the beginning of your program you will allocate empty storage for two original arrays and their sorted versions. For the overall program layout, use the program skeleton file (lab2-v??-A-skl) available on Canvas.
- [16] 2.a) Complete this MSP430 assembly language program where the SORT1 section sets the R4/R5/R6 parameters, which are used by the COPY and SORT subroutines to copy and sort array ARY1. R4 holds the starting address of the array. R5 holds the length of the array. R6 holds the starting location of the sorted array. COPY subroutine copies the contents of array ARY1 into ARY1S. SORT subroutine sorts the elements on ARY1S in place. SORT2 section is similar to SORT1 above using same registers.

Arrays are in decimal notation! Sort Arrays in ascending order from lowest to highest value.

Main Program: [6] for Program setup, and [10] for Sort Subroutine.

Use the following values for the array elements. If the values in the skeleton code are different, use these values.

ARY1: (10, 33, -91, -75, 82, 11, -28, -99, 31, -92, 80), ARY2: (10, 21, 22, 20, -49, -80, 32, 62, 60, 61, -82)

[4] 2.b) Run your program and verify the results by using the <u>Memory Browser</u> window in the CCS Debug view. Write the Hex Values in order:

ARY1S:_____

ARY2S:____

Name: Grade: /20

```
;---- Your Sorting lab starts here -------
;Memory allocation of Arrays must be done before the RESET and Stop WDT
                             ;Memory allocation
ARY1
          .set
                  0x0200
                                                ARY1
ARY1S
                             ;Memory allocation
                  0x0210
                                                ARYS
          .set
                             ;Memory allocation
                                              ARY2
ARY2
          .set
                  0x0220
ARY2S
                  0x0230
                             ;Memory allocation
                                                AR2S
          .set
          clr
                   R4
                             ;clearing all register being use is a good
          clr
                   R5
                             ;programming practice
          clr
                   R6
SORT1
          mov.w
                   #ARY1, R4 ; initialize R4 as a pointer to array1
          mov.w
                   #ARY1S, R6 ;initialize R4 as a pointer to array1 sorted
          call
                   #ArraySetup1;then call subroutine ArraySetup1
          call
                   #COPY ;Copy elements from ARY1 to ARY1S space
          call
                   #SORT
                             ;Sort elements in ARAY1
                   #ARY2, R4 ;initialize R4 as a pointer to array2
#ARY2S, R6 ;initialize R4 as a pointer to array2 sorted
SORT2
          mov.w
          mov.w
                   #ArraySetup2; then call subroutine ArraySetup2
          call
          call
                   #COPY
                             ; Copy elements from ARY2 to ARY2S space
          call
                   #SORT
                             ;Sort elements in ARAY2
Mainloop
          jmp
                  Mainloop
                             ;Infinite Loop
ArraySetup1
          mov.b
                   #10, 0(R4)
                             ; Array element initialization Subroutine
          mov.b
                   #__, 1(R4) ;First start with the number of elements
                   #__, 2(R4)
                             ;and then fill in the 10 elements.
          mov.b
           . . . . . .
          ret
ArraySetup2 .....
                             ;Similar to ArraySetup1 subroutine
          ret
COPY
                             ;Copy original Array to allocated Array-
          . . . . . .
          ret
                             ;Sorted space
SORT
                             ; Subroutine SORT sorts array from
           . . . . . .
                             ; lowest to highest value
          ret
```

Name/Semester: Grade: /20

[20] 3) Implement the following arithmetic function using subroutines as a technique for efficient coding. The only input to the function is variable (a) that is initialized in register R4 at the beginning of the program to 5 and maintained thereafter. The X calculation result is stored in R5. The final answer, F, is stored in R7.

$$F = (\frac{4X + 40}{2})$$
 where $X = \sum_{i=0}^{i=|a|} (2(i!))$

[12] 3.a) Write an MSP430 assembly language program that implements the above function using subroutines for Multiplication and Factorial. The overall program structure is given in the skeleton below, which is available on Canvas as well. Please note that the multiply subroutine is included in the skeleton code. Please review how it works:

RESET StopWDT	mov.w mov.w		D,SP ;Initialize stack pointer OLD,&WDTCTL ;Stop WDT
LAB2	mov.w	#5, R4	;Load "a" into R4
CLEAR	clr clr clr	R5 R6 R7	;clear the entire register ;clear the entire register ;clear the entire register
XCALC			<pre>;the X calculation part of your program ;taking value of R4 as an input ;and returning result X in R5</pre>
FCALC			<pre>;the final part of your program ;taking inputs from R5 ;and returning result F in R7</pre>
MainLoop	jmp	Mainloop	;Infinite Loop
MULT			:Included in the skeleton code

- [4] Main Program [3] XCALC, [1] FCALC
- [8] Factorial Subroutine

Name/Semester:	Grade:	/20

[2] 3.b) Run your program and verify the results by examining registers

$$R4 = (a) = ____, in decimal = _5____$$

$$R5 = (X) = ____, in decimal = _____$$

[2] 3.c) Manually change the contents of R4 to 5, a new input value for variable a. Run your program and observe the results

$$R4 = (a) =$$
_____, in decimal = _6____

$$R5 = (X) = ____, in decimal = _____$$

[2] 3.d) Manually change the contents of R4 to -7, a new input value for variable a. Run your program and observe the results

$$R4 = (a) = ____, in decimal = _-7____$$


$$R5 = (X) =$$
_____, in decimal = _____

[2] 3.e) what is the maximum value of "a" that the function can execute correctly and why?

Name/Semester: Grade: /20

The MSP430 microcontroller is designed to allow port pins to be individually configured as digital input or digital output and in the case of Port1, all pins P1.0-P1.7 could also be configured as analog inputs. Some pins can be used as analog outputs (analog write). Finally some pins have specific functions, such as serial communication SPI. See the TI MSP430G2553 user's manual for complete description of all pins functionalities.

Assemble the circuit below making sure to follow the directions given during the class lectures. For digital inputs we are using six (6) dip switches connected to port Port2 pins 0-5. If your dip switches have more than 6 positions, ignore the unused ones. Please note the use of external pull-up resisters ($1K\Omega$) with the switches as they are all configured as active-low. When a switch is turned on, it asserts a logic zero (GND) on the port pin. When the switch is off, the pull-up resistor will make the micro pin floats high. For resisters, you can use discrete ones or a resistor network as shown in the photos below.



For digital outputs we are using eight (8) LEDs connected to Port 1 pins 0-7. Please note in the photo, we used 10-segment LED bar, we connected 8 of the LEDs and ignored the two on the right. In your kit, you may have discrete LEDs, so you can line up over the breadboard valley. Also note in the photo, we used a resister network for the current limiting resistors (330Ω) for the LEDs on the cathode (GND) side of the LEDs. The resister network has its common bus connected to the GND. Eight (8) wires are used to connect the anode side of the LEDs to the micro pins Port1, so the LEDs are configured as active high. A logic high signal (VCC) from the port pin will turn the LED on. For all the connections form the breadboard to the launchpad, we used Female-Male jumper cables.

If you choose to take MSP430G2553 chip off the Launchpad board and insert it on your breadboard directly, make sure you use a 3.3VDC supply on VCC pin. Also a Reset resistor of $47K\Omega$ must be used to connect Reset pin to VCC.

• CDA3331C • Intro to Microcomputers •


Name/Semester: Grade: /20

[20] 4) For this lab, you need to write a program in C that reads a 3-bit desired light pattern from the 3 input switches connected to pins P2.3-P2.5 and displays the pattern on the 8 LEDs (pins P1.0-P1.7) with some "light playing" options based on the input from other 3 switches (pins P2.0-P2.2), as described below. You should start with the skeleton code provided in your course Canvas site. Before you make any changes to the skeleton code, make sure all your hardware pieces are properly functioning. The following is how the program should be working, some of these requirements are already in the skeleton code.

- [8] 4.a) Switch on Port2.0 (Read/Rotate mode)
 - On (logic 0) Read mode: Your program continuously reads the switches and takes only the 3-bits (Port 2.3-2.5) as a desired display pattern and displays them on the LEDs (Port 1.3-1.5). All other LEDs on Port 1 are masked to zero (turned off). Already in the skeleton.
 - Off (logic 1) Rotate mode: Once this switch is turned off, your program will rotate the pattern on the 8 LEDs connected to Port1 pins 0-7. The pattern is the 3-bit value you constantly updated and saved during the Read mode.
 - o The skeleton code implements the Read mode, but for the Rotate mode, it would simply toggle the state of the 8-bit LEDs, part of which is the 3-bit pattern. You need to change the code so the pattern rotates on the 8 LEDs.
- [6] 4.b) Switch on Port2.1 (Left/Right direction mode)
 - On (logic 0) The LED pattern rotates to the Left.
 - Off (logic 1) The LED pattern rotates to the Right.
 - o The skeleton does not have code for this switch, but you can follow the way the skeleton reads the state of first switch. The C language does not have a rotate function, by you can implement it using shift and OR functions.
- [6] 4.c) Switch on Port2.2 (Fast/Slow speed mode)
 - On (logic 0) The pattern rotation is Fast.
 - Off (logic 1) The pattern rotation is Slow.
 - o Hint: use software delays.
- [2] 4.d) [BONUS] Modify the program so that the two Switches on Port2.0-1 provide four different fun patterns which continuously display/move on the 8 LEDs. Keep Switch on Port 2.2 to change speed. *Please be creative*.

Name/Semester: Grade: /20

- [20] 5) Write a C program using the MSP430G2553 Launchpad which creates a counter from 00-99. Your kit may have 7-seg displays with different pinout than the one in the drawings. As always check datasheets of your hardware components before wiring. For input control we use three DIP switches SW-321 which are connected to pins P2.5-3 with pull-up resistors. The different combinations of these 3 switches determine the operation of the counter as explained below. The two 7-segment digits are multiplexed (turned on alternately) by two control signals coming from P2.0 and P2.1. The two 2N2222 transistors with 1K Ohm resistors on the gate are used as power drivers for the Common Cathode pins of the displays. The 8 segments (a,b,c,d,e,f,g) of both displays are connected to Port 1 pins P1.0-P1.6 through a resister network (470-1000 Ohm). Please use the figure below as a sample how to organize components and wires on your breadboard. For exact pinout of the 2-digit 7-segment display, check the actual data sheet on the display part you are given in the lab kit. If the displays have Common Anode instead of Common Cathode, you need to use PNP transistors instead of NPN.
- [4] 5.a) Build the circuit as described above and run the skeleton code.
- [8] 5.b) Modify the code so that the counter initial number setup goes as follows. You may wish to slow down the display update so you see the changes better:
 - SW-321 = 000: Counter resets to 00
 - SW-321 = 001: Right digit cycles 0-9
 - SW-321 = 010: Left digit cycles 0-9
 - SW-321 = 011: Right and left digits both hold values (preset value)
- [8] 5.c) Counter counts up or down
 - SW-321 = 111: Counter cycles down from the preset value to 10, and repeats
 - SW-321 = 101: Recall the preset value
 - SW-321 = 110: Recall the preset value
 - SW-321 = 100: Counter cycles up from the preset value to 90, and repeats



• CDA3331C • Intro to Microcomputers •

Name/Semester: Grade: 20

[15] 6) In this lab, you will learn about reading analog values into the microcontroller. All pins of Port1 can be connected to analog signals which can vary form 0.0V-3.3V, and once converted by the internal ADC, the digital value for each port pin will be 0-255 for 8-bit resolution or 0-1023 for 10-bit resolution.


Assemble the following circuit with three analog signals as shown in the schematic below. For digital outputs we use the three LEDs 1, 2, and 3.

- The temperature sensor LM34DZ is connected to Port1.0 (A0). It is linear and it outputs 0.1 V for every degree, for example a room temperature of 78 F degrees, would show as a .78 V signal on your voltmeter, which is translated into 10-b digital value as .78 x (1023/3.3V) = 242. The exact value will fluctuate due to the imprecision of the sensor and the noise around it.
- The touch switch is connected to Port1.1 (A1) and a 100K ohm pull-up resistor. When you touch the transistor base, your body acts like a ground sinking a very little current from the PNP transistor, which is enough to trigger it due to its high gain (10,000). So when you touch the base and the transistor is turned on, the collector voltage will drop form VCC level (#1000 value) to almost ground (#50 value). To help your body to serve as a "better GND", touch the GND as well when you touch the base.
- The photo cell is connected to Port1.2 (A2). With the 10K resistor in series working as a voltage divider, you read about .97 VDC on A2 at room light. When you block the light completely from the photo sensor, the reading goes higher to 3.1 V. When you apply direct light onto the sensor, the reading goes lower to 0.3 V.
- LEDs 123 are connected to Port pins 1.4, 1.5, 2.0. LEDs must have current limiting resistors in series with value between 100-470 ohms.
- ➤ All above analog values are experimental, and they vary form one sensor to another. It is recommended that you actually measure the voltage with your voltmeter and do the math, and then check the corresponding values you read form the MSP430 internal registers.
- Analog vales are very fluctuating in nature and the ADC converter inside the micro works very fast, so it is recommended to add a small capacitor on the analog wire. In the software, it is also recommended to read few samples and average the reading.

The skeleton software provided in C will run on this circuit and it will write the three analog values in the three variables, temp, touch and light. Run the software and check the values in the debugger. Note that the skeleton code takes the initial room readings from the three sensors and saves them as baseline values before the program enter the infinite loop, lightroom, touchroom, and temproom.


- [8] 6.a) Observe how LED 1 changes on/off as you move your hand over the light sensor. Explain to the TA why LED1 is not flickering as it alternates between on and off, the hysteresis concept.
- [6] 6.b) Modify the main infinite loop so that If the room temperature reading increases by 2% over the room value, LED 2 turns on (think of it as an Air Conditioner). If the temperature decreases back to the original room temperature or below it, LED 2 will turn off. LED should not flicker!
- [6] 6.c) Modify the main infinite loop so that every time you touch the touch switch, LED 3 will toggle between on and off. LED 3 should not flicker!


Name/Semester: Grade: 20




Additional Lab Hints, Notes and Schematics Courtesy of Lab manager Perry Weinthal - EE205

Switches and LEDs connections










Seven-Segment Displays


- □ See the Datasheets for the parts in your kits. Use Google: part_number "datasheet .pdf"
 □ Some displays require each segment to be wired.
- ☐ Others have a common pin for each segment (CA or CC), which is used as a digit selection.
- □ *All LED segments require current limiting resistors:* R=180 330 ohm, lower for brighter, until your microcontroller smokes.

A Common Anode (CA) Display has the 7 LEDs connected together by their Anodes. A Common Cathode (CC) Display has the 7 LEDs connected together by their Cathodes. Some packages come with Joined Segments. There is a significant difference between these two types in how these LEDs are powered. "Common Anode segments draw current directly from the power source using the Vcc pin and sink it using Microcontroller pins, but Common Cathode LED's are sourced by pins of the microcontroller and sink by means of GND pin." Courtesy: Gadgetronicx











Common Anode



Common Cathode


For the Common Anode:

- ☐ A PNP will connect the Common Anode to the High (3.3V or 5V)
- □ 2n2907 or PN2907 or 2n3906 are PNP, ~500mA in a TO-92 type package (The "D" package)
- ☐ Emitter (Arrow Pointing IN) is connected to the "HIGH Rail"
- ☐ Base is an **Active LOW Control**
- ☐ Collector is to the Display Common



For the Common Cathode:

- ☐ A NPN will connect the Common Cathode to the Low (GND).
- □ 2n2222a or PN2222a or 2n3904 are NPN, 500mA in a TO-92 type package (The "D" package)
- ☐ Emitter (Arrow Pointing OUT) is connected to the "LOW Rail"
- ☐ Base is an **Active HIGH Control**
- ☐ Collector is to the Display Common




Sensors

Temperature Sensor:


Your kit may not contain the LM34/LM35/LM36.

Instead it may contain the MCP9700 or MCP9701, you need to look up the slope / curve of this device.



Light Sensor:

It is basically a light-sensitive resistor, so along with another resistor, it work like a voltage divider.



Touch Sensor:

It is a high gain PNP transistor, and your body touching the base acts like a ground.

