General Notes
Only written dimensions are to be followed.
Read the drawing along with Structural engineers drawing.
Any ambiguity in the drawing is to be referred to the architect before the execution of the work.
All dimensions are in Imperial Scale (Feet n Inches).











