

- Take the M3n nut and place it in the printed part (all the way in).
- Use the screw pulling technique.
- Rotate the X-carriage-back and tighten it together with the cable-holder.
- Check the "u-shaped" slot is aligned properly on both parts.

