

- For the following steps, please prepare:
- Extruder-idler (1x)
- Bondtech WITHOUT the hole for the set screw (1x)
- Bearing (2x) might be stuck inside the gear
- Shaft (1x)
- M3n nut (1x)
- M3x40 screw (2x)
- Idler spring (1x) place the spring on the screw

